

COVAC™
Sapphire capacitance diaphragm gauge
User's Manual
Models SPG5A and SPG6A



Thank you for purchasing the SPG5A or SPG6A. This manual contains information for ensuring correct use of the SPG5A / 6A. It also provides necessary information for installation, maintenance, and troubleshooting. This manual should be read by those who design and maintain devices that use the SPG5A / 6A. Be sure to keep this manual nearby for handy reference.

Please read the "Terms and Conditions" from the following URL before ordering or use:
<http://www.azbil.com/products/bi/order.html>

NOTICE

Be sure that the user receives this manual before the product is used.

Copying or duplicating this user's manual in part or in whole is forbidden. The information and specifications in this manual are subject to change without notice.

Considerable effort has been made to ensure that this manual is free from inaccuracies and omissions. If you should find an error or omission, please contact Yamatake Corporation.

In no event is Yamatake Corporation liable to anyone for any indirect, special or consequential damages as a result of using this product.

©2011 Yamatake Corporation ALL RIGHTS RESERVED.

SAFETY PRECAUTIONS

Safety precautions are for ensuring safe and correct use of this product, and for preventing injury to the operator and other people or damage to property. You must observe these safety precautions. Also, be sure to read and understand the contents of this user's manual.

! WARNING

- The burst pressure is the pressure at which this device will break. To avoid an accident, never apply pressure exceeding the burst pressure.

! CAUTION

- Use the SPG5A/6A within the operating ranges recommended in the specifications (temperature, humidity, voltage, atmosphere, etc.).
- Do not use this device in explosive atmospheres or near flammable fluids or steam.
- Always use the specified couplings and gaskets. After the piping work has been completed, check that there are no gas leaks before operating the device.
- When wiring the power for this device, be sure to install a master cut-off switch for the electrical power within easy reach of the operator.
- Wire the SPG5A/6A properly according to the standards given in this document, using the specified power source and installation methods. Not doing so might result in fire or device failure.
- Do not allow wire or solder clippings, water, etc. to enter the case of this device. They could cause fire or device failure.
- Do not block ventilation holes. Doing so might cause fire or device failure.
- The surface of this device is very hot while the power is ON and for a while after the power has been turned OFF. To avoid a burn, do not touch it during this period. When removing this device, turn the power OFF and allow sufficient time for it to cool.
- If there is a chance that work personnel will come in contact with this device after installation, take appropriate countermeasures. (Self-heating models)
- Do not use the relays in this device beyond their recommended service life. Doing so could cause fire or device failure.

OVERVIEW

The SPG5A/6A is a capacitance diaphragm vacuum gauge that uses a sapphire capacitance pressure sensor to achieve high accuracy and reliability, compact size, and light weight. Self-heating and non-self-heating models are available. On self-heating models, the heating temperature can be selected. The SPG5A/6A is especially suited for use in semiconductor manufacturing. It features the following:

- A single-crystal sapphire pressure sensing medium, offering excellent corrosion resistance, ability to withstand high temperatures, and excellent mechanical characteristics. The capacitive measurement design provides high repeatability even when used in a high-temperature environment.
- Small size and light weight, achieved by micromachining technology.
- Advanced signal processing technology, contributing to excellent temperature characteristics and linearity of measurement.
- Microprocessor-based digital PID, providing fast warm-up time and stable sensor temperature control. (Self-heating models)
- A wide range of supply power voltages.
- Easy zero point adjustment with automatic adjustment button or up/down zero adjustment buttons.
- SLP-SP5J60 Smart Loader Package (sold separately), for easy monitoring of the SPG5A/6A and setting of its parameters from a PC.
- Equipped with three event relays. Relay settings can be changed easily with the Smart Loader Package (SLP-SP5J60, sold separately).
- Conformity to IEC directives; CE-marked; compliance with EN61326 and EN55011.
- Does not contain any of the six hazardous substances forbidden by the RoHS directive.


Model selection table

I	II	III	IV	V	VI	VII	VIII	Example:SPG5AT11HD500500
Basic model No	Type	Additional function	Pressure range	Self-heating temperature	Coupling	Event 1 setting	Event 2 setting	
SPG								Sapphire capacitance diaphragm gauge
	5							Standard model
	6							Extra high-temperature model *
		A						Event configuration model
			---					Refer to the table on the left
				R				Without self-heating function
				D				125°C
				E				150°C
				F				160°C
				G				180°C
				H				200°C
					D			Equivalent to 8VCR (female) (SUS316L VIM/VAR electrolytic polishing)
						***		**.% FS Always OFF if "NNN" is specified.
							***	**.% FS Always OFF if "NNN" is specified.

For details about other pressure ranges, contact the Sales Dept. at Yamatake.

*Not available for non-self-heating models.

Part names



Smart Loader communication function


This device can be monitored and its parameters changed easily from a PC using the SLP-SP5J60 Smart Loader Package.

For more detail, refer to the manual for the Smart Loader Package, CP-UM-5499E


Monitoring	Pressure monitor SPG internal status monitor • Temperature of electronics circuit and of sensor head; DC supply voltage • Alarm status, failure status
Adjustment	Bias compensation Ratio compensation
Configuration	0 to 10V output settings
	0 to 10V output 0 V pressure for 0-10 V output
	10 V pressure for 0-10 V output
	Conditions for 0-10 V output
	0-10 V output value (abnormal status)
	Event relay settings
	Always OFF.
	Normal status: ON, Abnormal status: OFF.
	Normal status: OFF, Abnormal status: ON.
	Normal status: ON, Abnormal status: latch OFF.
	Normal status: OFF, Abnormal status: latch ON.
	Warm-up done: ON, Warm-up in progress or abnormal status: OFF.
	Warm-up done: OFF, Warm-up in progress or abnormal status: ON.
	Warm-up done: ON, In progress: OFF, Abnormal status: OFF latch.
Warm-up done: OFF, In progress: ON, Abnormal status: ON latch.	
Pressure high limit (direct action)	
Pressure low limit (direct action)	
Pressure high limit (reverse action)	
Pressure low limit (reverse action)	
Deviation high / low limit (Direct action)	
Deviation high / low limit (Reverse action)	
1st order filter time constant	
Instrumentation check	0 to 10V output simulation Event simulation

Operation charts for pressure interlock of event relays


Pressure high limit (Direct action)




Pressure low limit (Direct action)




Pressure high limit (Reverse action)




Pressure low limit (Reverse action)



Deviation high / low limit (Direct action)



Deviation high / low limit (Reverse action)



INSTALLATION

CAUTION

- Use the SPG5A/6A within the operating ranges recommended in the specifications (for temperature, humidity, voltage, atmosphere, etc.). Using it outside these ranges might cause fire or device failure.
- Always use the specified couplings and gaskets. After the piping work has been completed, check that there are no gas leaks before operating the device.

Installation locations

Install the device in a location with the following characteristics:

- Not subject to high or low temperature/humidity.
- Free from sulfide gas or other corrosive gases.
- Little dust or soot.
- Appropriate protection from direct sunlight, wind and rain.
- Little mechanical vibration or shock.
- Not near high voltage lines, welding machines, or other sources of electrical noise.
- At least 15 meters away from a high voltage ignition device for a boiler.
- Not subject to strong electromagnetic fields.
- Not an explosive atmosphere, and not near flammable fluids or steam.

Installation

When connecting this device to the piping, always use the specified couplings and gaskets, and check for leaks after installation is complete.


There are no limitations on mounting angle. However, since a zero-shift may occur at some angles, be sure to adjust the zero point after installation.

Handling Precautions

- Vibration may move the SPG's pressure-sensitive diaphragm, causing the pressure reading to fluctuate. Therefore, take appropriate measures so that this device is not subject to vibration. In particular, guard against vibration that would move the device along its axis (e.g., up-and-down vibration, if the device is mounted vertically).
- When installing, attach the coupling firmly, taking care not to apply any force to the case. Application of force to the case might break the device.
- For a model with a VCR coupling, check the cautions in the instruction manual from the coupling manufacturer and be sure you understand them fully before starting the installation work.
- This is a precision instrument. Do not drop it or bump it against any object. Application of any shock to this device might adversely affect its performance.
- If there is a chance that the temperature will exceed the operating ambient temperature range, install an appropriate cooling fan.

Note

- This device was calibrated at the factory in a vertical position. Shift of the zero point may have occurred, depending on the mounting angle. In such a case, accuracy can be recovered by adjusting the zero point after installation. Vertical installation is recommended to prevent contaminants from accumulating on the sensor unit.



WIRING

CAUTION

- Wire the SPG5A/6A properly according to the standards given in this document, using the specified power source and installation methods. Not doing so might result in fire or device failure.
- Do not allow wire clippings, shavings, water, etc. to enter the case of this device. They could cause fire or device failure.
- The surface of this device is very hot while the power is ON and for a while after the power has been turned OFF. To avoid a burn, do not touch it during this period. When removing this device, turn the power OFF and allow sufficient time for it to cool. If there is a chance that work personnel will come in contact with this device after installation, take appropriate countermeasures. (Self-heating models)
- When wiring the power for this device, be sure to install a master cut-off switch for the electrical power within easy reach of the operator.

Wiring Precautions

- Before wiring, mounting, or removing the SPG5A/6A, be sure to turn the power OFF.
- Before starting the wiring work, check the model No. of this device and the connector pin assignments (see page 4). Make sure that the wiring is correct.
- Devices or systems to be connected to the SPG5A/6A must have basic insulation sufficient to withstand the maximum operating voltage levels of the power supply and input/output components.
- Use a power supply suitable for instrumentation, and make sure that noise does not adversely affect this device.
- Use a power supply with a rated current equal to or greater than the maximum power current specified on p. 6 of this document.
- Use shielded cables for the wiring.
- Be sure to connect a ground wire to the frame ground.
- Use a power supply, connectors, and cables with appropriate ratings for voltage, current, etc. Make sure that the voltage at the connector of this device is within the specified power voltage range.
- Take care not to wire incorrectly. Wrong wiring may cause device failure.
- This device does not function for up to 10 s after the power has been turned on. Great care should be taken when the relay output from this device is used as an interlock signal.
- Do not connect multiple Smart Loader cables connected to multiple SPG5A/6A units to one personal computer at the same time. The current coming from other circuits might cause an output value indication error to occur.


■ WIRING

● Connector pin assignments (D-sub 15-pin)



Pin No.	Name
1	Event relay 3 (COM)
2	Output (+)
3	Power supply (COM) *1 *2
4	Event relay 2 (COM)
5	Power supply (-) *1
6	Event relay 3 (NO)
7	Power supply (+)
8	Event relay 3 (NC)
9	Event relay 2 (NO)
10	Event relay 2 (NC)
11	Event relay 1 (COM)
12	Output (COM) *2
13	Event relay 1 (NO)
14	Event relay 1 (NC)
15	FG *3

● Example of external connection

• ±15 Vdc (dual power supplies)




• 24 Vdc (single power supply)



- * 1. If using a single 24 Vdc input power supply, connect the power COM to the power “-”.
- * 2. The power COM and output COM are internally connected. If using a single 24 Vdc input power supply, do not connect the power COM and output COM together. Also, take care to avoid any wrong wiring that may cause a short circuit in other equipment. If the wiring is connected incorrectly, current from the power supply will also flow through the output line, and the voltage drop from wiring resistance may cause a measurement error.
- * 3. The FG is electrically continuous with the case, but is insulated from the power COM, output COM, and other terminals.

📖 Note

Event relay connection



When the power supply is turned off the event relay is turned off.

ADJUSTMENT AND START-UP

⚠ CAUTION

- The surface of this device is very hot while the power is ON and for a while after the power has been turned OFF. To avoid a burn, do not touch it during this period. When removing this device, turn the power OFF and allow sufficient time for it to cool. If there is a chance that work personnel will come in contact with this device after installation, take appropriate countermeasures. (Self-heating models)
- Do not block ventilation holes. Doing so might cause fire or device failure.
- Do not use the relays in this device beyond their recommended service life. Doing so could cause fire or device failure.

■ Turning the power ON

Use this device after warm-up is complete, 1 hour or more after turning the power ON.

- If warm-up is not finished, the status LED is orange.
- When warm-up is complete, the status LED turns green.

⚠ Handling Precautions

- This device does not satisfy specifications for accuracy during the warm-up period after the power has been turned ON, before the self-heating temperature has stabilized. Always use this device after warm-up is complete.
- If any problem with the operating environment (power voltage, ambient temperature, etc.) is detected during the self-diagnosis of this device, the status LED starts to flash red. If this occurs, turn off the power and check the instrumentation status.
- If any internal error is detected during the self-diagnosis of this device, the status LED lights up red. If this occurs, turn off the power and contact Yamatake.
- Do not apply a pressure to this device that exceeds the marginal pressure. Doing so might cause device failure.
- Take appropriate measures so that no contaminant enters this device. Otherwise a measurement error or device failure might occur.
- Take appropriate measures so that no foreign matter flows into this device. If it does, measurement error or device failure could result.
- For the pressure range characterized by molecular flow and intermediate flow, if the self-heating temperature of this device is different from the temperature inside the chamber to be measured, a minute pressure difference occurs due to thermal transpiration. To achieve especially accurate measurement, this must be taken into account. Factory calibration of this device assumes that no temperature difference exists. For details, refer to T. Takaishi and Y. Sensui, Trans. Faraday Soc. 59 (1963) 2503.

■ Zero point adjustment

- Adjust the zero point before using this device. Zero point adjustment should be done with a sufficient vacuum (1/20,000 or less of the selected pressure range span), 1 hour or longer after the power was turned on, after warm-up is complete.
- For accurate measurement, periodic adjustment of the zero point is recommended.

- When the zero point is adjusted, the bias adjustment values inside the device are updated. The updated bias adjustment value is added to the pressure measurement, which is then output. The factory setting for the bias adjustment value is 0.

Adjust the zero point in either of the two ways described below.

● Auto zero point adjustment

- (1) Apply a vacuum with a pressure of 1/20,000 or less of the selected pressure range.
- (2) Keep the auto zero point adjustment button pressed for 3 s. After zero point adjustment:
 - If the bias adjustment value is within $\pm 5\%$ FS, the status LED flashes green three times.
 - If the bias adjustment value is between $\pm 5\%$ and $\pm 20\%$ FS, the status LED flashes orange three times.

! Handling Precautions

- Auto zero point adjustment cannot be done in the following cases even if the button is pressed:
 - Before warm-up is complete.
 - If an error occurs.
 - If the required bias adjustment value is beyond $\pm 20\%$ FS.
- In these cases, the status LED flashes alternately red and orange three times.

● Manual zero point adjustment

- (1) Apply a vacuum with a pressure of 1/20,000 or less of the selected pressure range.
- (2) The 0-10 V output voltage changes when the up/down zero adjustment button is pressed. Adjust the output voltage to 0.

When the button is pressed, the speed at which the 0-10 V value changes depends on how long the button is pressed. Keep it pressed for a long time to do a quick rough adjustment. Afterwards, press it repeatedly for a short time to make fine adjustments.

- During adjustment using the up/down zero point button:
 - If the bias adjustment value is within $\pm 5\%$ FS, the status LED flashes green.
 - If the bias adjustment value is between $\pm 5\%$ and $\pm 20\%$ FS, the status LED flashes orange.
 - The status LED stops flashing about 3 s after the up/down zero point adjustment button is released, and the bias adjustment value is then set.
- Zero adjustment is restricted to the range in which the bias adjustment value is $\pm 20\%$ FS. If the bias adjustment value reaches $\pm 20\%$ FS as the up/down zero point adjustment button is pressed, the status LED flashes red.

! Handling Precautions

- Manual zero point adjustment cannot be done in the following cases even if the button is pressed:
 - Before warm-up is complete.
 - If an error occurs.
 - If the pressure value exceeds the measurement range.

In these cases, the status LED flashes alternately red and orange three times.

● Resetting of bias adjustment value

To reset the bias adjustment value to its factory setting, keep the auto zero point adjustment button pressed for 30 s or longer. The zero point is adjusted after 3 s, and the bias value is reset after 30 s. The status LED then flashes alternately green and orange three times.

■ Status LED display operation

Status LED	Status
Lit green	Normal operation status (after warm-up)
Lit orange	Warm-up in progress (device temperature is not yet stable)
Lit red	Abnormal status (a problem with the device)
Flashing red (0.3 s, 0.3 s)	Abnormal status (operating environment problem, such as excessive ambient temperature or wrong power voltage)
3 green flashes (0.3 s, 0.3 s)	Automatic zero point adjustment (by pressing the auto zero point adjustment button) is complete, and the bias adjustment value is within $\pm 5\%$ FS.
3 orange flashes (0.3 s, 0.3 s)	Automatic zero point adjustment (by pressing the auto zero point adjustment button) is complete. The bias adjustment value is between $\pm 5\%$ and $\pm 20\%$ FS.
Flashing green (0.1 s, 0.1 s)	The zero point is being adjusted with the up/down zero point adjustment buttons. The bias adjustment value is within $\pm 5\%$ FS.
Flashing orange (0.1 s, 0.1 s)	The zero point is being adjusted with the up/down zero point adjustment buttons. The bias adjustment value is between $\pm 5\%$ and $\pm 20\%$ FS.
Flashing red (0.1 s, 0.1 s)	During zero point adjustment with the up/down zero point adjustment buttons, the bias adjustment value reached the maximum adjustable range of $\pm 20\%$ FS.
Lit alternately red and orange 3 times (0.3 s, 0.3 s)	Because of the device conditions *, auto zero point adjustment and manual zero point adjustment cannot be done. * For the device conditions, see each Handling Precautions of auto zero point adjustment and manual zero point adjustment.
Lit alternately green and orange 3 times (0.3 s, 0.3 s)	The bias adjustment value has been reset.
Alternating green and orange with occasional red (1.9 s, 0.1 s)	The event relay is latched. *1
Lit alternately green and red. (0.3 s, 0.3 s)	Output is manually controlled. *2
Off	The device is not powered up.

*1 Latching of the event relay must be set up with the Smart Loader (sold separately).

*2 Output can be manually controlled with the Smart Loader (sold separately).

MAINTENANCE AND TROUBLESHOOTING

■ Maintenance

● Maintenance and inspection

- Check that the status LED is green during operation.
- Check periodically that there are no leaks in the piping.
- Adjust the zero point periodically.

● Cleaning

- Use a soft dry cloth.
- Do not use any organic solvent such as paint thinner or benzene.

● Part replacement

Do not disassemble the SPG5A/6A or attempt to replace any of its parts.

■ Alarm displays and corrective actions

The following table shows the alarm displays and corrective actions to take if there is a problem:

Status LED	Status	Possible Causes	Action
Flashing red	Alarm	<ul style="list-style-type: none"> • Temperature of electronic circuits • Temperature of sensor head • Heater temperature error • Self-heating control error • Wrong supply power voltage 	Turn off the power and check the power voltage, ambient temperature, and other operating conditions.
Red	Failure	<ul style="list-style-type: none"> • Heater wire break • Memory failure • Electronic circuit failure 	Turn off the power and contact a Yamatake dealer, agent, or salesperson. The device needs to be repaired by Yamatake.

Important notice: If you send this device to Yamatake for repair, fill out the Safety Sheet on page 8 and include it with the device.

■ Troubleshooting



Symptom	Action
Status LED does not light up	<ul style="list-style-type: none"> • Check that the wiring is connected correctly. • Check that the power voltage and polarity are correct.
Output value fluctuates	<ul style="list-style-type: none"> • Check that the wiring is connected correctly. • Adjust the zero point.

DISPOSAL

When disposing of this device, dispose of it appropriately as industrial waste in accordance with local regulations.

SPECIFICATIONS

Items	Specifications				
Pressure range	As specified in the model selection table.				
Self-heating temperature					
Accuracy	0.25 % of rdg.: No self-heating or self-heating temperature under 160 °C 0.5 % of rdg.: Models with self-heating temperature of 160 °C or more				
Temperature coefficients zero	Temperature coefficients at zero	Self-heating temperature range		Pressure range	
	0.004 % FS / °C	No self-heating or less than 160 °C		200 Pa or more	
	0.008 % FS / °C			Less than 200 Pa	
	0.008 % FS / °C	160 °C or more		200 Pa or more	
0.016 % FS / °C	Less than 200 Pa				
Temperature coefficients span	0.02 % rdg. / °C				
Resolution	1/10000 FS				
Operating temperature range	SPG5A (standard model)				
	Self-heating models: 10 to 45 °C (* Cooling air with a velocity of 0.5 m/s or more is required at 35 °C or more.) Non-self-heating models: 0 to 60 °C				
Operating humidity range	SPG6A (extra high temperature model)				
	Self-heating models: 10 to 65 °C (when mounted vertically), 10 to 70 °C (when mounted horizontally) (* Cooling air with a velocity of 0.5 m/s or more is required at 45 °C or more.)				
Storage temperature and humidity range	-20 to +80 °C, 10 to 95 % RH (without condensation)				
Response time	35 ms				
Gas-contacting materials	Sapphire, Inconel, SUS316L				
Internal capacity	7 cm ³ : Models with 8VCR coupling				
Allowable pressure *1	200 kPa abs : Models with pressure range of 100 kPa or more 110 kPa abs : Models with pressure range of less than 100 kPa				
Marginal pressure *2	300 kPa abs				
Burst pressure *3	700 kPa abs				
Input power supply	Voltage range: ±15 Vdc ± 10 % (dual power supplies) or 24 Vdc ± 10 % (single power supply) Allowable ripple voltage: 0.5 Vp-p max.				
Power consumption/ power current *4 *5	Self-heating temperature	Power consumption		Power current	
		During normal operation	During warm-up	±15 Vdc supply	24 Vdc supply
	(Non-self-heating model)	3 W max.	3 W max.	0.12 A max.	0.14 A max.
	125 °C	10 W max.	14 W max.	0.6 A max.	0.7 A max.
	150 °C	12 W max.	16 W max.	0.6 A max.	0.8 A max.
	160 °C	13 W max.	17 W max.	0.7 A max.	0.8 A max.
180 °C	15 W max.	19 W max.	0.8 A max.	0.9 A max.	
200 °C	16 W max.	23 W max.	0.9 A max.	1.1 A max.	
Output signal	Signal voltage: 0 to 10 Vdc Allowable load resistance: 10 kΩ min. Measurement output range: -0.5 to +11 Vdc *6 Output during warm-up or abnormal status: Output depends on the measured pressure *7				
I/O connector	D-sub 15-pin connector (male), retaining screw #4-40UNC				
Mass	520 g: Models with 8VCR coupling				
Warm up time	30 min (nominal), 1 h max.				
Zero point adjustable range	± 20 % FS				
Coupling	As specified in the model selection table.				
Leak rate	1×10 ⁻¹⁰ Pa · m ³ /s or less				
Mounting angle	Unrestricted *8				


Items	Specifications
Allowable cable length	10 m max.
Event relay ratings	Number of relays: 3 Contact form: 1c (both NO and NC contacts) Maximum load: 1A-30 Vdc resistance load Minimum load: 10 μ A 10 mVdc *10 Mechanical service life: 50 million cycles min. Electrical service life: 100 thousand cycles min. (with 1 A, 30 Vdc resistance load) Certifications: UL, CSA
Event relay functions default setting *9	Event relay 1: Pressure low limit (direct action) Setting: value is assigned by model No. Operating hysteresis: 0.5 % FS Always operates together with pressure during warm-up or abnormal status.  Event relay 2: Pressure low limit (direct action) Setting: value is assigned by model No. Operating hysteresis: 0.5 % FS Always operates together with pressure during warm-up or abnormal status.  Event relay 3: ON if warm-up complete and OFF if warm-up not complete or if status abnormal Event relay LED: Green when event relay ON, off when event relay OFF
Standards compliance	CE marked (EN61326, EN55011), RoHS compliant
Accessories (sold separately)	SLP-SP5J60 Smart Loader Package (with communication cable)

- *1. At the allowable pressure, the performance level of this unit can be maintained. However, if the SPG is repeatedly subjected to the allowable pressure, adjust the zero point periodically.
- *2. At the marginal pressure, this unit will continue to function. If the SPG is subjected to the marginal pressure, readjust the zero point. If more accurate measurement is required, return the unit to Yamatake for calibration. If the marginal pressure is exceeded, the proper operation of this unit can no longer be guaranteed. In this case, replace the unit with a new one.
- *3. The burst pressure is the pressure at which this device will break. To avoid an accident, never apply pressure equaling or exceeding the burst pressure.
- *4. Use an appropriate power supply with a rated current exceeding the max. power current value.
- *5. PID control is used to regulate the temperature and keep the rate of current supplied to the heater as constant as possible. Additionally, the maximum power current is varied depending on the power voltage, so that power consumption remains constant even during warm-up, irrespective of the power voltage. (Self-heating models)


- *6. Since a negative voltage is generated inside this unit, a negative voltage output is available even with only a single-output power supply.
- *7. The conditions and voltage can be changed using the Smart Loader.
- *8. This unit was calibrated at the factory in a vertical position. Shift of the zero point may have occurred, depending on the mounting angle. In such a case, accuracy can be recovered by adjusting the zero point after installation. Vertical installation is recommended to prevent contaminants from accumulating on the sensor unit.
- *9. The event relay functions can be changed using the Smart Loader.
- *10. The minimum load specification is an estimate of the minimum load at which the event relay is able to open and close. This value can vary depending on the frequency of operation, environmental conditions, and the expected reliability level. Before actual use, a check of the relay's operation using the actual load is recommended.

External Dimensions

- SPG5A (standard model)



- SPG6A (extra high-temperature model)



Unit: mm

IMPORTANT NOTE: If it is necessary to send this device back to Yamatake for repair, photocopy the following Safety Sheet, fill in the required items, and return the sheet with the unit.

The Safety Sheet is intended to ensure that the customer's product is safe for repair personnel and for the environment.

Without this sheet, Yamatake cannot start repair work. Please note that if the sheet is incomplete, Yamatake may request the customer to resubmit it.

Safety Sheet

To use, photocopy this page.

To: Yamatake Corporation

Statement by the End User (required prior to repair work)

I attest to the safety of this device based on the following evidence (check the applicable box):

- Hazardous substances have been purged or flushed completely.
- This device has been used only with clean, dry inert gas such as air, N₂, Ar, and He.

Model number: _____

Date code: _____

Serial number: _____

Name: _____

Date: _____

Department: _____

Company: _____

Phone: _____

Approved by (supervisor): _____

Comments or supplementary information:

(Do not fill in - for Yamatake internal use only) Dealer/Agent/Salesperson Information

Date: _____

Name: _____

Company: _____

Department: _____

Phone: _____

Date: _____

Name: _____

Company: _____

Department: _____

Phone: _____

Important Notice

Depending upon the degree of contamination of the device, Yamatake reserves the right to refuse repair.

Handling of personal information

We will use your personal information provided to us by this sheet only for the purposes of providing after-sales services to you.

azbil

Specifications are subject to change without notice. (08)

**Yamatake Corporation
Advanced Automation Company**

1-12-2 Kawana, Fujisawa
Kanagawa 251-8522 Japan

URL: <http://www.azbil.com>

1st Edition: Issued in Apr. 2011 (V)