



**MACHINE CONTROLLER
MX SERIES
MX200/MX100/MX50/MX30/MX20
User's Manual
Basic Programming**



Thank you for purchasing the Machine Controller MX200/MX100/MX50/MX30/MX20.

This manual contains information for ensuring correct use of the MX200/MX100/MX50/MX30/MX20. It also provides necessary information for installation, maintenance, and troubleshooting.

This manual should be read by those who design and maintain devices that use the MX200/MX100/MX50/MX30/MX20.

Be sure to keep this manual nearby for handy reference.

Yamatake Corporation

RESTRICTIONS ON USE

This product has been designed, developed and manufactured for general-purpose application in machinery and equipment. Accordingly, when used in the applications outlined below, special care should be taken to implement a fail-safe and/or redundant design concept as well as a periodic maintenance program.

- Safety devices for plant worker protection
- Start/stop control devices for transportation and material handling machines
- Aeronautical/aerospace machines
- Control devices for nuclear reactors

Never use this product in applications where human safety may be put at risk.

REQUEST

Ensure that this User's Manual is handed over to the user before the product is used.

Copying or duplicating this User's Manual in part or in whole is forbidden. The information and specifications in this User's Manual are subject to change without notice.

Considerable effort has been made to ensure that this User's Manual is free from inaccuracies and omissions.

If you should find any inaccuracies or omissions, please contact Yamatake Corporation.

In no event is Yamatake Corporation liable to anyone for any indirect, special or consequential damages as a result of using this product.

©1994 Yamatake Corporation ALL RIGHTS RESERVED

Machine controller MX200/MX100/MX50/MX30/MX20 is a trademark of Yamatake Corporation.

PC-9801 series is a trademark of NEC.

麋 番

The Role of This Manual

In all, 7 manuals have been prepared for the Machine controller MX200/MX100/MX50/MX30/MX20. Read the manual according to your specific requirements. The following lists all the manuals that accompany this controller and gives a brief outline of the manual: If you do not have the required manual, contact Yamatake Corporation or your dealer.




MX200 Specifications & Installation Manual

Manual No. CP-UM-1604E

This manual is required reading for first-time users of the Machine Controller MX200, those who design hardware for integrating the MX200 into operator control panels, and those who carry out maintenance.

It outlines the hardware configuration, product features and the other products used in combination with the MX200.

It also describes how to install and wire the MX200 for integrating into instruments, method of operation, maintenance and inspection, troubleshooting, and hardware specifications.




MX100 Specifications & Installation Manual

Manual No. CP-UM-1257E

This manual is required reading for first-time users of the Machine Controller MX100, those who design hardware for integrating the MX100 into operator control panels, and those who carry out maintenance.

It outlines the hardware configuration, product features and the other products used in combination with the MX100.

It also describes how to install and wire the MX100 for integrating into instruments, method of operation, maintenance and inspection, troubleshooting, and hardware specifications.




MX50

Manual No. CP-UM-1654E

This manual is required reading for first-time users of the Machine Controller MX50, those who design hardware for integrating the MX50 into operator control panels, and those who carry out maintenance.

This manual describes how to install and wire the MX50 into a device, maintenance and inspection, troubleshooting and hardware specifications.




MX30

Manual No. CP-UM-1423E

This manual is required reading for first-time users of the Machine Controller MX30, those who design hardware for integrating the MX30 into operator control panels, and those who carry out maintenance.

This manual describes how to install and wire the MX30 into a device, maintenance and inspection, troubleshooting and hardware specifications.



Basic Programming

Manual No. CP-UM-1562E

This manual.

This manual describes the basic knowledge required for programming the MX series, the internal structure of MX200/MX100/MX50/MX30/MX20 registers and memory, and basic programming procedures.




Programming Instruction Words

Manual No. CP-UM-1563E

This manual is required reading for programmers who write programs for the MX200/MX100/MX50/MX30/MX20 of machine controllers.

It gives detailed explanations of each instruction word and so can be used for reference.



Personal Computer Loader Operation

Manual No. CP-UM-1602E

This manual is required reading for those who write programs for the MX200/MX100/MX50/MX30/MX20 series of machine controllers.

This manual comes with a loader software package supplied on floppy disk. The loader software package supports the MX200, MX100, MX50, MX30 and MX20, and runs on an IBM PC AT series computer or an IBM compatible machine. This manual describes how to create an "execution system disk" and how to operate the personal computer loader.

Organization of This User's Manual

This manual is organized as follows.

Chapter 1 INTRODUCTION

This chapter describes MX programming characteristics, system configuration and operation modes.

Chapter 2 DEVICE TABLE & I/O ASSIGNMENTS

This chapter describes the structure of device tables, devices, I/O assignments and the OP link.

Chapter 3 PROGRAMMING NOTES

This chapter describes factors in the ladder design and function instructions that require special attention.

Chapter 4 DEBUGGING FUNCTION

This chapter describes debugging by inserting breakpoints and debugging through step operations.

Chapter 5 CONFIGURING & OPERATING PROCESSOR MODULES

This chapter describes the internal configuration, execution operations and scan times of the processor module.

Conventions Used in This Manual

The following conventions are used in this manual.

Handling Precautions

: Handling Precautions: Handling Precautions indicate items that the user should pay attention to when handling the MX series.

Contents

The Role of This Manual
 Organization of This User's Manual
 Conventions Used in This Manual

Chapter 1 INTRODUCTION

1-1	Design Procedures	1-1
1-2	MX Series Programming Characteristics	1-2
1-3	MX Series Programming Basics	1-3
	■ Basic system	1-3
	■ Communication systems	1-4
1-4	MX Operation Modes	1-6

Chapter 2 DEVICE TABLE & I/O ASSIGNMENTS

2-1	Device Table Configuration	2-1
2-2	Device Description	2-3
	■ External relay area (X, Y)	2-3
	■ Internal relay area	2-4
	■ Timer/counter area	2-5
	■ Register area	2-6
2-3	Special Relays and Registers	2-8
	■ Special relays	2-8
	■ Special registers	2-18
2-4	I/O Registration	2-33
	■ General-purpose I/O modules	2-33
	■ Operator's I/O	2-33
	■ Special I/O modules	2-34
	■ MX200/MX100/MX50	2-34
	■ Environment comprising operator's I/O and MX200/MX100/MX50 controllers	2-35
2-5	OP Links	2-36

Chapter 3 PROGRAMMING NOTES

3-1	Ladder Design Notes	3-1
	■ Program execution sequence	3-1
	■ Program shortcuts	3-2
	■ Creating programs for serial and parallel circuits	3-4
	■ Ladder display constraints	3-6
	■ Precautions to be taken in creating circuits	3-7
3-2	Using Function Instructions	3-12
	■ Range of numeric values	3-12
	■ Source and destination	3-13
	■ Instruction types	3-14
	■ Specifying pulse	3-14
	■ Specifying data	3-15
	■ Indirect addressing	3-17
	■ Flags	3-18

Chapter 4 DEBUGGING FUNCTION

4-1	Outline	4-1
4-2	Forced Setting, Resetting and Data Changing	4-2
	■ Forced setting, resetting and data changing	4-2
4-3	Breakpoints	4-3
4-4	Step Execution	4-5

Chapter 5 CONFIGURING & OPERATING PROCESSOR MODULES


5-1	Processor Module Configuration	5-1
	■ MX200	5-1
	■ MX100	5-2
	■ MX50	5-3
	■ MX30/MX20	5-4
5-2	Processor Module Operation	5-5
	■ Operation flow	5-5
	■ Main CPU operations	5-6
	■ Sub-CPU operations	5-7
	■ Ladder processing flow	5-8
5-3	Scan Time and Response Time	5-10
	■ Scan time	5-10
	■ I/O response time	5-14

Index

Chapter 1 INTRODUCTION

1 - 1 Design Procedures

The following flow chart describes each step involved in system design and provides references to related user manuals when using the MX series. The Basic Programming user manual mainly deals with I/O assignments and creation of ladder circuits.



- Check controller functions.
- Estimate the number of I/O points.
- Determine memory capacity.

- For details on registered I/O assignments of external relays (X, Y), see "Chapter 2, Device Tables and I/O Assignments."

- When designing ladder programs using MX instruction words, see "Chapter 3, Programming Notes" and "Programming Instruction Words, Manual No. CP-UM-1563E."

- Use the loader to load the program to the processor module.

- For details on using breakpoints and step operation to debug programs, see "Chapter 4, Debugging Function."

- Save the program to floppy disk (when using a personal computer loader) or memory card (when using a handy loader).

- — Indicates sections related to MX200/MX100/MX50/MX30/MX20 Programming Instruction Words (Manual No. CP-UM-1563E).
- ▭ — Indicates sections related to MX200/MX100/MX50/MX30/MX20 Specifications & Installation Manual (Manual No. CP-UM-1604E).
- ⋯ — Indicates sections related to MX200/MX100/MX50/MX30/MX20 Personal Computer Loader Operation (Manual No. CP-UM-1602E).

1 - 2 MX Series Programming Characteristics


Programming characteristics are as follows:

- ① A ladder language and mnemonic language are provided as standard.
- ② When a startup is standard during the processing of an instruction, the pulse can be specified by the instruction itself.
- ③ Data table instructions can be used to define preset multiple data items.
- ④ Strobe type instructions are provided to facilitate printer control and use of smart terminal (ST).
- ⑤ The use of conditional breakpoints allows real-time debugging something which was not possible with conventional controllers.

1 - 3 MX Series Programming Basics

Basic system

- Connect the processor module to the personal computer loader using an RS-232C crossover cable.
- If you connect operator's I/O to the processor module or MX50 using the RS-485 cable, only five wires will be required for operation button inputs and lamp outputs.





■ Communication systems

There are two types of communications: host communication and OP link communication.

① Host communication: Communication commands from a host computer are used for reading and writing MX data (I/O and alarms). The RS-232C port on the processor module is used for communications.

The following shows an example of a point-to-point and a multi-drop configuration that includes a host computer and an MX.

Host communication	Description
 <p>Host computer</p> <p>MX or MX20/MX30/MX50</p>	<p>Host computer: MX=1:1 The host computer can also be used as a personal computer loader.</p>
 <p>Host computer</p> <p>RS-232C/RS-485 converter module</p> <p>RS-232C/RS-485 converter module</p>	<p>Host computer: MX=1:N (On the MX20, N=9, while on the MX30 N=1.)</p>

② OP link: An MX100/200 is used as the master and an operator's I/O (simplified remote I/O) module, ST (smart terminal) or an MX100/200 are used as slave stations in a data link that does not require a program.

OP link	Description
<p>The diagram illustrates an OP link configuration. At the top left is the 'MX100/200 master station'. A horizontal line representing the data link extends from the master station to the right. Below this line, three slave stations are connected: 'Operator's I/O' (represented by a rack with arrows pointing to it), 'Smart terminal' (a terminal unit), and 'MX100 (slave station)' (another rack unit). A large bracket spans the bottom of these three slave stations, with the text '(The link can comprise a total of 320 processing points.)' written below it.</p>	<p>An OP link (RS-485) can contain up to five of the following modules.</p> <ul style="list-style-type: none"> ① Operator's I/O ② ST100/220 ③ MX100/MX200 <p>The link can comprise a total of 160 input processing points and 160 output processing points.</p> <ul style="list-style-type: none"> * ST100 has 16 input and 32 output points. * ST220 has 80 input points and 64 output points. <p>(Notes) A total of five MX100/200 modules can be connected as slave stations.</p>


OP link: OP link stands for Operational Communication link. This link is basically used for transmitting operational data between modules. It can be used by MX100 and MX200 controllers to establish a processor link (data link) as shown in the figure above.

1 - 4 MX Operation Modes

There are four MX operation modes:

1. RUN mode
 This mode is used to execute user programs
2. TEST mode
 Like the RUN mode, this mode is used for executing user programs and for real-time debugging using breakpoints during user program execution.
3. STOP mode
 The controller is in the STOP mode when the controller is turned ON or reset. User programs are stopped and I/O output is in OFF status in this mode. All other modes are accessed via this mode.
4. PROGRAM mode
 This mode is used to create programs. User programs are then stopped and I/O outputs are set to OFF.

Migration between the four modes is performed as follows.



Internal memory “device table” is held during migration from the RUN or TEST modes to the STOP mode, but is reset when the mode migrates from the STOP mode to the RUN or TEST modes.

! Handling Precautions

- When “forced set/reset” is used, the output conforms to the specified setting.
- When a “data change” is executed, output is for one scan only.
- RUN input and STOP input are contact inputs from the processor module terminal, while RUN C, STOP C and PROG C are mode selection commands input from the loader.
- The MX30/MX20 are not provided with contact inputs. They have an auto RUN function instead.
- The MX50 is not provided with contact inputs. They have an auto RUN function instead excluding when special settings are made.

Chapter 2 DEVICE TABLE & I/O ASSIGNMENTS

2 - 1 Device Table Configuration

The MX series has an internal memory called a "device table." The data in the table are assigned numbers which the instructions use to perform reading and writing.

	Device	Type	Address range	No. of points	Description
External relays	Input relay	MX200	X000 to X19F	320	Assigns DI modules.
		MX100	X000 to X09F	160	
		MX50	X000 to X19F	320	When the high-speed counter is not provided
			X000 to X15F	256	When the high-speed counter is provided, addresses X160 to X19F are assigned for the high-speed counter.
		MX30	X000 to X03F	64	Assigns DI modules.
		MX20	X000 to X00B	12	
	OP link input relay	MX200	X200 to X29F	160	Assigns OP I/O ST and other modules.
		MX100			
		MX50			
	Remote I/O input relay	MX30	X200 to X29F	160	Assigns CBL remote inputs.
	Output relay	MX200	Y000 to Y19F	320	Assigns DO modules.
		MX100	Y000 to Y09F	160	
		MX50	Y000 to Y19F	320	When the high-speed counter is not provided
			Y000 to Y15F	256	When the high-speed counter is provided, addresses Y160 to Y19F are assigned for the high-speed counter.
MX30		Y000 to Y03F	64	Assigns DO modules.	
MX20		Y000 to Y00B	12		
OP link output relay	MX200	Y200 to Y29F	160	Assigns OP I/O ST and other modules.	
	MX100				
	MX50				
Remote I/O output relay	MX30	Y200 to Y29F	160	Assigns CBL remote outputs.	
Internal relays	Auxiliary relay	MX200	M000 to M89F	1440	This area stores bit data. Bit data is cleared when the power is turned OFF and when the controller mode changes from STOP to RUN.
		MX100	M000 to M49F	800	
		MX50	M000 to M89F	1440	
		MX30	M000 to M49F	800	
		MX20			
	Latch relay	MX200	L000 to L49F	800	This battery-backed up area stores bit data.
		MX100			
		MX50			
		MX30			
		MX20			
	Special relay	MX200	M900 to M99F	160	Indicates alarm and error status.
		MX100	M900 to M94F	112	
			M980 to M99F	112	
		MX50	M900 to M99F	160	
MX30		M900 to M94F	112		
MX20	M980 to M99F				
Timer/Counter	MX200	T/C000 to T/C255	256	Indicates when a set timer or counter value has been reached. Indicates set value when used with WTCS and RTCS instructions, and current value when used with WTCA and RTCA instructions.	
	MX100	T/C000 to T/C199	200		
	MX50	T/C000 to T/C255	256		
	MX30	T/C000 to T/C199	200		
	MX20				

	Device	Type	Address range	No. of points	Description
Registers	Data register	MX200	R0000 to R0499 R1000 to R4999	4500W	This battery-backed up area stores word data.
		MX100	R0000 to R0499	500W	
		MX50	R0000 to R0499 R1000 to R4999	4500W	
		MX30	R0000 to R0499	500W	
		MX20			
	Input register	MX200	R0500 to R0519	20W	Assigned to special function modules
		MX100	R0500 to R0519	20W	
		MX50	R0500 to R0519	20W	When the high-speed counter is not provided
			R0508 to R0519	12W	When the high-speed counter is provided, addresses R0500 to R0507 are assigned for the high-speed counter.
		MX30	—	—	
	MX20				
	Output register	MX200	R0600 to R0619	20W	Assigned to special function modules
		MX100	R0600 to R0619	20W	
		MX50	R0600 to R0619	20W	When the high-speed counter is not provided
			R0608 to R0619	12W	When the high-speed counter is provided, addresses R0600 to R0607 are assigned for the high-speed counter.
		MX30	—	—	
	MX20				
	Special register	MX200	R0900 to R0999	100W	Registers all types of special data.
		MX100	R0900 to R0939	40W	
		MX50	R0900 to R0999	100W	
MX30		R0900 to R0939	40W		
MX20					
Link register	MX200	P0000 to P3999	4000W	CBL communication data register	
	MX100	—	—		
	MX50	P0000 to P3999	4000W		
	MX30	—	—		
	MX20				

2 - 2 Device Description

External relay area (X, Y)

Relay	Type	Address range	No. of points
Input relay	MX200	X000 to X19F	320
	MX100	X000 to X09F	160
	MX50	X000 to X19F	320 ^{*1}
	MX30	X000 to X03F	64
	MX20	X000 to X00B	12
OP link output relay	MX200	X200 to X29F	160
	MX100		
	MX50		
Remote I/O input relay	MX30	X200 to X29F	160
Output relay	MX200	Y000 to Y19F	320
	MX100	Y000 to Y09F	160
	MX50	Y000 to Y19F	320 ^{*2}
	MX30	Y000 to Y03F	64
	MX20	Y000 to Y00B	12
OP link output relay	MX200	Y200 to Y29F	160
	MX100		
	MX50		
Remote I/O output relay	MX30	Y200 to Y29F	160

*1 When the high-speed counter is provided, addresses X160 to X19F are assigned for the high-speed counter.

*2 When the high-speed counter is provided, addresses Y160 to Y19F are assigned for the high-speed counter.

These bit devices are used in transactions between the MX and external devices.


This area consists of the following relays:

- ① DI/DO input and output relays
- ② OP link input and output relays
- ③ Remote I/O input and output relays

OP link input and output is used to link to operator's I/O or to MX slave stations.

- I/O assignment assigns each X and Y device to input and output modules and operator's I/O terminals. For details, see 2-4 I/O Registration (page 2-33).
- Non-I/O assigned areas, except X areas, can be used as internal relays.
- There is no limit to the number of a and b contacts for a given XY device in the program.
- The first bit address determines whether data in these areas is to be read as 1-bit, 4-bit, 8-bit, 16-bit or 32-bit data. The number of bits is identified by each instruction word.

Example X001



16 bits X000 to X00F

■ Internal relay area

Relay	Type	Address range	No. of points
Auxiliary relay	MX200	M000 to M89F	1440
	MX100	M000 to M49F	800
	MX50	M000 to M89F	1440
	MX30	M000 to M49F	800
	MX20		
Latch relay	MX200	L000 to L49F	800
	MX100		
	MX50		
	MX30		
	MX20		
Special relay	MX200	M900 to M99F	160
	MX100	M900 to M94F	112
		M980 to M99F	
	MX50	M900 to M99F	160
	MX30	M900 to M94F	112
M980 to M99F			

Some internal MX relays cannot directly deal with external devices. There are no limits to the number of a and b contacts that can be used in a program.

- Auxiliary relay (M):
This internal bit device is not battery-backed up, and data is not held when any of the following conditions occur;
 - ① The MX power supply is turned OFF.
 - ② STOP mode changes to RUN.
 - ③ The RESET switch is pressed.
 - ④ The device is reset (RST).

- Latch (hold) relay (L):
This internal bit device is battery-backed up, and data is held when any of the following conditions occur:
 - ① The MX power supply is turned OFF
 - ② The RESET switch is pressed
 The latch relay is reset by issuing a latch clear from the loader.

- Special relay (M):
These internal bit devices automatically store alarm and error conditions. M980 to M99F cannot be used by the user program. See 2-3 Special Relays and Registers for details.

■ Timer/counter area

Device	Type	Address range	No. of points
Timer/Counter	MX200	T/C000 to T/C255	256
	MX100	T/C000 to T/C199	200
	MX50	T/C000 to T/C255	256
	MX30	T/C000 to T/C199	200
	MX20		

The timer (T) and the counter (C) have a total of 256 points for the MX200 and a total of 200 points for the MX100/30/20. The timer and the counter cannot use the same numbers. Contacts, current values and set values are not distinguished by the numbers used but by the type of instruction used.

- **Timer (T):**
Timer and counter area is used only for the ON delay timer (TMR), integrating timer (STM), timer/counter setting value write (WTCS), read (RTCS), writing current timer values (WTCA), and reading current timer values (RTCA) instruction words.
- **Counters (C):**
Timer and counter area is used only for the addition counter (CNT), double-length addition counter (DCNT), up-down counter (UDC), double-length up-down counter (DUDC), timer counter set value write (WTCS), read (RTCS), current value write (WTCA) and read (RTCA) instruction words. The double-length addition counter and the double-length up-down counter use two areas each. For example, when C001 is used for the double-length addition counter, C002 is also occupied. As a result, C002 cannot be used by any other timer or counter.

The table below gives the range of timer and counter settings.

Instruction word	Mnemonic	Setting range
ON delay timer	TMR	0.01 to 9999 sec.
Integrating timer	STM	0.01 to 9999 sec.
Addition counter	CNT	1 to 99999
Double-length addition counter	DCNT	1 to 99999999
Up-down counter	UDC	0 to 9999
Double-length up-down counter	DUDC	0 to 99999999

■ Register area

Register	Type	Address range	No. of points
Data register	MX200	R0000 to R0499 R1000 to R4999	4500W
	MX100	R0000 to R0499	500W
	MX50	R0000 to R0499 R1000 to R4999	4500W
	MX30/MX20	R0000 to R0499	500W
Input register	MX200	R0500 to R0519	20W
	MX100	R0500 to R0519	20W
	MX50	R0500 to R0519	20W ^{*1}
		R0508 to R0519	12W ^{*2}
MX30/MX20	—	—	
Output register	MX200	R0600 to R0619	20W
	MX100	R0600 to R0619	20W
	MX50	R0600 to R0619	20W ^{*1}
		R0608 to R0619	12W ^{*2}
MX30/MX20	—	—	
Special register	MX200	R0900 to R0999	100W
	MX100	R0900 to R0939	40W
	MX50	R0900 to R0999	100W
	MX30/MX20	R0900 to R0939	40W
Link register	MX200	P0000 to P3999	4000W
	MX100	—	—
	MX50	P0000 to P3999	4000W
	MX30/MX20	—	—


*1 When the high-speed counter is provided

*2 When the high-speed counter is provided, addresses R0500 to R0507 are assigned for the high-speed counter.

The register area, like the latch (hold) relay, is battery-backed up and the data it contains is not cleared when the power is turned OFF or the device is reset.

● Data register area:

The data register area is a 16-bit device for storing data in the MX. So, two registers are required to store 32-bit data. The specified address is the lower-order 16 bits and the specified address + 1 is the upper-order 16 bits.



● I/O register area:

This is a 16-bit device for storing the word data of special function modules. This area is assigned by I/O assignment.

-
- Special register area:
This is a 16-bit device for storing scan time data, module verification and stored data. These data items are stored automatically.

 - Link register area:
The link register is a data register for CBL communications. It is used for the following functions:
 - PC link
 - Remote I/O
 - Mail communication settings
 - Network information
 When CBL is not used, P0050 to P3199 can be used as a data register.

2 - 3 Special Relays and Registers

■ Special relays

Address	Contact	Type	Description	Applicable MX series device				
				200	100	50	30	20
M900	Shift carry	R/W	Carry used for shift related instructions	○	○	○	○	○
M901	Overflow		Turns ON when operation result exceeds the allowable numeric range.	○	○	○	○	○
M902	Underflow		Turns ON when operation result is below the allowable numeric range.	○	○	○	○	○
M903	Result of character string comparison		Turns ON when a character string comparison indicates a match. Otherwise OFF.	○		○		
M904	Remote transmission completed		Turns ON when Y200 data onwards is transmitted to the MX200. Turns OFF when the data is moved to the CBL LSI oscillation buffer.				○	
M905	Remote data reception		Turns ON when data received from MX200 is placed in X200 onwards. (When the END instruction has been executed, does not automatically turn OFF.)				○	
	Library input conditions		Input conditions for library instructions	○		○		
M906	Excessive remote speed		Turns ON when data received from MX200 is transmitted at a speed that exceeds the MX30 scan time.				○	
	User flag 1 for library		User flag 1 for library; the entry No. corresponds to bits 0 to 15 of R0960 and R0961.	○		○		
M907	Undefined CBL instruction received		Turns ON when the module receives a CBL command it does not support.				○	
	User flag 2 for library		User flag 2 for library; the entry No. corresponds to bits 0 to 15 of R0962 and R0963.	○		○		
M908	Instantaneous power failure		Turns ON after a recovery of an instantaneous power failure lasting longer than 20 ms is detected in the AC power supply and the MX power supply continued operation.	○	○			
M909	Unsuccessful CBL ring		Turns ON when there is an unsuccessful communication ring.				○	
M90A	MT failure		Turns ON when an MT problem causes a loopback.				○	
M90B	MR failure		Turns ON when an MR problem causes a loopback.				○	
	User alarm		The M92D turns ON when the contact is turned ON by the ladder.	○		○		
M90C	Unsuccessful CBL sub-ring		Turns ON when a failure occurs in the sub-ring during a non-loopback state.				○	
	Expansion program interface malfunction		Turns ON when the expanded program receives a CBL or ASCII communication that it cannot directly handle.	○		○		
M90D	Special module retry occurred		Turns ON when the READY wait time of a special function module is exceeded.	○				
M90E	Operation error 1		Turns ON when an operation error occurs during the execution of a function instruction. Turns OFF when the error is recovered or no other instruction caused an error.	○	○	○	○	○
M90F	Operation error 2	Operation error 1 latch	○	○	○	○	○	

(Note)

The "Type" column means the following:

R/W: Reading and writing is supported in a user program

R Only reading is supported in a user program

M: Only monitoring is supported (from the loader)

Address	Contact	Type	Description	Applicable MX series device				
				200	100	50	30	20
M910	Transmission of CBL read command	R/W	CBL: Turns ON when a request for transmission of a read command is received. The system turns it OFF when a response is received. (See MX30 CBL specifications for details.)				○	
M911	Transmission of CBL write command		CBL: Turns ON when a request for transmission of a write command is received. The system turns it OFF when a response is received. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 1. It automatically turns OFF after execution.	○	○	○		
M912	Reception of CBL polling communication		CBL: The system turns this contact OFF when a polling communication command is received. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 2. It automatically turns OFF after execution.	○	○	○		
M913	Transmission of CBL polling communication		CBL: Turns ON when a request for transmission of a polling communication command is received. The system turns it OFF when the transmission is completed. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 3. It automatically turns OFF after execution.	○	○	○		
M914	Abnormal termination of CBL reception		A CBL reception message terminated abnormally.				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 4. It automatically turns OFF after execution.	○	○	○		
M915	Abnormal termination of CBL transmission		A CBL transmission message terminated abnormally.				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 5. It automatically turns OFF after execution.	○	○	○		
M916	Reception of CBL multiplex command		Two or more WRITE commands and polling communications were received during one scan of MX30. (Processing during reception is determined by bit 15 of R0909.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 6. It automatically turns OFF after execution.	○	○	○		
M917	Excessive CBL reception commands		The amount of CBL data received exceeds processing capacity.				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 7. It automatically turns OFF after execution.	○	○	○		
M918	Error in CPL read parameter		CBL: The parameter setting in the read command is in error. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 8. It automatically turns OFF after execution.	○	○	○		
M919	Error in CBL write parameter		CBL: The parameter setting in the write command is in error. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 9. It automatically turns OFF after execution.	○	○	○		

Address	Contact	Type	Description	Applicable MX series device				
				200	100	50	30	20
M91A	One-shot execution of OP link	R/W	When ON this contact issues a communication command to OP link station number 10. It automatically turns OFF after execution.	○	○	○		
M91B	Parameter error in CBL polling communication transmission		CBL: The parameter setting in a transmitted polling communication is in error. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 11. It automatically turns OFF after execution.	○	○	○		
M91C	Error in CBL read response		CBL: The read response is in error. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 12. It automatically turns OFF after execution.	○	○	○		
M91D	Error in CBL write response		CBL: The write response is in error. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 13. It automatically turns OFF after execution.	○	○	○		
M91E	Error in CBL polling communication reception		CBL: An error was found in a received polling communication. (See MX30 CBL specifications for details.)				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 14. It automatically turns OFF after execution.	○	○	○		
M91F	CBL communication error		OR output for CBL alarm related contacts M906, M907, M909, M90A, M90B, M90C, M90D, M914, M915, M916, M917, M918, M919, M91B, M91C, M91D, M91E				○	
	One-shot execution of OP link		When ON this contact issues a communication command to OP link station number 15. It automatically turns OFF after execution.	○	○	○		

Address	Contact	Type	Description	Applicable MX series device				
				200	100	50	30	20
M920	Normally ON	R/W	Turns ON when the power is turned ON.	○	○	○	○	○
M921	Normally OFF		Turns OFF when the power is turned ON.	○	○	○	○	○
M922	ON during 1 scan		Turns ON for only one scan after start of program in RUN/TEST mode.	○	○	○	○	○
M923	OFF during 1 scan		Turns OFF for only one scan after start of program in RUN/TEST mode.	○	○	○	○	○
M924	Scan pulse		Turns ON and OFF repeatedly for each scan in RUN/TEST mode.	○	○	○	○	○
M925	20 ms clock		Turns ON and OFF repeatedly according to clock cycles.	○	○	○	○	○
M926	100 ms clock							
M927	1 second clock							
M928	1 minute clock							
M929	OP link scan completed	R/W	Turns ON for only one scan when the OP link scan completes.	○	○	○		
M92A	Remote I/O data valid	R/W	Turns ON when a remote I/O is set up and updated.	○		○		
M92B	—	—	Not used (always set to 0)					
M92C								
M92D	Alarm OR output	R/W		Turns OR output caused by alarm. See table below for details.	○	○		○
M92E	Loader monitor ON		Turns ON when the loader is connected and the monitor is ON.	○	○	○		
M92F	OP I/O connected		Turns ON when an OP I/O is connected.	○	○	○		
M930	—		—	Not used (always set to 0)				
M931	Battery failure	R/W	Turns ON when the voltage of the backup batteries is low and the batteries should be replaced.	○	○	○	○	○
M932	Fuse blown		Turns ON when a fuse in one of the modules in the slots is blown.	○	○			
M933	Loader communication error		A communication error occurred in the loader (a sum error or frame error).	○	○	○	○	○
M934	OP I/O communication error		Turns ON when a communication error occurred between an OP I/O and a processor module.	○	○	○		
M935	OP I/O verification error		Turns ON when a registered OP I/O does not respond.	○	○	○		

M92D Description of alarm output OR

MX200	OR for M908, M90B, M90C, M90D, M90E, M90F, M931 to M935, (M936, M93A to M93F)*, M970 to M97E, M98C, M98D
MX100	OR for M908, M90E, M90F, M931 to M935
MX30	M909, M90E, M90F, M931, M933
MX20	M90E, M90F, M931, M933

* When bit 4 of R0903 is ON, the alarm OR is canceled.

Address	Contact	Type	Description	
			Dedicated mode	General-purpose mode
M936	ASCII parameter error	R/W	Turns ON when transmission and reception parameters exceed the register area. Also M90E turns ON at this time.	Transmission and reception parameter error Turns ON when there is a nonconformity in data stored in R0941 to R0949.
M937	Request for forced termination of ASCII reception	R/W	Do not use this request.	Turns ON by the ladder program when ASCII reception is forcibly terminated. Turns OFF automatically when ASCII reception is completed.
M938	Request for ASCII transmission	R/W	Turns ON automatically when there is a request for ASCII communication (by execution of the SXRS or SXWS instructions). Turns OFF automatically when the transmission is completed.	Turns ON by the ladder program when there is a request for ASCII transmission. Turns OFF automatically when ASCII transmission is completed.
M939	Request for ASCII reception	R/W	Turns ON automatically when there is a request for ASCII communication (by execution of the SXRS or SXWS instructions). Turns OFF automatically when the reception is completed.	Turns ON by the ladder program when there is a request for ASCII reception. Turns OFF automatically when ASCII reception is completed.
M93A	ASCII time-out error	R/W	Turns ON automatically when the response monitoring time set by the SNOD instruction is exceeded during ASCII communication (by execution of the SXRS or SXWS instructions) and the number of retries is completed. Turns OFF automatically when a new request for ASCII communication (by execution of the SXRS or SXWS instructions) is issued.	Turns ON when the time set from completion of ASCII transmission (M938 OFF) up to ASCII reception (M939 OFF) exceeds the monitoring time preset by R0941. Turns OFF automatically at the startup of the request for ASCII reception (M939).
M93B	ASCII reception buffer full	R/W	Normally OFF	Turns ON when the data in the reception buffer exceeds 1024 bytes or when the data exceeds 768 bytes during RTS control.
M93C	ASCII response error	R/W	Turns ON automatically when the response code for the reception data is a value other than "00". Turns OFF automatically when a new request for ASCII communication (by execution of the SXRS or SXWS instructions) is issued.	Normally OFF
M93D	ASCII reception data error	R/W	Turns ON when a parity, framing or overrun error is found in ASCII reception data. Turns OFF automatically when a new request for ASCII communication (by execution of the SXRS or SXWS instructions) is issued.	Turns ON when a parity, framing or overrun error is found in ASCII reception data. Turns OFF automatically when a request for ASCII reception (M939) starts.
M93E	ASCII reception checksum error	R/W	Turns ON when an incorrect checksum result is found in ASCII reception data. Turns OFF automatically when a new request for ASCII communication (by execution of the SXRS or SXWS instructions) is issued.	Turns ON when an incorrect checksum result is found in received data. Turns OFF automatically when a request for ASCII reception (M939) starts.
M93F	ASCII alarm	R/W	Turns ON when an address between M93A to M93E is ON and turns OFF when all addresses are OFF.	

Note) M936 to M93F can only be used with the MX200/MX50.

Address	Contact	Type	Description	Applicable MX series device					
				200	100	50	30	20	
M940	STB instruction is being executed.	R/W	Y000 to 008	ON during execution of STB instruction	○	○	○	○	○
M941			Y010 to 018	OFF when instruction is not being executed					
M942			Y020 to 028						
M943			Y030 to 038						
M944			Y040 to 048	ON during execution of STB instruction	○	○	○		
M945			Y050 to 058	OFF when instruction is not being executed					
M946			Y060 to 068						
M947			Y070 to 078						
M948			Y080 to 088						
M949			Y090 to 098						
M94A to M94D			—	—	Not used (always set to 0)				
M94E	Clock data setting	R/W	When the state of this contact changes from OFF to ON, the data in the R0994 to R0997 check registers is written to the internal clock. This is used to adjust the clock.		○		○		
M94F	Fixed I/O	R/W	Turns ON when I/O registration data is used to fix the I/O configuration.		○	○	○	○	

Address	Contact	Type	Description	Applicable MX series device					
				200	100	50	30	20	
M950	Communication to one destination (response given) Command transmission and reception flag	R/W	R/W buffer 0	Conditions for turning ON: Turns ON by the ladder program when a request for transmission of a read or write command is issued. Automatically turns ON at periodic intervals.					
M951			buffer 1						
M952			buffer 2						
M953			buffer 3						
M954			buffer 4						
M955			buffer 5	Conditions for turning OFF: When a response is received When the following errors occur: Transmission parameter error Transmission error Time-out Reception parameter error Reception of error frame Periodically occurring error		○		○	
M956			buffer 6						
M957			buffer 7						
M958			buffer 8						
M959			buffer 9						
M95A			buffer 10						
M95B			buffer 11						
M95C			buffer 12						
M95D			buffer 13						
M95E			buffer 14						
M95F			buffer 15						

Address	Contact	Type	Description	Applicable MX series device					
				200	100	50	30	20	
M960	Communication to one destination (no response) Polling communication command Transmission flag	R/W	Transmission buffer 0	Conditions for turning ON: Turns ON by the ladder program when a request for command transmission is issued. Turns ON automatically at periodic intervals. Conditions for turning OFF: Turns OFF when transmission starts or when any of the following errors occur: • Transmission error • Transmission parameter error • Periodically occurring error	○		○		
M961			buffer 1						
M962			buffer 2						
M963									
M964	Communication to one destination (no response) Polling communication command Reception flag	R/W	Reception buffer 0	Conditions for turning ON: Turns ON by the ladder program to check reception. Conditions for turning OFF: Turns OFF when a command is received.	○		○		
M965			buffer 1						
M966			buffer 2						
M967									
M968	—	—	Not used (always set to 0)						
M969									
M96A									
M96B									
M96C									
M96D									
M96E									
M96F									

Address	Contact	Type	Description	Applicable MX series device				
				200	100	50	30	20
M970	CBL communication error	R/W	Turns ON when any of addresses M971 to M97E is ON, and OFF when they are OFF.	<input type="radio"/>		<input type="radio"/>		
M971	Mail communication error		Turns ON when a mail communication error occurs.	<input type="radio"/>		<input type="radio"/>		
M972	PC link error		Turns ON when a PC link error occurs.	<input type="radio"/>		<input type="radio"/>		
M973	Remote I/O error		Turns ON when remote I/O is in error or when a registered remote I/O configuration is not matched.	<input type="radio"/>		<input type="radio"/>		
M974	CBL address setting error		Turns ON when the communication setting is in error.	<input type="radio"/>		<input type="radio"/>		
M975	Unsuccessful ring		Turns ON when communication with an adjacent CBL node is not possible.	<input type="radio"/>		<input type="radio"/>		
M976	MT error		Turns ON when there is a loopback on the MT.	<input type="radio"/>		<input type="radio"/>		
M977	MR error		Turns ON when there is a loopback on the MR.	<input type="radio"/>		<input type="radio"/>		
M978	Loopback		Turns ON when a loopback occurs somewhere in the local station and CBL.	<input type="radio"/>		<input type="radio"/>		
M979	Sub-ring error		Turns ON when a sub-ring error occurs somewhere in the local station and CBL.	<input type="radio"/>		<input type="radio"/>		
M97A	PC link P area error		Turns ON when data is received from a link station other than the local station and in a different operation mode.	<input type="radio"/>		<input type="radio"/>		
M97B	Remote I/O P area error		Turns ON when a data input or output of more than 26 words is specified in the single mode, when a data input or output of more than 51 words is specified in the dual mode or when data is received from a node with an address No. greater than 32 in the dual mode.	<input type="radio"/>		<input type="radio"/>		
M97C	—	—	Not used (always set to 0)	<input type="radio"/>		<input type="radio"/>		
M97D	Remote I/O EEPROM error	R/W	Turns ON when an error occurs in the EEPROM that stores the remote I/O assignment data.	<input type="radio"/>		<input type="radio"/>		
M97E	Duplicate CBL address error		Turns ON when there is a node with the same address as the local address.	<input type="radio"/>		<input type="radio"/>		
M97F	CBL option		Turns ON when a CBL option board is installed.	<input type="radio"/>		<input type="radio"/>		

Address	Contact	Type	Description	Applicable MX series device				
				200	100	50	30	20
M980	In compilation	M	In compilation	○	○	○		
M981	RUN mode		In RUN mode	○	○	○	○	○
M982	TEST mode		In TEST mode	○	○	○	○	○
M983	STOP mode		In STOP mode	○	○	○	○	○
M984	PROG mode		In PROG mode	○	○	○	○	○
M985	—	—	Not used (always set to 0)					
M986	Error	M	Cause of error: OR output from address range M990 to M99F	○	○	○	○	○
M987	Alarm		OR output caused by alarm: same as for M92D	○	○	○	○	○
M988	—	—	Not used (always set to 0)					
M989	RUN terminal	M	Turns ON when the RUN terminal input is ON.	○	○			
M98A	—	—	Not used (always set to 0)					
M98B	STOP terminal	M	Turns ON when the STOP terminal input is ON.	○	○			
M98C	Special register EEPROM transmission error	M	A reset was performed during a data write to the EEPROM and data was corrupted. This is caused by a checksum error in the special register storage EEPROM.	○		○		
M98D	User EEPROM write error		Turns ON when data is not properly written to a user EEPROM.	○				
M98E	—	—	Not used (always set to 0)					
M98F								

Address	Contact	Type	Description	Applicable MX series device				
				200	100	50	30	20
M990	Bus error	M	Turns ON when an I/O bus line failure prevents normal access to all I/O modules.	○	○			
M991	I/O verification error	M	Turns ON when the I/O module configuration does not match registered I/O (FIX).	○	○	○		
M992	I/O module error	M	Turns ON when the system contains an I/O module that cannot be identified or does not respond normally.	○	○	○		
M993	—	—	Not used (always set to 0)					
M994	User ROM/memory card error	M	Defective user program ROM or memory card (MX100)	○	○	○	○	○
M995	CBL communication LSI error		Error occurred during communication LSI check.	○		○	○	
M996	—	—	Not used (always set to 0)					
M997								
M998	User WDT error	M	User watchdog timer time-out	○	○	○	○	○
M999	Program damaged		Checksum verification error in user program	○	○	○	○	○
M99A	Program incomplete		Syntax error in user program	○	○	○	○	○
M99B	Compile error		Some code in user program cannot be compiled.	○	○	○	○	○
M99C	Object code size exceeded		The size of the object code exceeds the capacity of the compiler RAM.	○		○		
M99D	—	—	Not used (always set to 0)					
M99E	AC power supply setting error	M	The power supply is set for 200V ac, but 100V ac is supplied.	○				
M99F	Sub-processor failure		Turns ON when an error occurs in the sub-processor, preventing data transactions between the sub-processor and the main processor.	○		○		

■ Special registers

Address	Register	Bit configuration				Description	Applicable MX series device							
		15	12	11	8		7	4	3	0	200	100	50	30
R0900	Min. scan time	x10 ³	x10 ²	x10	x1	Min. scan time value (ms) Default = 9999	○	○	○	○	○			
R0901	Last scan time	x10 ³	x10 ²	x10	x1	Last scan time value Default = 0000	○	○	○	○	○			
R0902	Max. scan time	x10 ³	x10 ²	x10	x1	Max. scan time value Default = 0000	○	○	○	○	○			
R0903	CBL address display LED	—		LED display data		Sets CBL node address in a lower-order byte at power up							○	
	Hardware switching					Switching between OP link of OP I/O terminal and ASCII or between instantaneous alarm latch and clear (See Note 1).	○		○					
R0904	Operation error 1	Step No.				The step No. where an operation error occurred. When the mode is changed from STOP to RUN or STOP to TEST, the oldest errors are cleared. Only four errors are stored at any one time. Step number 1 is the oldest error and step number 4 is the latest. A binary value in the range #0000 to FFFF	○	○	○	○	○			
R0905	Operation error 2	Step No.												
R0906	Operation error 3	Step No.												
R0907	Operation error 4	Step No.												
R0908	Personal computer link computer setup data	Personal computer link data	Not used		Data for setting host communication with personal computer. (See Note 2.)						○	○		
		Personal computer link data	OP link data		Data for setting host communication with personal computer and data for setting OP link communication. (See Note 2.)	○	○	○						
R0909	CBL set address		Group	Set address	CBL node address, group node address, etc. (See Note 3.)							○		

Note 1) Data for setting hardware switching

The following table describes the meaning of the bits in register R0903.

To change the setting of register R0903 in the ladder program, use the MOV (F-00) instruction. Note that data preset to the ladder program is enabled from the next scan whose setting was changed.

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Bit				
R0903																					
																	Applicable MX series device				
Bit	Description																200	100	50	30	20
15	0: The OP I/O terminal is used by the OP link function. 1: The OP I/O terminal is used by the ASCII function.																○		○		
14	Not used (always set to 0)																				
13	0: Places battery alarm in M931 when battery voltage is too low. 1: Does not place battery alarm in M931 when battery voltage is too low.																○		○		
12	0: Places alarm in M908 during detection of instantaneous alarm. 1: Does not place alarm in M908 during detection of instantaneous alarm.																○				
11 to 1	Not used (always set to 0)																				
0	0: PC link errors are stored in M972 latch. 1: PC link errors are periodically cleared.																○		○		

Note 2) Data for setting host communications


The following table describes the meaning of the bits in register R0908.

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Bit				
R0908																					
																	Applicable MX series device				
Bit	Description																200	100	50	30	20
15	Baud rate	0	19200 bps	0	9600 bps	1	4800 bps	1	2400 bps	○	○	○	○	○							
14		0		1		0		1		○	○	○	○	○							
13	Data format 0: 8 bit data, even parity, 1 stop bit 1: 8 bit data, no parity, 2 stop bits																○	○	○	○	○
12	0: Restart after instantaneous power failure 1: Processing continues after instantaneous power failure																○	○			
11	Host address (0 to 15) MX100: 0 to 15 MX30: fixed address 1 MX20: 1 to 9 (Specified in R0950 for MX200/MX50)																	○		○	○
10																					
9																					
8																					
7	Baud rate	0	19200 bps	0	9600 bps	1	4800 bps	1	2400 bps	○	○	○									
6		0		1		0		1		○	○	○									
5	Data format 0: 8 bit data, even parity, 1 stop bit 1: 8 bit data, no parity, 2 stop bits																○	○	○		
4	0: Set to OP link slave 1: Set to OP link master																○	○	○		
3	OP link station (0 to 15)																○	○	○		
2																					
1																					
0																					

Note 3) Address for setting CBL

Register R0909 is used only on the MX30.

The following table describes the meaning of the bits in register R0909.



Bit	Description
15	0: During polling reception when two or more write commands are received during one scan, all received data is directly written during the interrupt process. The simultaneity of data is lost, but all data is received. 1: During polling reception when two or more write commands are received during one scan, the second command onwards is ignored. The data of the second command is not received.
14	Procedure for setting address format of parameter setting area* 0: Decimal setting 1: BCD setting * Applicable to MX30 version S09 or higher.
13 to 11	Always set to 0
10	Polling communication of destination group 3 (FAH) 0: Not received 1: Received
9	Polling communication of destination group 2 (F9H) 0: Not received 1: Received
8	Polling communication of destination group 1 (F8H) 0: Not received 1: Received
7	Always set to 0
6	Always set to 0
5 to 0	CBL node station No. (2 to 63) The CBL function cannot be used when the station No. is 0. When the station No. is 1, host communications from MX30 station Nos. 2 to 63 cannot be accessed via CBL.

Handling Precautions

When the R0909 setting is changed using the loader, the new setting is enabled after a system reset (by shutting down and turning ON the power again).

Address	Register	Bit configuration								Description	Applicable MX series device				
		15	12	11	8	7	4	3	0		200	100	50	30	20
R0910	CBL: Parameter setting of read command	0 to 499 (register No. setting)								Defines the parameter setting area required for reception and transmission using the CBL read command.				○	
	OP link verification alarm	Verification failure address								This bit turns ON to indicate the address where registered OP link data and stored OP link data do not match.	○	○	○		
R0911	CBL: Parameter setting of write command	0 to 499 (register No. setting)								Defines the parameter setting area required for reception and transmission using the CBL write command.				○	
	Identifier indicating use/non-use of OP link	Used address								The bit corresponding to an address used for an OP link turns ON.	○	○	○		
R0912	CBL: Parameter setting of polling reception	0 to 499 (register No. setting)								Defines the parameters required for polling reception.				○	
	OP link verification data	0000	0000	Address 1						See R0913 to R0919.	○	○	○		
R0913	CBL: Parameter setting of polling transmission	0 to 499 (register No. setting)								Defines the parameters required for polling transmission.				○	
	OP link verification data	Address 2		Address 3						The number of registered I/O words for OP link addresses are stored as 4-bit hexadecimal. If not registered, stored data is used at reset.					
R0914	Address 4		Address 5												
R0915	Address 6		Address 7												
R0916	Address 8		Address 9						○		○	○	○		
R0917	Address 10		Address 11												
R0918	Address 12		Address 13												
R0919	Address 14		Address 15												

Address	Register	Bit configuration						Description	Applicable MX series device						
		15	12	11	8	7	4		3	0	200	100	50	30	20
R0920	Remote communication default/variable length switching	30H or other than 30H			0000 0000			When the value of the upper-order byte is 30H, the number of remote I/O words is changed to the value specified in R0921. When the value of the upper-order byte is other than 30H, the default (3 word input/3 word output).					○		
	Stored OP link data	0000 0000			Address 1			The number of registered I/O words of each address of the OP link is stored as 4-bit hexadecimal.	○	○	○				
R0921	Remote communication data length setting	No. of input words (00H to 0AH)			No. of output words (00H to 0AH)			When the upper-order byte is R0920 is 30H, upper-order byte in R0921 indicates the number of remote input words. The lower-order bytes in R0921 indicate remote output words. (When the entry exceeds 10 words, it is corrected to 10 words.)					○		
	Stored OP link data	Address 2			Address 3			The number of registered I/O words of each address of the OP link is stored as 4-bit hexadecimal.	○	○	○				
R0922	Stored OP link data	Address 4			Address 5										
R0923	Stored OP link data	Address 6			Address 7										
R0924	Stored OP link data	Address 8			Address 9										
R0925	Stored OP link data	Address 10			Address 11										
R0926	Stored OP link data	Address 12			Address 13										
R0927	Stored OP link data	Address 14			Address 15										
R0928	No. of CBL receptions	No. of CBL reception counter							The number of remote communication receptions from MX200 (binary)					○	
R0929	Blown fuse in I/O module	0000 0000			Slot No.				The bit corresponding to the I/O module where the fuse was blown turns ON.	○	○				

Address	Register	Bit configuration				Description	Applicable MX series device							
		15	12	11	8		7	4	3	0	200	100	50	30
R0930	I/O module verification error	0000	0000	Slot No.		The relevant bit turns ON when I/O module verification data and stored data differ.	○	○	○	○	○			
R0931	I/O bit/word identifier	0000	0000	0000	0000	Indicates that all I/Os are general-purpose I/Os (fixed data).	○		○					
		Stored data	Verification data			The bit of each slot indicates the type of module. 0: General-purpose I/O module 1: Special I/O module		○		○	○			
R0932	I/O verification error	Slot 1 data	Slot 2 data			Indicates I/O verification data of each slot.	○	○	○	○	○			
R0933		Slot 3 data	Slot 4 data											
R0934		Slot 5 data	Slot 6 data											
R0935		Slot 7 data	Slot 8 data											
R0936	Stored I/O data	Slot 1 data	Slot 2 data			Indicates stored I/O data of each slot.	○	○	○	○	○			
R0937		Slot 3 data	Slot 4 data											
R0938		Slot 5 data	Slot 6 data											
R0939		Slot 7 data	Slot 8 data											


The data of I/O modules installed in each slot is stored in the following format:

● Bit modules

Bit configuration								Description
15	14	13	12	11	10	9	8	
7	6	5	4	3	2	1	0	
0	0	0	0	0	0	0	0	Not defined
0	0	0	0	0	0	0	1	16-point input
0	0	0	0	0	0	1	0	32-point input
α (*)				0	0	1	1	32 point input + α (*)
0	0	0	0	0	1	0	1	16-point input/32-point output
0	0	0	0	0	1	0	1	16-point output
0	0	0	0	0	1	1	0	32-point output
α (*)				0	1	1	1	32-point output + α (*)
0	0	0	0	1	0	0	0	Not defined
0	0	0	0	1	0	0	1	8-point input
0	0	0	0	1	0	1	0	24-point input
0	0	0	0	1	0	1	1	Not defined
0	0	0	0	1	1	0	0	8-point input/18-point output
0	0	0	0	1	1	0	1	8-point output
0	0	0	0	1	1	1	0	24-point output
0	0	0	0	1	1	1	1	Not defined

(*) α : In addition to a: 32-point input (output), a device code is added.
 16I, 32I,
 16O, 32O,

● Word modules



Address	Register	Bit configuration						Description	Applicable MX series device					
		15	12	11	8	7	4		3	0	200	100	50	30
R0940	ASCII communication setting	Data defining ASCII communications						Sets communication mode, RTS control, communication speed, data format, etc.						
R0941	Monitoring time of ASCII communication response	Set data 0 to 9999 (specified in BCD)						Sets the time (in 10 ms increments) for monitoring response to ASCII communication. When set to 0, the response is not monitored. Example: when R0941=100H, the response time is monitored for 1s.						
R0942	Transmission data storage	0 to 499, 1000 to 4999 (register Nos. are specified in BCD)						Indicates where data transmitted in an ASCII communication comes from. Example: when R0942=2000H, data stored in R2000 onwards is transmitted.						
R0943	Transmission frame definition	Start code	End code					Sets the start and end code of data in an ASCII transmission.						
R0944	Procedure for creating transmission checksum data	Procedure for adding/not adding checksum data	Position of checksum data					Procedure for adding/not adding transmission checksum data and how to create checksum data. (Example:00 is 8 bit addition and 01 is 1's complement.) It also sets the position of checksum data.	○		○			
R0945	Range of transmission checksum calculation	Position for starting checksum calculation	Position for ending checksum calculation					Sets the start and end position of a transmission data checksum calculation.						
R0946	Reception data storage	0 to 499, 1000 to 4999 (register Nos. are specified in BCD)						Indicates where data received in an ASCII communication is stored. Example: when R0946=3000H, received data is stored in R3000 onwards.						
R0947	Reception frame definition	Start code	End code					Sets the start and end code of data in an ASCII reception.						
R0948	Procedure for creating reception checksum data	Procedure for adding/not adding checksum	Position of checksum data					Procedure for adding/not adding reception checksum data and how to create checksum data. (Example:00 is 8 bit addition and 01 is 1's complement.) It also sets the position of checksum data.						
R0949	Range of reception checksum calculation	Position of checksum start data	Position of checksum end data					Sets the start and end position of a reception data checksum calculation.						

Note) Data for setting host communication

The following table describes the meaning of the bits in register R0940.

To change the setting of register R0903 in the ladder program, use the MOV (F-00) instruction. Note that data preset to the ladder program is enabled from the next scan whose setting was changed.

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Bit
R0940			0				0	0								0	

Bit	Description																
15	0: ASCII communication function								1: Loader, host communication function								
14	0: General-purpose mode								1: Dedicated mode								
13	Not used: Always set to 0																
12	0: RS-232C								1: RS-485								
11	0: 5-wire RS-485 (full duplex)								1: 3-wire RS-485 (half duplex)								
10	0: No control								1: RTS control								
9	Not used: Always set to 0																
8																	
7	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	
6	0 19200		0 9600		1 4800		1 2400		0 1200		0 600		1 Not		1 Not		
5	0 bps		1 bps		0 bps		1 bps		0 bps		1 bps		0 used		1 used		
4	0: 7 bits								1: 8 bits								
3	0 No parity				0 No parity				1 Even parity				1 Odd parity				
2	0				1				0				1				
1	0: 1 stop bit								1: 2 stop bit								
0	Not used: Always set to 0																

(Note)

Half duplex: When data transmission is completed, the output driver is disabled within 500 μ s.

RST control: When the reception buffer contains 768 or more data items, the RTS signal is automatically set to a non-active state.

Address	Register	Bit configuration		Description	Applicable MX series device				
		15 12 11 8 7 4 3 0			200	100	50	30	20
R0950	MX address	1 to 63, 7FH		MX address for CBL and host communication. When the MX address is set to 7H, the MX is set not to participate in the CBL network.					
R0951	Group class of polling communication reception	0 to 7		No reception when set to 0 (default: 0)					
R0952	Single/dual mode setting	0 to 1		0: Single mode 1: Dual mode (default)					
R0953	Group address for destination of PC link transmission	0 to 3		No transmission when set to 0 (default: 0)					
R0954	Group class for PC link reception	0 to 7		No reception when set to 0 (default: 0)	○		○		
R0955	PC link monitoring time	0 to 1		0: 500 ms (default) 1: 1s					
R0956	No. of connected remote slave stations	0 to 31		0: Default					
R0957	—	—		Not used (always set to 0)					
R0958	ROM version	Main CPU ROM version	Sub-CPU ROM version	Indicates the ROM versions for the main and sub-CPU in a 2-digit decimal format.					
R0959	MX operation address	1 to 63, 7FH		Copy of R0950					

Note) The following table describes the meaning of the bits in register R0950.

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Bit
R0950	0	0	0	0	0	0	0	0	0	0							

Bit	Description
15 to 6	Not used: Always set to 0
5	Address 1 to 63
4	
3	
2	
1	
0	

The following table describes the meaning of the bits in register R0951.

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Bit
R0951	0	0	0	0	0	0	0	0	0	0	0	0	0				

Bit	Description
15 to 3	Not used: Always set to 0
2	Polling communication of destination group 3 (FAH) 0: Not received 1: Received
1	Polling communication of destination group 2 (F9H) 0: Not received 1: Received
0	Polling communication of destination group 1 (F8H) 0: Not received 1: Received

The following table describes the meaning of the bits in register R0954.

	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Bit
R0954	0	0	0	0	0	0	0	0	0	0	0	0	0				


Bit	Description
15 to 3	Not used: Always set to 0
2	PC link group 3 0: Not received 1: Received
1	PC link group 2 0: Not received 1: Received
0	PC link group 1 0: Not received 1: Received

Address	Register	Bit configuration						Description	Applicable MX series device				
		15	12	11	8	7	4		3	0	200	100	50
R0960	Library Internal flag M906: Save data 1	Entry Nos. 15 to 0 correspond to bits 15 to 0.						Special contact used in the library. Save data of each M906 library	○				
R0961	Library Internal flag M906: Save data 2	Entry Nos. 31 to 16 correspond to bits 15 to 0.											
R0962	Library Internal flag M907: Save data 1	Entry Nos. 15 to 0 correspond to bits 15 to 0.						Special contact used in the library. Save data of each M907 library					
R0963	Library Internal flag M907: Save data 2	Entry Nos. 31 to 16 correspond to bits 15 to 0.											
R0964	Library Entry data 1	Entry Nos. 15 to 0 correspond to bits 15 to 0.						Indicates numbers of executable libraries.					
R0965	Library Entry data 2	Entry Nos. 31 to 16 correspond to bits 15 to 0.											
R0966	—	—						Not used (always set to 0)					
R0967													
R0968	Incremented every 10 ms, BCD data	0000 to 9999						This register is incremented every 10 ms by adding a BCD value (substitute function of library timer).					
R0969	Incremented every 10 ms, BIN data	0 to 65535						This register is incremented every 10 ms by adding a BIN value (substitute function of library timer).					

The following table describes the meaning of the bits in registers R0980 to R0987.

15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	Bit
0	0	0	0					0	0	0	0	0	0			

Bit	Description
15 to 12	Not used: Always set to 0
11	Indicates state of EPROM/EEPROM (192 to 256 Kbytes)
10	Indicates state of EPROM/EEPROM (128 to 192 Kbytes)
9	Indicates state of EPROM/EEPROM (64 to 128 Kbytes)
8	Indicates state of EPROM/EEPROM (0 to 64 Kbytes)
7 to 2	Not used: Always set to 0
1	Indicates state of expanded RAM
0	Indicates state of standard RAM



Address	Register	Bit configuration								Description	Applicable MX series device				
		15	12	11	8	7	4	3	0		200	100	50	30	20
R0990	—	—								Not used (always set to 0)					
R0991	Basic display setting									Sets the data normally displayed on the processor module 0: User mode 1: MX address 2: Error/Alarm					
R0992	User display code 1 (7-segment LED)	0 to F	0 to F	0 to F	0 to F					Data displayed in the user mode by the 7-segment LED on the processor module					
R0993	User display code 2 (8-bit data LED)				00 to FF					Data displayed in the user mode by the 8-bit data LED on the processor module	○				
R0994	Clock register	Year								Indicates the year Example: 1993 is displayed as 1993[H]					
R0995		Month			Day					Upper-order byte: Month, Lower-order byte: Day Example: November 5 is displayed as 1105[H]					
R0996		Hour			Minute					Upper-order byte: Hour, Lower-order byte: Minute Example: PM3:28 is displayed as 1528[H]			○		
R0997		Second			Day of the week					Upper-order byte: Seconds, Lower-order byte: Days of the week Days of the week: Sunday, Monday, Tuesday, Wednesday, Thursday, Friday, Saturday → 0 1 2 3 4 5 6					
R0998	—	—								Not used (always set to 0)					
R0999	—	—								Not used (always set to 0)					

2 - 4 I/O Registration

■ General-purpose I/O modules

The MX series processor module automatically reads the data (stored data) in I/O modules in the I/O slots when the power is turned ON or when the RESET switch is pressed. Assignment is based on how close an I/O module is to the processor module. Inputs start from X000 and outputs from Y000. Assignments are automatically left justified if there are any unoccupied slots.

Processor module	32 input points X000 X01F	16 output points Y000 Y00F	Unoccupied	16 input points X020 X02F	32 output points Y010 Y02F	
------------------	-------------------------------------	--------------------------------------	------------	-------------------------------------	--------------------------------------	--

I/Os exceeding 512 points (a maximum of 320 input points and 320 output points) are ignored. When I/Os are registered by the loader, their data is registered as verification data, and a difference between stored data and the verification data is indicated as an error. If not registered, the stored data is taken as verification data, each time the power is turned ON.

Refer to the MX Series User's Manual "Personal Computer Loader" CP-UM-1602E for details.


■ Operator's I/O

The I/O for the OP link are registered by setting the number of words required by the number of I/O points with the loader. Inputs are assigned from X200, while outputs are assigned from Y200. Note that inputs/outputs exceeding 160 points are ignored.

An alarm is displayed in the following cases:

- No OP I/O response at startup.
- Stored OP I/O data differs from registered data
- No OP I/O response during operation

Unless the OP I/Os are assigned with the loader they will not function even if they are connected.



! Handling Precautions

The processor module does not automatically read the OP I/O data when the OP link I/O is not registered.

■ Special I/O modules

MX special function modules are assigned to I/O registers in word units (16 bits.) Inputs are assigned to R0500 to R0519 and outputs are assigned to R0600 to R0619 starting from those closest to the processor module.

Assignment starts automatically when the power is turned ON or when the RESET switch is pressed. Special function modules may be mounted in any I/O slot.

After assignment, a missing I/O module is detected by comparing the I/O module data with registered I/O module data (if I/O assignments are registered in the personal computer loader) or with the data stored in the processor when the power was turned ON or when the RESET switch was pressed.

Processor module		Special function Input 4 words Output 2 words		Special function Input 2 words Output 4 words		
		Input R0500 to R0503	Output R0600 to R0601	Input R0504 to R0505	Output R0602 to R0605	


See the user manual supplied with the special module for details.
Special I/O modules refers to analog I/O modules and special function modules.

■ MX200/MX100/MX50

When MX200/MX100/MX50 devices are connected to an OP link (RS-485) to form a data link between host and slave stations, I/O registration is required just as in the case of operator's I/O connections.

Note that 32 inputs and 32 outputs (fixed values) can be assigned to an MX200/MX100/MX50 device used as a slave station.


Example



■ Environment comprising operator's I/O and MX200/MX100/MX50 controllers

When operator's I/O and MX200/MX100/MX50 slave stations are connected to an OP link (RS-232C), they are assigned as normal operator's I/O. (In this environment, MX200/MX100/MX50 each has 32 input and 32 output points.)


Example



2 - 5 OP Links

The following factors have to be kept in mind when data transactions are performed between MX100/MX200/MX50 host and slave stations connected to an OP link (RS-485).

1. The data link area in the MX100/MX200/MX50 host stations is the OP link area (X200 onwards , Y200 onwards).
2. The data link area for MX100/MX200/MX50 slave stations is fixed at X200 to X21F and Y200 to Y21F.
3. Host stations receive the values of slave station output relays (Y200 to Y21F) through the local station input relay (X200 onwards) and outputs the value of the local station output (Y200 onwards) to the slave station input relay (X200 to X21F).
4. The host (master) station, slave station and slave station numbers of an MX200 are set on a personal computer loader or processor module key operation. On the MX50 controller, the personal computer loader is used, and on the MX100 controller the DIP switches on the processor module are used to do the same. These are also the only procedure available.
5. Modules connected to an OP link must be I/O registered.




When Y200 on an MX100/MX200/MX50 controller used as slave station No.1 turns ON, the MX200 on host station MX200 also turns ON. Alternatively, when the Y200 on the host station turns ON, the X200 on slave station No.2 also turns ON.

Chapter 3 PROGRAMMING NOTES

3 - 1 Ladder Design Notes

■ Program execution sequence

The sequence of program execution is shown by the mnemonics listed below.




Program shortcuts

The position of the instruction will change the number of bytes needed when other factors in the ladder program are identical. The number of bytes can be reduced by placing contact instructions to the left and reducing the number of contacts as the column descends.


(Example 1)

(Ladder)



(Mnemonic)


		No. of bytes
LD	1	2
LD	2	2
OR	3	2
ANB		2
OUT	4	2
		Total 10



LD	2	2
OR	3	2
AND	1	2
OUT	4	2
		Total 8


(Example 2)

(Ladder)



(Mnemonic)

		No. of bytes
LD	1	2
LD	2	2
AND	3	2
ORB		2
OUT	4	2
		Total 10




LD	2	2
AND	3	2
OR	1	2
OUT	4	2
		Total 8


(Example 1)

(Ladder)

(Mnemonic)



		No. of bytes
LD	1	2
LD	2	2
AND	3	2
LD	4	2
LD	5	2
OR	6	2
ANB		2
ORB		2
ANB		2
OUT	7	2
		<hr/>
		Total 20



LD	3	2
AND	2	2
LD	5	2
OR	6	2
AND	4	2
ORB		2
AND		2
OUT	7	2
		<hr/>
		Total 16


■ Creating programs for serial and parallel circuits

Programs for serial circuits are created by dividing the circuit into blocks which are placed on top of each other.

(Example 1)

(Ladder)


(Mnemonic)



```

LD 1 [ ] ----- A
OR 2 [ ] ----- B
AND 3 [ ] ----- C
ORB 4 [ ] ----- D
OUT 7 ( )
    
```

(Example 2)




```

LD 1 [ ] ----- A
AND 2 [ ] ----- B
LD 3 [ ] ----- C
AND 4 [ ] ----- D
ORB 5 [ ] ----- E
AND 6 [ ] ----- F
ORB 7 [ ] ----- G
LD 8 [ ] ----- H
AND 9 [ ] ----- I
LD 10 [ ] ----- J
OR 11 [ ] ----- K
ANB 12 [ ] ----- L
OUT 13 ( )
    
```

- Repeated entries of ANB or ORB can be made after repeated creation of blocks including LD or LDNOT. However, as only 8 blocks can be stored temporarily, it is not possible to create nine or more blocks at one time. If more blocks are required, use ANB (or ORB) after creating the first blocks, then add more blocks.

(Example)



More than 9 blocks
so not executable

LD	1	LD	1
AND	2	AND	2
LD	3	LD	3
AND	4	AND	4
LD	5	ORB	
AND	6	LD	5
LD	7	AND	6
AND	8	ORB	
LD	9	LD	7
AND	10	AND	8
LD	11	ORB	
AND	12	LD	9
LD	13	AND	10
AND	14	ORB	
LD	15	LD	11
AND	16	AND	12
LD	17	ORB	
AND	18	LD	13
ORB		AND	14
ORB		ORB	
ORB		LD	15
ORB		AND	16
ORB		ORB	
ORB		LD	17
ORB		AND	18
ORB		ORB	
OUT	0	OUT	0




Program as indicated above.

■ Ladder display constraints

The following describes constraints that apply to writing ladder programs. They do not apply to the entry of mnemonics, so they are entry constraints and not execution constraints.

● Maximum range of circuit blocks

The maximum number of entries for a circuit block (section connected by the right and left buses) is 10 columns (nine contacts plus a coil) times 22 lines.




! Handling Precautions

- A program written in mnemonics that exceed this constraint cannot be displayed as a ladder, but can be executed.
- A total of 10 LPSs (branch start) can be used in one circuit block.

● Line loopback

Up to 169 contacts can be connected in series in a ladder display.



! Handling Precautions


- A program written in mnemonics that exceed this constraint cannot be displayed as a ladder, but can be executed.
- Branch lines cannot be looped back using LPS (branch start), LRD and LPP.

■ Precautions to be taken in creating circuits

● Writing from relay panel circuit

The current in a relay circuit panel flows in both directions. Such circuits are configured as follows. However, as such a circuit cannot be handled by the MX series of controllers it must be adapted as shown.


(Example)



This kind of circuit is not possible on the MX series.



Redraw the circuit as shown below.




Take care to prevent ladder circuits from interfering with each other.

● Branch back circuit not permitted

Do not write branch back circuits like the one shown below.


(Example)




This kind of circuit is not possible on the MX series.



Redraw the circuit as shown below.




Do not write branch backs into ladder programs.



This kind of circuit is not possible on the MX series.



Redraw the circuit as shown below.




Enter by a branch from the bus.

● Notes on the use of the compare instruction


Do not write branch back circuits like the one shown below.

Enter the compare instruction in parallel circuits under the ladder block.

(Example)




Redraw the circuit as shown below.




Enter the compare instruction in parallel circuits under the ladder block.

● Notes on the use of branches in parallel circuits

Do not write branch back circuits like the one shown below.




(Example 1)



Add a normally ON contact (M920) at the start of the ladder row.




(Example 2)



Divide the ladder circuit into two rows.

● Duplicated output

When an OUT instruction with the same number is used twice, the loader displays a syntax alarm. The Y001 state is output when the END instruction is executed. The last written operation has priority.




● Instructions which require care during changing of modes (STOP → RUN)

The pulse rise instruction is executed when the input condition during the change from STOP to RUN takes place. The instruction is not executed when the input condition is OFF.


Instruction \ Condition	Input ON	Input OFF
CNT	Executed	Not executed
STB (F-08)		
PLS↑ (F-20)		
UDC (F-26)		
DCNT (F-27)		
DUDC (F-28)		
SR (F-60)		
Optional pulse instruction		

● Notes on the use of branch instructions


- Insert the JMP instruction after the branch instruction.




- When several outputs follow a JMP instruction, the JMP instruction is executed, but not the following JMP instruction.



- When several outputs follow a CALL instruction, the execution of the instruction following the CALL instruction is not guaranteed.



- When several outputs follow a LIB instruction, the execution of the instruction following the LIB instruction is not guaranteed.



3 - 2 Using Function Instructions

Range of numeric values

The MX series of controllers use instructions that handle both 16-bit and 32-bit numerics. The most significant bit (MSB) of 16-bit or 32-bit BIN data is used for the plus and minus sign bit (1: minus, 0: plus). Hexadecimal constants and BCD constants are all positive and have no sign bit. BIN data is expressed as decimal constants.

The range of numeric data is shown in the table below.


	Symbol	16-bit data	32-bit data
Decimal constants (stored as BIN values)	K	-32768 to +32767	-2147483648 to +2147483647
Hexadecimal constants	#	0000 to FFFF	00000000 to FFFFFFFF
BCD constants	#	0000 to 9999	00000000 to 99999999

Handling Decimal Constants as Binary Data

Since the MSB of word data is a plus or minus identification bit, the decimal constant K is handled as follows:




(Example)



■ Source and destination

- Source (S)
This is the storage source of operation data. There are four types of sources: 4-bit, 8-bit, 16-bit and 32-bit data. Each source is specified by an instruction word.
- Destination (D)
This is the storage destination of operation data. There are five types of destinations: 4-bit, 8-bit, 16-bit, 32-bit and 64-bit data. Each destination is specified by an instruction word.
- Bit device (Z)
This is the storage destination for operation inputs or output bit data.
- Constants (n)
This is the storage destination for operation constants (set values and numbers.)

MX instruction words store device data in the four data storage destinations.



The same device number can be used for both a source (S) and a destination (D).

■ Instruction types

MX instructions consist of an instruction part and a device.

The instruction part indicates the function of the instruction, and the device indicates the data that is used by the instruction. The combination of instruction parts and devices makes it possible to distinguish instructions as shown below.

(See page 3-13 for information on abbreviations such as S, D, Z or n.)

- | | | | | | | | | | |
|-----|-------------------------|--------|-------|--|---|-------|---|-------|---|
| [1] | Instruction part | (only) | ----- | <p>This is a type of instruction whose device does not change status.
It is mainly used for program control.
(Example) END and AND</p> | | | | | |
| [2] | Instruction part | + | n | ----- | <p>This type of instruction performs operation specified by constant (n) data.
(Example) MC and CALL</p> | | | | |
| [3] | Instruction part | + | Z | ----- | <p>This type of instruction is used for turning bit devices ON and OFF.
(Example) AND, OUT and PLS ↑</p> | | | | |
| [4] | Instruction part | + | D | ----- | <p>This type of instruction performs operations on destination (D) data and stores the result in destination (D).
(Example) BCDI, RST</p> | | | | |
| [5] | Instruction part | + | D | + | n | ----- | <p>This type of instruction performs operations on constants (n) and stores the result in bit device (Z).
(Example) TMR and CNT and other timer and count instructions</p> | | |
| [6] | Instruction part | + | S | + | D | ----- | <p>This type of instruction performs operations on source (S) data and stores the result in destination (D).
(Example) MOV → BCD and other transfer and conversion instructions</p> | | |
| [7] | Instruction part | + | S1 | + | S2 | + | D | ----- | <p>This type of instruction performs operations on source 1 (S1) and Source 2 (S2) data and stores the result in destination (D).
(Example) Compare, BCD + and other compare and operation instructions</p> |
| [8] | Other instruction types | | | | | | | | |
| | Instruction part | + | S | + | D1 | + | D2 | ----- | <p>(Example) DMPX and other distribution and extraction instructions</p> |
| | Instruction part | + | n | + | D1 | + | D2 | ----- | <p>(Example) SFL and other shift instructions</p> |
- etc.

■ Specifying pulse

Function instructions are used for specifying pulses.


When the execution condition is in the input ON mode, some instructions are used to specify a “rise” (referred to as “pulse setting”) for the execution status. Pulses are specified by inserting ↑ in the instruction sheet.

See User’s Manual “Programming Instruction Words” CP-UM-1563E for information.

(2) Specifying register area (R)


① Enter the relevant device number to specify 16 bits.

(Example)



② Enter the lower-order 16-bit device number to specify 32 bits.

(Example)



(Note) The least significant bit may be even or odd.

! Handling Precautions


Data in the register area is generally handled in 16-bit units. However, as an exception, when a register area is specified in S or D, 4-bit data transfers (M4BT) or 8-bit data transfers (M8BT) may be handled as lower-order 4-bits or lower-order 8-bits.

■ Indirect addressing

Some instructions allow the use of the BCD value in register R as an indirect address in an MX application instruction instead of addressing register R itself. This can be achieved by prefixing register R with the “@” symbol in addressing with the loader.


(Example) MOV (data transfer) instruction

When S: X000, D: @R0000, the X000 to X00F 16-bit data item is not moved to register R0000. Instead, if the R0000 value is a BCD value “0015”, it is moved to register R0015.



(Example) BCD + (BCD addition) instruction

When S1 @R0000, S2 #1234, D: @R0020, the R0000 value and #1234 are not added directly. If the R0000 value is BCD value “0030” and the value in R0020 is “0040”, the R0030 value and #1234 are added and the result is stored in R0040.



! Handling Precautions

- As shown in the above examples, indirect addressing can be used for several (2 or 3) registers of the same instruction.
- When the value in register R prefixed with “@” to indicate indirect accessing does not contain a BCD value or when the range of register R is exceeded, an operational error flag (M90E or M90F) is set.
See the User’s Manual “Programming Instruction Words” CP-UM-1563E for information on which instruction words allow indirect addressing.

■ Flags

The MX series of controllers have the following five type of flags:

1. Shift carry flag (M900)
2. Overflow flag (M901)
3. Underflow flag (M902)
4. Character string compare flag (M903) (MX200 only)
5. Operational error flag (M90E, M90F)

● Flag handling

● Flag operation

Once a flag is set, it stays ON until an instruction that affects its operation is executed. However, the operational error latch type (M90F) stays ON when set to ON.

● Flag holding

As stated earlier, flags are turned ON or OFF during scanning. So, in order to monitor the state using a loader, apply self-holder or breakpoints after the instruction that affects the flag. (See Chapter 4, "Debugging" for information on breakpoints.)

● The shift carry flag


The shift carry flag (M900) is used in the following cases.

Instruction words:

- SR (shift in both directions)
- SFL (left shift)
- SFR (right shift)
- RLC (leftward rotation including carry)
- RRC (rightward rotation including carry)
- RL (leftward rotation)
- RR (rightward rotation)


(Example) SFL

As shown below, when one bit is shifted leftwards, "1" is stored in the carry (M900).



(Example) RLC

As shown below, when four bits are rotated leftwards, "0" is stored in the carry (M900).




● **Overflow and underflow**


An overflow flag (M901) or an underflow flag (M902) is set in the following cases:

	Instruction Words	When flag is set
Overflow flag	BIN addition/subtraction	When result exceeds #FFFF (see note)
	Double-length BIN addition/subtraction	When result exceeds #FFFFFFF
	BIN increment	When result exceeds #FFFF
	BCD addition	When result exceeds 9999
	Double-length BCD addition	When result exceeds 99999999
	BCD increment	When result exceeds 9999
Underflow flag	BIN addition/subtraction	When result is lower than #0000
	Double-length BIN addition/subtraction	When result is lower than #00000000
	BIN decrement	When result is lower than #0000
	BCD subtraction	When result is negative
	Double-length BCD subtraction	When result is negative
	BCD decrement	When result is negative


! **Handling Precautions**

As shown below, an overflow occurs when there are too many digits. BIN values has a minus sign bit, so the numeric range (32767) it can handle is not an overflow.





The same is true for underflow conditions.



See the User's Manual "Programming Instruction Words" CP-UM-1563E for information on character string compare result flags.

● Operational error flags

The table below shows examples when error flags (M90E: unlatched flags and M90F: latched flags) are set.

	Operational error	Example
1	No BCD data can be found.	<ul style="list-style-type: none"> The operand of a BCD operation is not a BCD value. The offset data of a data distribution instruction or extraction instruction is not a BCD value. The write data of a timer/counter set value write or current value write instruction is not a BCD value. The table specified value of a data table read instruction is not a BCD value. The conversion object of a double-length BCD to BIN conversion is not a BCD value.
2	A digit-over condition results when data is converted to BCD values.	<ul style="list-style-type: none"> The result of a BIN to BCD conversion instruction exceeds 9999. The result of a double-length BIN to BCD conversion instruction exceeds 99999999.
3	Division by 0 executed.	<ul style="list-style-type: none"> BIN division or double-length BIN division by 0 is executed. BCD division or double-length BCD division by 0 is executed.
4	The offset of the distribution destination, extraction source or storage destination data is too great.	<ul style="list-style-type: none"> The address of distribution destination D1 + (D2) of data instruction exceeds the area to which D1 belongs. The address of extraction source S1 + (S2) of data instruction exceeds the area to which S1 belongs. The data table read instruction was specified for an area where there was no table. The storage destination D + (S2) of data table read instruction exceeds the area to which D belongs, and S2 is not a constant (#).
5	Although 1 is to be raised, there is no such rise.	<ul style="list-style-type: none"> A 16 to 4 encode instruction is used on an operand that is all 0's.
6	A value other than a BCD value or a value outside the address range is stored in the register when an indirect instruction is specified.	<ul style="list-style-type: none"> #FFFF is transferred to the register by MOV.
7	A value other than a character string was specified in the process of a character string processing instruction	<ul style="list-style-type: none"> The specified data string exceeds 256. The result of the character string process exceeds 256.

! Handling Precautions

- When several operational errors occur, check the special registers (R0904 to R0907) to locate the step where the error occurred.
- Latch type (M90F) operational errors are reset with a table change or forced set/reset from the loader.

● Syntax errors

The conditions listed in the table below cause a syntax error. This causes a syntax error (M99A) to be set. A syntax error message is also displayed on the loader. Such an error is detected during the program check performed at powering up or during the loader program check.

Code	Error	Cause of Error
02	Parameter error	Incorrect parameter value (device No., constant #, constant K)
03	Device area exceeded	The device No. value exceeds the defined area. (Example) X000 to X09F → X100 X200 to X29F → X11F (Correct) (Wrong)
04	Illegal constant #	① The value of constant # exceeds the specified number of digits. ② A decimal point (timer values are excluded) has been set. ③ Numeric values A to F, a to f are used.
05	Illegal constant K	① Symbols other than "-", "+", and "0 to 9" are used in a K value. ② The value of a double-length instruction $-2747483648 \leq \text{value} \leq 2147483647$. ③ The value of K (other than double-length instruction) $-32768 \leq \text{value} \leq 32767$.
06	Same area error	The parameter value is not the same area. ① The D1 and D2 values of DCPY (FUN07), SR (FUN60), SFL (FUN61), SFR (FUN62), RCL (FUN63), RRC (FUN64), RL (FUN65) and RR (FUN66) are in the same area, and D1 must be equal to or less than D2. ● General-purpose Y output (Y00 to Y090) and OP I/O output (Y200 to Y290) are in different areas. Register R (R0000 to R0499) and output register (R0600 to R0619) are also in different areas. ② S1 and S2 of BMOV (01) are in the same area, and S1 must be equal to or less than S2. ● General-purpose X output (X00 to X090) and OP I/O input (X200 to X290) are in different areas. General-purpose Y input and OP I/O input are in different areas, too. ● Register R (R0000 to R0499) and input register (R0600 to R0619) are in different areas. ● Only register (R0000 to R0499) can use indirect addressing which is assumed to be in the same area as register (R0000 to R0499). When indirect addressing is used for S1 and S2, an $S1 \leq S2$ check is not performed.
07	Parameter area exceeded	Parameter values (device No., constant #, constant K) exceed the set area. ① BMOV (FUN01) is exceeded The number of D words exceed the $S2 - S1 + 1$ word value of device set in D. (Example) BMOV S1: X000 9 - 0 + 1 = 10 words (FUN01) S2: X090 D: R498498 + 9 > 499 (error) ② Words $(n + 1)/2 + 1$ (all decimals are rounded off) were added to a device specified in STB (FUN08) area over S and the area was exceeded. (Example) STB n: #11 → $(11 - 1)/2 = 6$ words (FUN08) S: X080 D: Y000 → $8 + 5 = 13 > 9$ (error)
12	Multiple defective outputs	Several output instructions (OUT, MOV, CALL, etc.) were issued after a CALL and LIB instruction. (This occurs because the line logic after a CALL instruction is the value of the corresponding RET value. The line logic after execution of a LIB instruction becomes undefined depending on the content of the library.)
20	Undefined instruction	An undefined instruction was found in the program.

Code	Error	Cause of Error
21	Circuit error	<p>The following errors occurred on the circuit block.</p> <ul style="list-style-type: none"> ① The total of ANB, ORB plus 1 does not match the total of LD, LDNOT, LD compare and DLD compare. ② The total of LD, LDNOT, LD compare and DLD compare exceeds 8. <ul style="list-style-type: none"> ● In internal processing of LD, LDNOT, LD compare and DLD compare, the internal count is +1; with ANB and ORB the internal count is -1. When the internal count is more than 9 or less than 0, an error has occurred. ③ There is an ORB or ANB instruction following an output instruction. (Note) Output instructions: OUT, TMR, CNT, INV (FUN22), LPS (FUN34), LRD (FUN35) and LPP (FUN36) ④ There is an output instruction immediately after JPE (FUN33), RBP (FUN41), SBR (FUN43) and RET (FUN44). However, an output instruction is allowed immediately after MCR (FUN31), JPE (FUN33), RBP (FUN41), BSR (FUN43), RET (FUN44) and END (FUN40) ⑤ There is no LD instruction at all in front of an output instruction. However, this is possible with MCR (FUN31), JPE (FUN33), RBP (FUN41), BSR (FUN43), RET (FUN44) and END (FUN40).
22	CALL, SBR, RET error	<ul style="list-style-type: none"> ① There is no SBR (FUN43) having the No. called by CALL (FUN42). ② There is no RET (FUN44) having the same No. as an SBR (FUN43). ③ There are CALL (FUN42) instructions having the same Nos. as SBR (FUN43) and RET (FUN44). ④ There is no RBP (FUN41) or RET (FUN44) immediately before SBR (FUN43).
23	MC, MCR error	<ul style="list-style-type: none"> ① There is no MC (FUN30) No. corresponding to MCR (FUN31). ② There is no MCR (FUN31) having a No. of #n or less between MC (FUN30) #n and END (FUN40).
24	JMP, JPE error	There is no JPE (FUN33) with the same No. as JMP (FUN32).
25	Multi-input instruction error	<ul style="list-style-type: none"> ① The total number of LD, LDNOT, LD compare and DLD compare output instructions preceding a multi-input instruction (see note 1) does not match the total number of ANB and ORB instructions. This condition is the cause of the error. <ul style="list-style-type: none"> 2 inputs: The total number of LD, LDNOT and other instructions must equal 2 + (the total number of ANB and ORB instructions). 3 inputs: The total number of LD, LDNOT and other instructions must equal 3 + (the total number of ANB and ORB instructions). 4 inputs: The total number of LD, LDNOT and other instructions must equal 4 + (the total number of ANB and ORB instructions). (Note 1) Multi-input instructions are instructions that are used for entering inputs other than execution conditions such as counter and shift. <ul style="list-style-type: none"> 2 inputs: CNT, STM (FUN25) 3 inputs: UDC (FUN26), DUDC (FUN28) 4 inputs: SR (FUN40) ② There is an output instruction following the multi-input instruction.
26	STOP instruction error	There is no LD or LDNOT input immediately before the STOP (FUN94) instruction.
27	LPS, LRD, LPP error	<ul style="list-style-type: none"> ① LPS (FUN34) count is not equal to LPP (FUN36) count in a block. ② There is no output instruction before an LRD (FUN35) or LPP (FUN36). ③ The LPS (FUN34) count in a block exceeds 32.
30	Timer and counter using the same number	<p>The same No. is used by the timer and counter instructions.</p> <p>Timer instruction: TMR, STM (FUN25) Counter instruction: CNT and UDC (FUN26), DCNT (FUN27), DUDC (FUN28)</p> <p>(Note 2) DCNT (FUN27) and DUDC (FUN28) occupy specified devices and specified devices plus 1.</p>
31	JPE duplicated	There are two or more JPEs (FUN33) having the same No.
32	SBR duplicated	There are two or more SBRs (FUN43) having the same No.

Code	Error	Cause of Error
33	Pulse specification exceeded	More than 2000 pulse instructions are used. Pulse instructions <ul style="list-style-type: none"> ● PLS[↑] (FUN20) ● STB (FUN08) ● PLS[↓] (FUN21) ● SR (FUN60) ● Function instructions using pulse options
34	DTBL instruction (MX100, MX30)	The instruction immediately preceding the DTBL instruction (FUN98) is not an END instruction (FUN40). (An error is also caused if it is preceded by a NOT instruction.) The set value n (number of data items) does not meet the following requirement: $2n \leq (\text{total byte count}) - (\text{used byte count including this instruction} + 2)$
35	RTBL instruction error	<ul style="list-style-type: none"> ① Although the RTBL instruction (FUN99) is used, the DTBL instruction (FUN98) has not been written. ② The DTBL instruction caused an error. ③ When the S1 constant is used, the set count in the DTBL instruction (FUN98) does not meet the following requirement: $n \geq S1 + 1$ ④ When the S1 and S2 constants are used, the set count in the DTBL instruction (FUN98) does not meet the following requirement: $n \geq S1 + S2$

Handling Precautions

- Multi-input instructions are instructions such as counter and shift that are used for entering inputs other than execution conditions.
2 inputs: CNT, STM (FUN25)
3 inputs: UDC (FUN26), DUDC (FUN28)
4 inputs: SR (FUN40)
- When two or more operational errors occur, special registers (R0904 → R0907) store data identifying which step the error occurred.
- When a latch type (M90F) is reset to clear an operational error by changing operation modes (→ STOP → RUN) or loader operation (table operation or forced set/reset).

The following conditions do not produce an error but an alarm. When they occur, the program cannot be transferred to an MX controller or to disk.

Code	Error	Cause of Error
40	Duplicated coil used	Y, M and L having the same number are used in the output instruction (OUT), PLS[↑] (FUN20), PLF[↓] (FUN21), SET (FUN23) and RST (FUN24)
41	No JMP to JPE	There is no JMP (FUN32) having the same number as in JPE (FUN33).
42	No CALL to SBR (MX100, MX30)	There is no CALL instruction (FUN42) having the same number as in SBR (FUN43).
43	No END instruction (MX100, MX30)	There is no END instruction (FUN40) in the program.

Chapter 4 DEBUGGING FUNCTION

4 - 1 Outline

Programs often do not run as intended when they have been written. This is often caused by an incorrect understanding or the setting of instruction words, errors in programming sequence and other errors that are referred to as "bugs". "Debugging" is the process of removing these bugs to enable the program to run smoothly.

The MX series of controllers are provided with the following functions to allow efficient debugging:

- Functions for observing internal data
 - Functions for observing internal data
 - Functions for manipulating the program execution process
 - Functions for directly changing internal data from outside
- **Functions for observing internal data**
 - Hot-line monitor
 - Multi-point monitor

These functions are ideal for monitoring ON and OFF conditions of "contacts", "coils" and other relay image devices. These monitors allow you to execute the program from the first step to the END instruction as the internal data is read out, and to check the result of execution.
 - Time chart display

This is a chart displaying time series changes of bit data.
- **Functions for directly changing internal data from outside**
 - Data changes
 - Forced setting/forced resetting

These functions allow you to change the data in the user program from outside without having to operate the program itself which greatly facilitates the debugging process.
- **Functions for manipulating the program execution**
 - Breakpoints
 - Step execution

You must be able to monitor the result produced after the execution of an instruction in programs that repeatedly operate on data in several data registers to be able to judge whether the program is operating normally. To make this possible, the program is executed in separate steps which allow you to monitor the result produced by execution.

4 - 2 Forced Setting, Resetting and Data Changing

■ Forced setting, resetting and data changing

The MX series of controllers are provided with the following two ways of changing a device table. Both operations are performed on the loader.


- Forced setting and resetting
- Data change

● Forced setting and resetting

The states of the device table can be forcibly set or reset before the user program is executed. For example, if a forced Y001 setting is made, the program is set to ON before the execution of the next scan program even if the user program is OFF.

● Data changes

Like forced setting and resetting, the states of the device table can be forcibly changed. For example, even if Y001 is set to ON as a result of a table change, the program stops at the next scan if an OFF condition is set in the user program.



! Handling Precautions

- Forced setting, resetting and table changes can be set in the device table before execution. As a result, the result of the user program may not match the result produced by the forced result.
- Communication processing and table changes are processed off-line. (See figure above.)


4 - 3 Breakpoints

Breakpoints allow you to interrupt (break) a program when execution reaches a preset instruction step (the breakpoint), and monitor the result of execution produced at that point. This speeds up debugging of programs that perform a great number of data operations. A total of 16 breakpoints can be inserted in a program.

The conditions set at each breakpoint to stop the program can be set separately. The table on the following page describes break conditions.

(Example)

When a program does not operate as intended, the instruction words that are used to operate a device are called up and their changes are traced using the following procedure.



- ① Set the controller to the TEST mode.
- ② Insert a breakpoint before the instruction word whose operation is to be checked.
- ③ Make a monitor setting for the target device.
- ④ Set the execution (RUN) mode and specify start.
- ⑤ Execution stops when the program reaches the instruction with the breakpoint. The device data at this time are the values immediately before execution of the instruction.
- ⑥ Restart execution by specifying continue.
- ⑦ The program now stops (breaks) immediately after executing the instruction with the breakpoint. The device data at this point is the result of executing the instruction.
- ⑧ Check the data immediately before and after execution of the instruction to make sure that the intended process is taking place.

This procedure allows to check operation of a selected part of a program that runs erratically and identify the bugs (program errors) in them.

● Break types

The table below lists the nine break conditions. Set one of the following conditions.

	Break condition	Description
①	Normal break processing	User program execution is stopped at positions where breakpoints have been inserted.
②	Line logic ON	When the user program reaches the breakpoint, the line logic turns ON and break processing starts.
③	Line logic OFF	When the user program reaches the breakpoint, the line logic turns OFF and break processing starts.
④	Line logic OFF → ON	When the user program reaches the breakpoint, the line logic turns from OFF to ON and break processing starts.
⑤	Line logic ON → OFF	When the user program reaches the breakpoint, the line logic turns from ON to OFF and break processing starts.
⑥	Operational error 1 (M90E) is ON	When the user program reaches the breakpoint, break processing starts if operation error 1 (M90E) is ON.
⑦	Shift carry (M900) is ON	When the user program reaches the breakpoint, break processing starts if shift carry (M900) is ON.
⑧	Overflow flag (M901) is ON	When the user program reaches the breakpoint, break processing starts if the overflow flag (M901) is ON.
⑨	Underflow flag (M902) is ON	When the user program reaches the breakpoint, break processing starts if the underflow flag (M902) is ON.


4 - 4 Step Execution

This function is used to execute a program in instruction steps.

Step execution is used after program execution is stopped at a breakpoint, and enables detailed analysis of operation results.

Step execution allows 300 steps to be set at two locations or a total of 600 steps.

Step execution is performed as follows:



- ① Set the controller to the TEST mode.
- ② Specify step execution at the start of a program step range you want to check.
- ③ Make monitor setting for device that is to be observed.
- ④ Set step execution to "enable".
- ⑤ Set the controller to the execution (RUN) mode and specify start.
- ⑥ Execution stops (breaks) at the start of step where step execution was set. The device data at this point are the values of the instruction indicated by the cursor before execution.
- ⑦ Restart execution by specifying continue.
- ⑧ The instruction word indicated by the cursor is executed and then execution stops. The cursor now indicates the next instruction to be executed. The device data at this point is the result of execution of the instruction in step ⑥.
- ⑨ Steps ⑦ and ⑧ are repeated.

This procedure allows to check operation of a selected range part of a program that runs erratically and identify the bugs (program errors) in them.

! Handling Precautions

Care is required in inserting breakpoints and performing step execution.


- No outputs are updated to the output module during break operation. An update is made when the END instruction is executed.
- Inputs from input modules are accepted during break processing.

麿番


Chapter 5 CONFIGURING AND OPERATING PROCESSOR MODULES

5 - 1 Processor Module Configuration


■ MX200




■ MX100



■ MX50



■ MX30/MX20




Device	Description
Main CPU	This is the main CPU. This CPU is in charge of overall control of the processor module. It conducts I/O transactions with the sub-CPU and handles self diagnosis, program execution and peripheral services for ASCII communication.
Sub-CPU	This CPU controls I/O transactions between CBL, I/O modules and operator's I/O terminals. It also provides the main CPU with data of its operations and diagnoses key inputs, I/O bus checks, etc.
Working RAM	Stores the device table data. (The latch relay, timer/counter and register data are stored in registers that are battery backed up to ensure that it lasts through a power failure.)
PRAM	This RAM memory (31 K) stores user program source code. User programs from personal loaders, handy loaders* and PROM cards are written to this memory as source code.
Compile RAM	PRAM compiles stored user program source code i.e. converts it to machine language (object code) and stores it in this form. The CPU reads user programs stored in the compile RAM during execution to fetch required machine code data. This ensures speedy processing.
System ROM	This system ROM is used for self diagnosis.

* Only for MX100/MX30/MX20.

5 - 2 Processor Module Operation

■ Operation flow



■ Main CPU operations

1. Initial diagnosis

The CPU performs a ROM sumcheck and a read and write test of RAM.

2. Initialization of device table

The CPU checks the status of the device table when the MX controller is powered up or when the operation mode is changed from STOP to RUN/TEST modes.

Device		Device state			
		Master (MX200)		Slave (MX100, OP, ST100, etc.)	
		Used	Not used	Used	Not used
X	M000 to X19F	Clear → Input data	Clear (no module)	Clear → Input data	Clear (no module)
	X200 to X29F	Clear → Input data	Clear (no module)	Clear → Master data from X200 to 21F	Clear (no module)
Y	Y000 to Y19F	Clear	Clear → Can be used as M contact	Clear	Clear → Can be used as M contact
	Y200 to Y29F	Clear	Clear → Can be used as M contact	Clear	Clear → Can be used as M contact
M000 to M89F		Clear			
T/C contact					
L000 to L49F		Hold			
R0000 to R0499 R1000 to R4999					
Current T/C value		Cleared when used with a TMR instruction.			
T/C contact		Held when used with CNT, STM, UDC, DCNT and DUDC instructions.			
R0500 to R0519		Hold → Input data	Hold	Hold → Input data	Hold
R0600 to R0619		Clear → Input data	Clear → When used as general-purpose register	Clear → Input data	Clear → When used as general-purpose register
* P0050 to P3199		Hold → PC link for remote I/O data	Hold → When used as general-purpose register	Hold → PC link for remote I/O data	Hold → When used as general-purpose register

* P0000 to P0049 is CBL network data and P3800 to P3999 is mail communication setting data.

See Chapter 2, "Device Table and I/O Assignment" for information on device tables.

3. Check of user program (RAM)

A sumcheck of the user program is performed, and a program damage error (M999) is generated if an error is found.

4. Program check

Users programs undergo a syntax check before they are compiled. If a syntax error is found, the syntax error flag (M99A) is set and the program is not compiled.

5. Program compile

Compiling turns the user program into machine code which normally takes about 2 seconds.

6. Self diagnosis check

The result of the self diagnosis determines the operation mode.


-
7. Peripheral service
Data transactions are performed between the loader (Handy Loader or personal computer loader) or a host computer.
 8. Data transactions with the sub-CPU
I/O, alarms and error data is passed between the main and sub-CPU.

■ Sub-CPU operations


1. Initial diagnosis
The sub-CPU performs a ROM sumcheck and a read and write test of RAM.
2. Registered I/O check
The sub-CPU compares registered I/O modules and operator's I/O information with registered I/O modules and operator's I/O data. A verification error is output if they do not match.
3. Slot I/O self diagnosis
The sub-CPU issues a STOP request if a slot I/O self diagnosis discovers an error.
4. Data input
The sub-CPU fetches data from input modules.
5. Control of operator's I/O
The sub-CPU controls data transactions with operator's I/O.
6. Status display control
The sub-CPU outputs a status display on the front panel of the processor module.
7. Data output
The sub-CPU outputs data to output modules.

■ Ladder processing flow

● Internal flow




● Process flow



5 - 3 Scan Time and Response Time

■ Scan time

The scan time is the sum of the times required for ① execution of peripheral services, ② data transactions with the sub-CPU, and ③ execution of the user program.



① Peripheral service execution:

This is the time taken to perform data transactions between the loader (personal computer or Handy Loader) or host computer.

② Data transactions with sub-CPU:


This is the time taken to perform data transactions between the sub-CPU and registered I/O modules, operator's I/O and alarm and other data.

③ User program execution:

This is the time taken to process each instruction word.


● Update frequency of registered I/O module data

The sub-CPU continues to enter data in the registered I/O modules until the main CPU issues a handshake request. The data that the main CPU fetches from the sub-CPU is the latest data.



● Update frequency of operator's I/O data

Operator's I/O data is not input or output with the same frequency as data from registered I/O modules. As shown in the diagram below, the sub-CPU inputs and outputs data to and receives data from the operator's I/O once every several scans. When data from all connected operator's I/O modules is fetched, the sub-CPU issues a handshake request to the main CPU and passes all address data to the main CPU while it receives the data of all addresses that should be output.



- (Notes)
- Update cycles are reflected in special contact M929.
 - The MX30 and MX20 does not have an OP link function.


● How to Estimate Scan Time for MX200

The scan time is the sum of the following:

- ① peripheral service time + ② data transactions with the sub-CPU + ③ user program execution
- (Scan time estimate)

The minimum scan time for the MX200 depends on whether or not CBL is used, operation methods and I/O configuration.

The following graph shows the relationship between program size and scan time (reference value).



Factors that affect scan time

- ① No CBL but DI/O
 - Input module : 32 IN x 3, 64 IN x 1
 - Output module : 32 OUT x 3, 64 OUT x 1
- ② No CBL, but DI/O and special module
 - Input module : 32 IN x 1, 64 IN x 1
 - Output module : 32 OUT x 1, 64 OUT x 1
 - Special module (IN/OUT) : AI (4w/2w), AO (2w/2w), HSC (3w/3w), PPM (6w/6w)
- ③ CBL and DI/O
 - CBL : Five MX200 modules operating in dual mode; PC link execution
 - Input module : 32 IN x 3, 64 IN x 1
 - Output module : 32 OUT x 3, 64 OUT x 1

④ CBL, DI/O and special module

CBL	: Five MX200 modules operating in dual mode; PC link execution
Input module	: 32 IN x 1, 64 IN x 1
Output module	: 32 OUT x 1, 64 OUT x 1
Special module (IN/OUT)	: AI (4w/2w), AO (2w/2w), HSC (3w/3w), PPM (6w/6w)

① to ④ shared conditions

① The ladder program uses a combination of the following ten instructions

(1 instruction takes an average of 9 μ S):

Contact instruction	4
Output instruction	2
Compare instruction	1
BCD addition (F-10)	1
BIN subtraction (F-71)	1
8-word block transfer	1

- ② The loader is used for monitoring multi-contacts.
- ③ Data is changed according to the ASCII connector loader settings.
- ④ No OP link
- ⑤ Calculate maximum scan time.

● Notes on estimating scan time

- When a jump instruction is executed, the area of the program that is bypassed is not executed, but the scan time can be shortened proportional to the size of the skipped area. Master control instructions, on the other hand, execute the program between MC and MCR which means that the scan time does not change.
- The execution of instructions (ISS and IOS) that refresh I/O in a user program lengthens the scan time by 2 to 3 msec per instruction.

● Monitoring scan times

- The scan time is managed by a watchdog timer. When the scan time exceeds the value set in the watchdog timer, a scan time-out (M998) is generated. The program then enters the STOP mode. The initial value set in the watchdog timer is 100 ms. This can be changed with the watchdog timer refresh WDT instruction. Execute this instruction regularly.
- The MIN., LAST and MAX. scan time values are stored in the R0900 to R0902 special registers
- When the processor module is in the STOP mode, the value indicated by special register R0901 is the sub-CPU scan time.
This value indicates the minimum (=0) scan that is required by any step.


■ I/O response time

When there is a change in an external input signal, the time it takes from when the signal is output until a result is produced on the output terminal is referred to as the I/O response time.

- ① Minimum value: When the sub-CPU fetches a registered I/O module change immediately before a data transaction with the main CPU.
- ② Maximum value: When the sub-CPU fetches a registered I/O module change immediately after a data transaction with the main CPU.


● Minimum scan time:

I/O response time is the sum of (input module response time) + 1 scan + (output module response time).



● Maximum scan time:

I/O response time is the sum of (input module response time) + 2 scans + (output module response time).



Index

	[A]		[I]		
ASCII connector	· · · · ·	5-13	I/O register	· · · · ·	2-2
Auxiliary relay	· · · · ·	2-4	I/O registration	· · · · ·	2-33
	[B]		Indirect addressing	· · · · ·	3-17
Basic system	· · · · ·	1-3	Input relay	· · · · ·	2-3
Bit device	· · · · ·	3-13	Internal relay	· · · · ·	2-1
Break types	· · · · ·	4-4	Internal relay area	· · · · ·	2-4
Breakpoint	· · · · ·	4-3			
	[C]		[L]		
Communication system	· · · · ·	1-4	Ladder display constraints	· · · · ·	3-6
Constants	· · · · ·	3-13	Ladder processing flow	· · · · ·	5-8
Counter	· · · · ·	2-5	Latch relay	· · · · ·	2-4
	[D]		Line loopback	· · · · ·	3-6
Data changes	· · · · ·	4-2	Link register	· · · · ·	2-7
Destination	· · · · ·	3-13			
Device table	· · · · ·	2-1	[M]		
Duplicated output	· · · · ·	3-11	Main CPU operation	· · · · ·	5-6
	[E]		Maximum range of circuit block	· · · · ·	3-6
External relay	· · · · ·	2-1	Missing I/O module	· · · · ·	2-34
External relay area	· · · · ·	2-3	Monitoring scan times	· · · · ·	5-13
	[F]				
Flag	· · · · ·	3-18	[N]		
Flag hold	· · · · ·	3-18	Notes on the use of branch instructions	· · · · ·	3-11
Flag operation	· · · · ·	3-18			
Flow chart describing each step involved in system design	· · · · ·	1-1	[O]		
Forced setting/resetting	· · · · ·	4-2	OP link	· · · · ·	1-5, 2-36
Function for directly changing internal data from outside	· · · · ·	4-1	OP link output relay	· · · · ·	2-3
Function for manipulating the program execution	· · · · ·	4-1	Operation mode	· · · · ·	1-6
Functions for observing internal data	· · · · ·	4-1	Operational error flag	· · · · ·	3-21
	[G]		Operator's I/O	· · · · ·	2-33
General-purpose I/O module	· · · · ·	2-33	Output relays	· · · · ·	2-3
	[H]		Overflow flag	· · · · ·	3-19
Host communication	· · · · ·	1-4			
How to estimate scan time	· · · · ·	5-12	[P]		
			PROG mode	· · · · ·	1-6
			Program execution sequence	· · · · ·	3-1
			Program shortcuts	· · · · ·	3-2
			Pulse specifying	· · · · ·	3-14

[R]

Range of timer/counter settings 2-5
Register 2-2
Register area 2-6
Remote I/O input relay 2-3
Remote I/O output relay 2-3
Response time 5-14
RS-232C crossover cable 1-3
RUN input 1-6
RUN mode 1-6

[S]

Scan time 5-10
Shift carry flag 3-18
Source 3-13
Special I/O module 2-34
Special register 2-6, 2-18
Special relay 2-4, 2-8
Specifying data 3-15
Step execution 4-5
STOP input 1-6
STOP mode 1-6
Sub-CPU operation 5-7
Syntax errors 3-22

[T]

TEST mode 1-6
Timer 2-5
Timer/counter area 2-5

[U]

Underflow flag 3-19
Update frequency of operator's I/O data 5-11
Update frequency of registered I/O module data 5-10

[W]

Watchdog timer 5-13

Specifications are subject to change without notice.

YAMATAKE

Yamatake Corporation

Control Products Division

Head office : Totate International Building
2-12-19 Shibuya Shibuya-ku Tokyo 150-8316 Japan

Inquiries to : International Business Division

Phone : 81-3-3486-2331, Fax : 81-3-3486-2300 (Sales)

Phone : 81-466-20-2307, Fax : 81-466-27-9264 (Customer Service)

<http://www.yamatake.com>

This has been printed on recycled paper.

Printed in Japan.

1st Edition: Issued in Nov., 1989

3rd Edition: Issued in Oct., 2002(M)