

ThermoPLUS
Smart Temperature Transmitter
(Remote Type)
Model ATT60/70
Operation Manual



Yamatake Corporation

Copyright, Notices and Trademarks

Printed in U.S.A. – © Copyright 1999 by Yamatake Corporation.

While this information is presented in good faith and believed to be accurate, Yamatake Corporation disclaims the implied warranties of merchantability and fitness for a particular purpose and makes no express warranties except as may be stated in its written agreement with and for its customer.

In no event is Yamatake Corporation liable to anyone for any indirect, special or consequential damages. The information and specifications in this document are subject to change without notice.

Preface

Thank you for purchasing the Yamatake's ThermoPLUS, the Smart Temperature Transmitter. ThermoPLUS is a highly reliable, next generation of advanced transmitter for general use. It has been developed based on our extensive experience and field record. ThermoPLUS suites a wide range of applications and is easy-to-use in on-site operation.

Unpacking and Inspection

Unpacking

This product is a precision instrument and should be handled with care to prevent damage or breakage.

After unpacking the product, verify that the following items are included:

- ThermoPLUS Smart Temperature Transmitter
 - 2 pressure-tight packings, 2 washers and 2 elbows
 - 1 hexagonal wrench key
 - 2-inch pipe mounting bracket (optional)
 - Operation manual
-

Verifying specifications

The specifications of your ThermoPLUS are written on its attached identification plate. Compare these specifications with those listed in the Appendix, and verify that all specifications on the plate are correct, paying special attention to the following:

- Basic model number
 - Product number
 - Power supply
 - Output/communications
 - Contact input/output
-

Inquiries

If you have any questions regarding the specifications of your ThermoPLUS, contact your nearest Yamatake representative. When making an inquiry, be sure to provide the model number and product number of the product.

Storage precautions

When storing ThermoPLUS before use, observe these precautions:

- Store it indoors at room temperature (77°F or 25°C) and humidity (65%), in a place safe from vibration or shock.
- Store it in the same condition as it was shipped.

When storing the product after use, follow these steps:

1. Rinse the inside of the transmitter with water to eliminate residual fluids, then allow it to dry.
 2. Firmly attach the terminal box cover and the electrode cover in order to keep out the moisture.
 3. Replace the transmitter in its original packaging.
 4. Store the transmitter indoors at room temperature and humidity (65%), in a place safe from vibration or shock.
-

Safety Precautions

Introduction

Correct installation, correct operation and regular maintenance are essential to ensure safety during the use of this device. Do not try to install or operate the device before reading and understanding the safety precautions described in this manual. Be sure to follow the instructions, operation and maintenance

Safety Standard

The safety instructions presented in this operation manual conforms to ANSI (American National Standards Institute) Z535-4. Two kinds of safety precautions are used in this manual - Warning and Cautions. The meanings of these terms are as follows:

 **Warning**

Potentially hazardous situation which, if not avoided, could result in death or serious injury.

 **Caution**

Failure to observe these precautions may produce dangerous conditions that could result in injury to the user or in physical damage.

General Precautions

- Turn OFF the power switch before any wiring work.
- Be sure that the product conforms to the specifications. If the range is inappropriate, excessive temperature may be generated, causing damage to the device.
- Do not use a transceiver (including cellular phones) within the area of 7 feet (2 meters) around this product or its connecting cables. Doing so may result in malfunctioning of the product.
- Check wiring carefully for mistakes. Wrong connections may result in product failure.
- Be sure that, while clamping a terminal, the other wire(s) do not touch the adjacent terminals.
- If something goes wrong with this product, its electrical output may become abnormal, causing an abnormal response. If product safety could be impaired in such a situation, this product should be used with appropriate consideration given to fail-safe design, including separation of the controller from the limiter, use of a duplex system and redundancy design.
- After the wires have been connected, be sure to close the terminal box cover and tighten the set-screws that hold the housing in place. The cover must be locked for an explosion-proof specification.

About Explosion-proof Models

Pressure-resistant Explosion-proof Housing

- Explosion-proof ATT (Advanced Temperature Transmitter) has a pressure-resistant explosion-proof housing. Handling an explosion-proof model requires special care. Be sure to read and understand all the applicable Explosion-proof codes and regulations of respective Approval Body before use.
- The completely sealed housing is designed to withstand the pressure that may result from an explosion of an explosive gas **INSIDE** the housing. This housing may prevent combustion of any explosive gas **OUTSIDE**.

Applicable Installations

- Always use the explosion-proof unit in applicable condition and in applicable location. Failure to satisfy any of these requirements will destroy the designed explosion-proof characteristics of the transmitter. When wiring, follow all the applicable codes for explosion-proof and intrinsically safe system applications.
- Attach only the supplied pressure-tight accessories to the signal-wire exit. If necessary, change the wiring direction and use the elbow (supplied). No other elbow may be used to ensure the designed explosion-proof characteristic.
- When handling explosion-proof unit, prevent corrosion, deformation or damage to its housing or cover. When installing the cover, completely tighten the hexagon socket set screw to lock. **NEVER** open the cover while the unit is in operation.

NOTES

Table of Contents

1. Overview of Product	1-1
1.1 Overview of ThermoPLUS Transmitter	1-1
1.2 Types of ThermoPLUS Transmitter	1-1
1.3 Data Settings for ThermoPLUS Transmitter	1-1
1.4 Names of ThermoPLUS parts	1-2
2. Installation and Wiring	2-1
2.1 Overview	2-3
2.2 Installation Environment	2-3
2.3 Installing the Transmitter Using the Mounting Brackets	2-5
2.4 Wiring	2-6
2.5 Burn-out Setting	2-8
2.6 Wiring for Explosion-Proof Specifications	2-8
2.7 Insulation-Resistance and Voltage-Withstand Tests	2-9
3. Operations and Settings	3-1
3.1 SFC	3-1
3.2 Features of the SFC	3-2
3.3 Names of the SFC Components	3-3
3.4 Connecting the SFC	3-5
3.4.1 How to Connect the SFC	3-5
3.4.2 Starting Communication	3-7
3.5 ThermoPLUS-Specific Features Using SFC	3-9
3.5.1 Displaying and Changing the Input	3-9
3.5.2 Displaying and Changing the Cold Junction Options	3-11
3.5.3 Displaying and Changing the Temperature Input for External Cold Junction	3-12
3.5.4 Displaying and Changing the Burn-out Setting	3-13
3.5.5 Displaying and Changing the Settings for Internal Linearization Processing	3-14
3.5.6 Displaying the Maximum and Minimum Input Values	3-15
3.5.7 Displaying the Internal Cold Junction Temperature	3-16
3.6 Using the Common Features of SFC	3-17
3.6.1 Displaying and Changing the Tag Number	3-17
3.6.2 Displaying the Input Temperature Value	3-18
3.6.3 Displaying the Transmitted Output (%)	3-18
3.6.4 Displaying and Changing the Upper- and Lower-Range Values for Range Setting	3-19
3.6.5 Displaying or Changing the Engineering Unit of Measurement	3-21
3.6.6 Displaying or Changing the Damping Time Constant	3-22
3.6.7 Displaying the Software Version	3-24
3.6.8 Printing Function (optional)	3-25
3.6.9 Printing Function: Printing Out Data Stored in the Transmitter (Maintenance Printing)	3-26
3.6.10 Printing Function: Printing Responses Continuously (Action Printing)	3-28
3.6.11 Changing from Analog Mode to Digital Mode	3-30
3.7 Setting the Signal Mode for Digital Communication Specifications	3-31
3.7.1 Setting the Output Signal Mode	3-32
3.7.2 Setting the Information Size Mode	3-33

3.7.3 Setting the Fail-Safe Mode _____	3-34
3.8 Adjusting the Output Current _____	3-36
3.8.1 Setting the Constant Current Mode _____	3-36
3.8.2 Canceling the Constant Current Mode _____	3-37
3.8.3 Calibrating the Output Signal _____	3-38
3.8.4 Storing the Calibrated Values and Cancelling the Constant Current Source Mode _____	3-40
3.9 Calibrating the Set Range by Inputting the Actual Temperature _____	3-41
3.9.1 Overview _____	3-41
3.9.2 Calibrating the Lower-Range Value _____	3-42
3.9.3 Calibrating the Upper-Range Value _____	3-43
3.9.4 Resetting Calibrated Data _____	3-44
3.10 Setting Lower-Range Value as Actual Temperature _____	3-45
4. Troubleshooting _____	4-1
4.1 Troubleshooting by SFC _____	4-2
4.1.1 Troubleshooting and Verification of Normal Functioning _____	4-2
4.1.2 If Abnormal Conditions Are Encountered during Communication _____	4-3
4.1.3 Self-diagnostic Messages _____	4-4
4.1.4 If an Error Has Occurred on the Thermone Transmitter _____	4-7
4.2 FAQs _____	4-8
4.3 Contact Information in the Event of an Error _____	4-9
5. Maintenance _____	5-1
5.1 Spare Parts _____	5-1
5.2 Disassembly and Assembly _____	5-2
6. Types of Installation _____	6-1
6.1 Example of Sensor installed Remotely _____	6-1
6.2 Example of Sesor Connected Directly _____	6-1

1. Overview of Product

1.1 Overview of ThermoPLUS Transmitter


The ThermoPLUS Smart Temperature Transmitter is a temperature transmitter with a built-in microprocessor. It accepts various types of thermocouple (T/C), resistance temperature detector (RTD), or voltage signals, and converts them to and outputs a signal of 4-20 mA DC or digital DE.

1.2 Types of ThermoPLUS Transmitter

ThermoPLUS Transmitters come in two types: the temperature-sensor-remote type and the temperature-sensor-integral type. Each type is further classified into water-proof and explosion-proof, with a total of four different types. This operation manual is intended for both the water-proof and explosion-proof types of the temperature-sensor-remote transmitter. For the temperature-sensor-integral type, see the operation manual “ThermoPLUS Smart Temperature Transmitter 2-Wire Temperature Transmitter (Integral Type)” (CM2-ATT110-2001).

1.3 ThermoPLUS Data Settings

A Smart Field Communicator (referred to as “SFC”), available separately, is used to adjust or set data for ThermoPLUS. The SFC can operate from anywhere on a DC 4-20 mA signal line as long as the wiring distance between ThermoPLUS and the SFC is 1,500 meters (1,640 yard) or less. For details, see the operation manual for the SFC (CM2-SFC100-2001).



Smart Field Communicator (sold separately)

1. Overview of Products

1.4 Names of ThermoPLUS Parts

Description of parts




Figure 1-1 General view (front view)




Figure 1-2 General view (rear view)

Description of parts
(continued)




Figure 1-3 Mounting Bracket (optional)

2. Installation and Wiring

Safety Precautions

 **CAUTION**

- After the transmitter is installed, do not use it as a foothold or for other improper uses. Doing so may cause damage to the product and personal injury.
- Hitting the glass portion of the indicator with a tool may break the glass and cause personal injury. Caution must be exercised with products equipped with digital indicators.
- The heat of the process fluid and/or the heat radiated from the piping may raise the surface temperature of the transmitter very high. Exercise caution.

Installation Precautions

- Do not use the transmitter under any operating conditions other than those described in the product specifications (i.e., rated pressure, connection standard, rated temperature, rated vibration, and rated humidity). Using this product under incorrect operating conditions may cause damage to the product and leakage that could lead to a major accident.
 - Wiring work in hazardous areas should be performed carefully by following the work methods specified in the explosion-protection guidelines.
 - Provide good grounding to the transmitter. If it is not grounded or grounding is inadequate, output error will occur. Not grounding the transmitter is a violation of regulations. Be careful of your footing during installation. Always wear safety shoes.
 - This product must be installed on a 2-inch pipe using the mounting bracket (optional part).
-

Wiring Precautions

 **CAUTION**

- Performing wire work with wet hands or with the power connected may result in electric shock to personnel. Perform wiring work with dry hands, always wear gloves and be sure to disconnect the power to the product before performing work.
- Perform the wiring work correctly while carefully checking the specifications. Incorrect wiring will cause a damage or malfunction to the product.
- Use the power supply properly, based on the specifications. Connecting a different power supply will cause a damage to the product.
- This product is designed based on a two-wire wiring system. The power supply line also functions as a signal line. The wires are routed through the conduit hole on the side face of the transmitter and connected to the terminals. The conduit connection is potted with a sealing agent or by fitting a sealing plug, so that water cannot leak into the transmitter unit. The wires to be connected to the terminals must be drawn in from below the position where the connection port is located.
- **Grounding wire**
The transmitter has two grounding terminals: one at the terminal and the other on the outside face. Either terminal can be used for grounding. The grounding terminal must be connected to a class D ground (grounding resistance 100 Ω or less) or better ground.
- If installing your ThermoPLUS according to the explosion-proof specifications, observe the restrictions specific to the explosion-proof equipment. The wiring method for the explosion-proof device is described in Section 2.6, "Wiring for Explosion-Proof Specifications." In this case, also refer to respective applicable Approval Body for details.

 **WARNING**

- Turn OFF the power supply before wiring work to prevent the electric shock from occurring.
- Be sure to follow all the regulations of respective Explosion-Proof Approval Body applicable.
- Use only the supplied pressure-tight accessories for installing an explosion-proof unit. Close the terminal box cover completely and tighten the packing unit securely. Never open the housing cover while the unit is in operation.

2.1 Overview

There are two product lines of ThermoPLUS; the temperature-sensor-remote type and the temperature-sensor-integral type. The transmitter you have purchased is the temperature-sensor-remote type and the converter is typically installed separately from the temperature-sensor. The separate type can be connected to a temperature-sensor, in which case it no longer conforms to the JIS explosion-proof structure for the integral type, thus respective codes and regulations of your applicable Approval Body should be thoroughly followed. If your ThermoPLUS is to be attached to a temperature-sensor element, be sure to install it properly by reading and following the operation manual for the temperature-sensor-integral converter type (CM2-ATT110-2001).

2.2 Installation Environment

(1) Ambient temperature

Exercise extra caution if you are installing your ThermoPLUS at a location that is subject to large temperature fluctuation. To minimize the effects of heat radiated through the process, take measures as needed; such as using a radiator or air purging.

Note that when you use the temperature-sensor-integral type, even more heat will be felt.

The explosion-proof specifications stipulate the operating temperature (ambient temperature of the temperature-sensor section, for explosion-proof purposes separately from the temperature-sensor's heat-resistant temperature.

(2) Ambient atmosphere

If the transmitter is installed at a location where there may be a corrosive gas, protect the ThermoPLUS from the possible gas corrosion for the temperature-sensor elements. Select a corrosion-proof material that is appropriate to the actual fluid subject to measurement. If an inappropriate material is used, fluid may flow inside the converter, resulting in damage not only to the temperature sensor but also to the converter itself.

Continued

Continued

(3) Vibration and shock

Using ThermoPLUS in an environment subject to constant, excessive vibration is not recommended. However, if it is unavoidable, take necessary measures to minimize the vibration. Carefully examine the vibration factors, especially when using the transmitter with the temperature-sensor attached. Vibration may cause damage to the temperature-sensing element as well as the converter unit itself. For details of the effect of vibration on the temperature-sensing element, see the specifications of the sensor.

(4) Noise

Your ThermoPLUS has been tested and verified to be immune to high-frequency noise that is typical to field transceivers. However, due to the recent rapid proliferation of cellular phones, some of the models have not been tested for their effects. If such device is to be used near the ThermoPLUS, make sure that the device has no effect on the ThermoPLUS.

(5) Insulation resistance and voltage-withstand tests

Your ThermoPLUS has a built-in lightning arrester. When testing its insulation resistance and withstand voltage, exercise caution, because excessive electricity may deteriorate the arrester performance and internal damage may result. If these tests are necessary, be sure to follow the procedure provided in Section 2.7 "Insulation-Resistance and Voltage-Withstand Tests."

(6) Others

Install your ThermoPLUS in an area where adequate space is available for disassembly and maintenance.

2.3 Installing the Transmitter Using the Mounting Brackets

Mounting brackets are supplied with the ThermoPLUS as optional accessories. For additional mounting hardware, refer to Section 5.1, "Spare Parts." With the mounting bracket, the ThermoPLUS can be installed on a 2-inch pipe as well.




Figure 2-1 Mounting Brackets

2.4 Wiring

Use DC power and see ThermoPLUS's Specification sheet for the relationship between power supply and load resistance. Terminal connections are shown in Figures 2-2 and 2-3.

For the wiring cable, use vinyl-insulated vinyl sheath cable for control CVV (JIS C3401) or higher quality. The cable may be affected by electromagnetic induction if there is a high-voltage motor or transformer near the transmitter. If this is the case, use a shielded cable and place the transmitter as far away from the noise source as possible. If the transmitter is used in an environment where the ambient temperature becomes high or corrosion may occur, use a vinyl-sheath cable with high heat or corrosion resistance. If an inappropriate cable is used, the transmitter's reliability and explosion-proof performance will be adversely affected.

For grounding, use a 600-V vinyl-insulated cable and perform class D grounding work (grounding resistance 100 Ω or less).

For the wiring from the temperature sensor, use the cable dedicated to the temperature-sensor. Use a compensation lead wire for a thermocouple temperature sensor, and a 3-core cable for a thermoresistance temperature sensor.

(Note: Check the temperature specifications of the cable that is used to connect the temperature sensor. If its heat resistance is less than the maximum value of the ambient temperature, the explosion resistance may be compromised.)

Table 2-1 Terminal numbers

Terminal numbers	RTD	TC	Remarks
1	A	N/A	
2	B	-	Voltage (-)
3	B	+	Voltage (+)
4	Power supply (+)		DC 24 V or connected to the distributor
5	Power supply (-)		
6	GND		
7	Burn-out		without short bar:Downscale
8			with short bar: Upscale

Figure 2-2 Terminal connection diagram (input wiring)





Figure 2-3 Terminal connection diagram (Output Wiring and Burn-out Setting)



2.5 Burn-out Setting

As shown in Figure 2-3, “Terminal Connection Diagram (Output Wiring) and Burn-out Setting,” the burn-out setting depends on whether or not a short bar is installed on the terminal. If the transmitter is used with the short-circuit board installed, burn-out upscale (upscale output in the event of an error) takes effect; otherwise, burn-out downscale (downscale output in the event of an error) takes effect.

The product is shipped as either U (upscale) or D (downscale) according to the burn-out direction you specified as an option at the time of ordering. Verify the burn-out setting before using the transmitter.

Table 2-2 Burn-out setting

Short bar	Burn-out	Output in the event of error
Used	Upscale	\geq DC20.8mA DC
Not used	Downscale	\leq DC3.8mA DC

2.6 Wiring for Explosion-Proof Specifications

- JIS explosion-proof specifications employed in your ThermoPLUS are based on the explosion-proof standard that was stipulated as part of the technical standards revised in February 1997 (international conformity with IEC79). The explosion-proof performance stipulated in this standard can be achieved by combining ThermoPLUS with a pressure-tight packing-type cable ground (optional). Be sure to use the specified pressure-tight packing-type cable ground when wiring for explosion-proof specifications.
 - For other types of explosion-proof specifications, follow the regulations, and guidelines stipulated by respective Explosion Approval Body.
-

2.7 Insulation-Resistance and Voltage-Withstand Tests

Precautions

Generally, insulation-resistance and voltage-withstand tests should not be necessary. If these tests are conducted, the built-in varistor for surge voltage absorption may be damaged. If these tests are absolutely necessary due to unavoidable circumstances, they must be conducted carefully by following the specified test procedures.

Test Procedure

1. Remove the external wires from the ThermoPLUS.
2. Short-circuit the + and – SUPPLY terminals.
3. Conduct the tests between these short-circuited terminals and the ground terminals.
4. Voltage to be applied and judgment criteria are shown as follows. To prevent damage to the product, voltages higher than the voltage values shown must not be applied.

Judgment Criteria

Voltage to be applied and judgment criteria are as follows.

Test	Judgment criteria
Insulation-resistance test	More than $2 \times 10^7 \Omega$ at an applied voltage of 25 VDC ($25^\circ\text{C} \pm 5^\circ\text{C}$, less than 60% RH)
Voltage-withstand test	50 VAC, 1 minute, current set at 2 mA

3. Operations and Settings

3.1 SFC

SFC is a very convenient tool that enables the user to communicate with the ThermoPLUS Transmitter and remotely operate and set internal data. SFC can adjust the ThermoPLUS or set its data from anywhere on a DC 4-20 mA signal line, as long as the wiring distance between ThermoPLUS and the SFC is 1,640 yard (1,500 meters) or less. For details about SFC, see the SFC operation manual (CM2-SFC100-2001).

SFC can display or change any of the transmitter values or status listed as follows. Such display or modification can be performed even during measuring operation.

3. Operations and Settings

3.2 Features of the SFC

Table 3-1 ThermoPLUS-specific features

√: Available, -: Unavailable

Item	Display	Modification	Details
Input selection	√	√	3.5.1
Cold junction (internal, external)	√	√	3.5.2
External cold junction temperature	√	√	3.5.3
Burn-out	√	√	3.5.4
Thermocouple disconnection diagnosis	√	√	3.5.5
Internal linearization processing	√	√	3.5.6
Displaying the maximum and minimum input values	√	-	3.5.7
Displaying the internal cold junction temperature	√	-	3.5.8
LRL	√	-	----

Table 3-2 Common features

√: Available, -: Unavailable

Item	Display	Modification	Details
Entering the tag number	√	√	3.6.1
Displaying the input temperature (units of measurement)	√	-	3.6.2
Displaying the transmitted output (%)	√	-	3.6.3
Lower-Range value for range setting	√	√	3.6.4
Upper-Range value for range setting	√	√	3.6.4
Span of range setting	√	*	3.6.4
Units of measuremen	√	√	3.6.5
Dumping time constant	√	√	3.6.6
Software version	√	-	3.6.7
Printing function	-	-	3.6.8
Maintenance printing	-	-	3.6.9
Action printing	-	-	3.6.10
URL	√	-	-
Output format (analog/digital)	√	√	3.6.11

*: This information cannot be changed directly, but a change is made as a result of setting LRV or URV.

3.3 Names of the SFC Components

Names of Components

The following figure shows the structure of the SFC and the names of its parts. The model shown here (SFC260) has the printer unit.




Figure 3-1 Names of the SFC components

3. Operations and Settings

SFC Keyboard

The following figure shows the keyboard of the SFC.




Figure 3-2 SFC Keyboard

3.4 Connecting the SFC

3.4.1 How to Connect the SFC

Connect SFC as shown in figure 3-3 before use.




Figure 3-3 Connecting the SFC

Warning








After the SFC is connected as shown above, turn on the power switch. When using the SFC for setting or checking during startup, place the control loop connected to the transmitter in the manual control mode; otherwise, a dangerous operational condition may occur.

If the ThermoPLUS Transmitter is operated with its housing cover open, it is no longer considered explosion-proof equipment. Operate your ThermoPLUS with the cover open only in a safe place in a non-explosion-proof area.

3. Operations and Settings


How to Interact with the SFC Screen

The SFC can be operated interactively. To operate the SFC in an interactive manner, observe the following instructions:

- To respond “Yes” to a question on the screen, press the  key. Pressing the  key on the special function screen will bring you to the next level in the communication hierarchy.
- To respond “No” to a question, press the  key. Pressing the  key on the special-function screen brings you back to the previous level in the communication hierarchy. Pressing and holding down the  key returns you to the initial screen.
- When selecting a different function in the same hierarchy, press either the  key or the  key.

Caution

If a “:” mark shown below appears in the eighth digit at the top of the SFC screen, immediately discontinue operation of the SFC and recharge its battery. If you ignore this mark and continue operation, the battery will continue to discharge, become damaged, and cannot be recharged.






3.4.2 Starting Communication

Warning

- Before starting communication with the transmitter from the SFC, switch over the process-control loop to manual control.
- If communication with the transmitter begins while the process-control loop is still in the auto control mode, abrupt changes in output may occur, creating an unstable operating environment.





Procedure

Start communicating with Thermones by operating the SFC as follows:

Step	Description	SFC screen
1	Check to make sure that the ThermoPLUS is turned on. If its power switch is off, turn it on.	
2	Check to make sure that the signal lines of the ThermoPLUS and SFC are correctly wired.	
3	Turn on the power switch of the SFC. The SFC performs a self-diagnosis and displays the message shown to the right. This message requests the user to take an appropriate action so that the host control system is not directly affected by the fluctuation of ThermoPLUS output that may be caused by communication between the SFC and ThermoPLUS. Take special care when using an analog output system. Press the  key.	
4	The message to the right is displayed.	

3. Operations and Settings

Procedure
(continued)





Step	Description	SFC screen
5-1	<p>Analog specifications: Press the  key. When this step is completed, the ThermoPLUS and the SFC are connected and other communication-related information can be set.</p>	<div data-bbox="1142 580 1391 656" style="border: 1px solid black; padding: 2px;">TAG No. WORKING...</div> <div data-bbox="1142 680 1391 757" style="border: 1px solid black; padding: 2px;">ATT TAG No. ATT XXXXXXXX</div>
5-2	<p>Digital specifications: Press the  key and then press the  key. When this step is completed, the communication between ThermoPLUS and the SFC are established and is ready for further communication. Tag number, xxxxxxxx (8 digits) will appear unless default tag number setting was done prior to shipment. To enter the tag number, refer to 3.6.1 “Displaying and Changing the Tag Number.”</p>	<div data-bbox="1142 831 1391 907" style="border: 1px solid black; padding: 2px;">SHIFT-</div> <div data-bbox="1142 931 1391 1008" style="border: 1px solid black; padding: 2px;">DE XMTR WORKING... XX %</div> <div data-bbox="1142 1032 1391 1108" style="border: 1px solid black; padding: 2px;">ATT DE TAG No. ATT DE XXXXXXXX</div>
6	<p>Press the  key. When the message to the right is displayed, the SFC can be disconnected from the ThermoPLUS.</p>	<div data-bbox="1142 1368 1391 1444" style="border: 1px solid black; padding: 2px;">ATT XXXXXXXX READY...</div>

Note: For use of SFC prior to version 7.8; please do not be alarmed if “STT” appears in stead of “ATT”, after step 5. “STT” is Yamakate’s former model of temperature transmitter, and should be regarded as same as “ATT.”

3.5 ThermoPLUS-Specific Features by Using SFC





3.5.1 Displaying and Changing the Input

Procedure

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 6 of Section 3.4.2.	ATT XXXXXXXX READY...
2	Press the  key, to display this message.	ATT CONFIG CHANGE CONFIG?
3	Press the  key. The ThermoPLUS-specific features are now ready to be set. These features enable the user to change the type of input and set the cold junction, output format, power filter, and detection of thermocouple burn-out. <u>Note that the power filter is not applicable to the ThermoPLUS.</u>	ATT CONFIG PROBE = TYPE J
4	Press the  key to select the type of input. (For the thermoresistance input, either Pt100 or JPt100 can be selected.) (For the thermocouple input, Type J, K, T, S, R, E, B, or N can be selected.) (Voltage input is in mV only.)	Thermoresistance input: ATT CONFIG PROBE = Pt100 Thermocouple input: ATT CONFIG PROBE = TYPE J Voltage input: ATT CONFIG PROBE = mV
5	Press the  key. The subsequent steps are for exiting the procedure for setting the ThermoPLUS-specific features. These steps are also used when the settings of other ThermoPLUS-specific features are changed.	ATT CONFIG ENTERD IN SFC


















3. Operations and Settings

Procedure
(continued)

Step	Description	SFC screen
6	Press the  or  key until the message to the right is displayed.	<div data-bbox="1139 584 1390 658" style="border: 1px solid black; padding: 5px;">ATT CONFIG DOWNLOAD DATA?</div>
7	Press the  key. The messages to the right are displayed in this order.	<div data-bbox="1139 833 1390 907" style="border: 1px solid black; padding: 5px;">ATT CONFIG WORKING...</div> <div data-bbox="1139 936 1390 1010" style="border: 1px solid black; padding: 5px;">ATT CONFIG DATA LOADED!</div> <div data-bbox="1139 1039 1390 1113" style="border: 1px solid black; padding: 5px;">ATT CONFIG CHANGE CONFIG?</div>
8	When the setting is completed, press the  key. When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	<div data-bbox="1139 1270 1390 1344" style="border: 1px solid black; padding: 5px;">ATT XXXXXXXX READY...</div>

3.5.2 Displaying and Changing the Cold Junction Options








Procedure

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 3 of Section 3.5.1.	
2	Press the  key to display this message.	
3	Press the  key and select either internal or external cold junction.	 
4	Press the  key.	
5	Press the  or  key until the message to the right is displayed.	
6	Press the  key. The messages to the right are displayed in this order.	  
7	When the setting is completed, press the  key. When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	

3. Operations and Settings









3.5.3 Displaying and Changing the Temperature Input for External Cold Junction

Procedure

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 3 of Section 3.5.1.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> ATT CONFIG PROBE = TYPE J </div>
2	Press the  or  key until the message to the right is displayed.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> ATT CONFIG 0.0000°C ECJT </div>
3	Press numeric keys to set the external cold junction temperature.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> ATT CONFIG 0.2000°C ECJT </div>
4	Press the  key.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> ATT CONFIG ENTERD IN SFC </div>
5	Press the  or  key until the message to the right is displayed.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> ATT CONFIG DOWNLOAD DATA? </div>
6	Press the  key. The messages to the right are displayed in this order.	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 5px;"> ATT CONFIG WORKING... </div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 5px;"> ATT CONFIG DATA LOADED </div> <div style="border: 1px solid black; padding: 5px; width: fit-content;"> ATT CONFIG CHANGE CONFIG? </div>
7	When the setting is completed, press the  key. When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> ATT XXXXXXXX READY... </div>

3.5.4 Displaying and Changing the Thermocouple Burn-out Setting









Procedure

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 3 of Section 3.5.1.	ATT CONFIG PROBE = TYPE J
2	Press the  or  key until the message to the right is displayed.	ATT CONFIG BURN OUT ON
3	Press the  key and select whether thermocouple burn-out diagnosis is ON or OFF.	ATT CONFIG BURNOUT ON or ATT CONFIG BURNOUT OFF
4	Press the  key .	ATT CONFIG ENTERED IN SFC
5	Press the  or  key until the message to the right is displayed.	ATT CONFIG DOWNLOADED DATA?
6	Press the  key. Messages will be displayed as shown.	ATT CONFIG CHANGE CONFIG? ATT CONFIG WORKING ATT CONFIG CHANGE CONFIG?
7	Press the  key when the setting is completed. When this message is displayed, the ThermoPLUS can be disconnected from SFC.	ATT XXXXXXXX READY...

3. Operations and Settings









3.5.5 Displaying and Changing the Settings for Internal Linearization Processing

Procedure

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 3 of Section 3.5.1.	ATT CONFIG PROBE = Pt100
2	Press the  or  key until the message to the right is displayed.	ATT CONFIG O/P LINEAR
3	Press the  key to select the option for having the ThermoPLUS internally calculate linearization and output the value, or the option for assigning output within the preset range according to the input from the temperature sensor, without internal calculation by the ThermoPLUS.	ATT CONFIG O/P LINEAR
4	Press the  key.	ATT CONFIG ENTERD IN SFC
5	Press the  or  key until the message to the right is displayed.	ATT CONFIG DOWNLOAD DATA?
6	Press the  key. The messages to the right are displayed in this order.	ATT CONFIG WORKING... ATT CONFIG DATA LOADED! ATT CONFIG CHANGE CONFIG?
7	When the setting is completed, press the  key. When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	ATT XXXXXXXX READY...

3.5.6 Displaying the Maximum and Minimum Input Values





Procedure

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described in step 3 of Section 3.5.1.	ATT CONFIG CHANGE CONFIG?
2	Press the  or  key until the message to the right is displayed.	ATT CONFIG READ Hi/Low PV?
3	Press the  key to read the maximum and minimum values of temperature stored in the ThermoPLUS. Once this data is read, it is erased and the next maximum and minimum values are stored.	ATT CONFIG WORKING... ATT CONFIG -3.14°C Lo
4	Press the  or  key.	ATT CONFIG 1 2 4 . 8 9 °C Hi
5	When data has been read, press the  or  key.	ATT CONFIG EXIT?
6	Press the  key. When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	ATT CONFIG READY...

3. Operations and Settings

3.5.7 Displaying the Internal Cold Junction Temperature

Procedure



















Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 3 of Section 3.5.1.	ATT CONFIG CHANGE CONFIG?
2	Press the  or  key until the message to the right is displayed.	ATT CONFIG READ CJT?
3	Press the  key to read the Internal Cold Junction Temperature. The displayed value will update itself every 6 seconds.	ATT CONFIG WORKING... ATT CONFIG 25.31°C CJT
4	When data has been read, press the  key.	ATT CONFIG READ CJT?
5	When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	ATT CONFIG READY...

3.6 Using the Common Features of SFC

3.6.1 Displaying and Changing the Tag Number

Procedure

The tag number can be displayed or changed with the procedure described as follows. This example shows changing XXXXXXXX to TIC001.






Step	Description	SFC screen
1	<p>Press the  key.</p> <p>Options:</p> <ul style="list-style-type: none"> If you do not want to change the tag number, press the  key to end this procedure. If you want to change the tag number, proceed to step 2. 	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>ATT TAG NO. X X X X X X X X</p> </div>
2	<p>Press the , , , and  keys in this order.</p> <p>Note:</p> <ul style="list-style-type: none"> If a wrong key was pressed by mistake, move the cursor backward by pressing the  key and the  key, and then press the  key again. Then restart the input. 	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>ATT TAG NO. TIC</p> </div>
3	<p>Press keys , , , and  in this order.</p>	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>ATT TAG NO. TIC001</p> </div>
4	<p>Press the  key.</p> <p>Options:</p> <ul style="list-style-type: none"> Pressing the  key before pressing the  key will take you back to the previously set tag number. 	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>ATT TAG NO. WORKING</p> </div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-top: 5px;"> <p>ATT TAG NO. TIC001</p> </div>
5	<p>Press the  key and then the  key.</p> <p>Result:</p> <ul style="list-style-type: none"> Data has been stored in the transmitter. 	<div style="border: 1px solid black; padding: 5px; width: fit-content;"> <p>XXXXXXXX READY...</p> </div>

3. Operations and Settings

3.6.2 Displaying the Input Temperature Value

Procedure





To display the temperature value applied to the transmitter, use the following procedure:

Step	Description	SFC screen
1	Press the  and  keys. Result: <ul style="list-style-type: none">• In this example, the temperature input to the transmitter is 4°C.	
2	Press  key.	

3.6.3 Displaying the Transmitted Output (%)

Procedure

To display the temperature value applied to the transmitter, use the following procedure:

Step	Description	SFC screen
1	Press the  key. Result: <ul style="list-style-type: none">• In this example, the output is 50%.	
2	Press the  key.	

3.6.4 Displaying and Changing the Upper- and Lower-Range Values for Range Setting

Overview

Display or change the upper- and lower-range values for range setting and the temperature corresponding to the desired span by using the following procedure.

The following case is described here as an example:





- Lower Range Value: 0°C changed to 20°C
- Upper Range Value: 50°C changed to 55°C
- Span: 50°C changed to 75°C

Notes:

- Span is automatically determined by the difference between Upper- and Lower-Range Values. The span is displayed but cannot be changed directly.
- When changing the upper- and lower-range values for range setting, be sure to change the lower-Range Value first and then the Upper-Range Value.

Displaying the Set Range






















Displaying the Set Range

Step	Description	SFC screen
1	<ul style="list-style-type: none"> • Press the  key to display the Lower-Range Value. • Press the  key to display the Upper-Range Value. • Press the  key to display the span. 	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">LRV TIC001 0.0000 °C</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">URV TIC001 50.00 °C</div> <div style="border: 1px solid black; padding: 2px;">SPAN TIC001 50.00 °C</div>
2	<p>Options:</p> <ul style="list-style-type: none"> • If the displayed data does not need to be changed, press the  key to end the procedure. • If the displayed data needs to be changed, proceed to the procedure for changing the set range, which is described on the next page. 	<div style="border: 1px solid black; padding: 2px;">ATT TIC001 READY...</div>

3. Operations and Settings

Changing the Set Range

Changing the Set Range

Step	Description	SFC screen
1	To change the Lower Range Value, press the  key.	
2	Press the  and  keys.	
3	Press the  key. Result: • The Lower Range Value has been set to 20°C.	 
4	To change the Upper Range Value, press the  key.	
5	Press the  and  keys.	
6	Press the  key. Result: • The Upper Range Value has been set to 75°C.	 
7	Press the  and  keys. Result: • The data has been stored in the transmitter.	  

3.6.5 Displaying or Changing the Engineering Unit of Measurement

Engineering units available






Available engineering units of measurement are as follows. By pressing the key, you can display them in the order (or reverse order) shown.

- °C → °F → K → R → °C

(When the SFC uses the SI units by default)

Procedure

Display or change the engineering unit of measurement by using the following procedure. Here we describe the procedure for displaying the unit of measurement when °C is set.

Step	Description	SFC screen
1	Press the  key.	
2	If you want to use a different unit of measurement, press either the  key or  key repeatedly until the desired unit is displayed on the screen. Pressing the  key once will bring you back to the previous unit of measurement.	

3. Operations and Settings

3.6.6 Displaying or Changing the Damping Time Constant

Overview

In some cases, fluctuation of temperature causes the output from the transmitter to be unstable, depending on the conditions of the process. This makes the measured values difficult to read. By using a larger damping time constant, minute fluctuations in the measured values can be eliminated and the output can be stabilized.

Damping Time Constants available

The damping time constants that can be selected are listed as follows. Pressing the keys shown in the following procedure allows you to display each damping time constant in either the forward or backward direction. The actual response time will be delayed by about 0.4 seconds from the displayed value (time loss). The unit is “seconds.”













- 0.0 → 0.3 → 0.7 → 1.5 → 3.1 → 6.3 → 12.7 → 25.5 → 51.1 → 102.3
-

Procedure

Display or change the damping time constant by performing the following procedure. Here we describe the case in which 0.0 second is already set.

Note:

If the damping time constant needs to be changed, first select a value larger than the current set value and see how the output fluctuates.

Step	Description	SFC screen
1	Press the  key.	
2	<p>To change the damping time constant, press either the  key or  key repeatedly until the desired value appears on the screen.</p> <ul style="list-style-type: none"> When the  key is pressed, the message on the right is displayed. 	 
3	<p>First press the  key and then press the  key.</p> <p>Result: The data has been stored in the transmitter.</p>	  

3. Operations and Settings








3.6.7 Displaying the Software Version

Procedure

Check the software version by using the following procedure. Here we describe the case where the software version is 7.1.

SFC : 7.8

ATT :3.3

Step	Description	SFC screen
1	Press the  key.	
2	Press the  key. Results and options: <ul style="list-style-type: none">• If the SFC is not in communication with the transmitters, the message on the right is displayed.• If the SFC is in communication with the transmitter, the message on the right is displayed.	 
3	After checking the software version, press the  key.	

3.6.8 Printing Function (optional)







Types of Printing Functions

There are two kinds of printing functions operated using different keys:

- Maintenance printing
Using the maintenance printing function, you can print out the data stored in the transmitter (tag number, damping time constant, output range, temperature, output values, etc.).
- Action printing
Using the action printing function, you can print the responses of the transmitter each time you operate the SFC keys.

Recording Form Feed

Feed the recording form by using the following procedure.

Step	Description	SFC screen
1	<p>Press the  and  keys in this order.</p> <p>Result:</p> <ul style="list-style-type: none"> • Each time you press the  key, the recording form is fed by one line. 	
2	<p>Press the  key to clear the recording form feed function.</p> <p>Result:</p> <ul style="list-style-type: none"> • "PRINTER FEED" disappears and the display reverts to the initial screen. 	

3. Operations and Settings









3.6.9 Printing Function: Printing Out Data Stored in the Transmitter (Maintenance Printing)

When to Print Out Data Stored in the Transmitter

This printing function is used to print the tag number, damping time constant, output range, temperature, output value, results of self-diagnosis, etc. It can be used to record the settings of the transmitter and the status of functional problems.

Procedure

Use the following procedure:

Step	Description	SFC screen
1	Press the  key.	
2	Press the  key.	
3	Press the  key. Result: • Printing starts.	  

Example of Maintenance Printing

Example of data printing	Meaning
'99-06-03 04:51	Date, time
TAG No. TIC001	Tag number
FORM : LINEAR	Internal linearization setting
ANA/DE : DIGITAL XMTR	Output mode
PROM# : 2000000037	PROM number
SW VER : 3.3	Software version
DAMP : 0.0s	Damping time constant
SPAN : 100.00°C	Span
LRV : 0.0000°C	Measured value that can produce 0% output
URV : 100.00°C	Measured value that can produce 100% output
-LRV : -200.0°C	Minimum value of range setting
URL : 850.0°C	Maximum value of range setting
COLD JUNCTION : INTERNAL	Cold junction setting
FILTER : 60 Hz	Power source frequency filter (not used)
INPUT : 25.2°C	Input value
OUTPUT : 25.2%	Output value
SV : 29.2°C CJT	Internal cold junction temperature
RESULT OF SELF-DIAGNOSIS: OK	Results of self-diagnosis

Figure 3-4 Example of Maintenance Printing

3. Operations and Settings













3.6.10 Printing Function: Printing Responses Continuously (action printing)

When to Print Responses

The printing function is used to continuously print data about the responses of the transmitter each time the SFC keys are used. If data needs to be kept as a record, the action printing function (continuous printing) may be used.

Procedure

Execute the printing function by using the following procedure.
 Note: This procedure can be performed during measurement.

Step	Description	SFC screen
1	Press the  key.	
2	Press the  key and  keys in this order.	
3	Press the  key. Result: The following is printed.	
4	From this step onward, the responses of the transmitter will be printed each time the keys on the SFC are operated.	
5	To end this printing function, press the  and  keys in this order.	
6	Press the  key. Result: The message  is printed and printing ends.	

Example of Action Printing

Pressing the keys as shown at the left would produce the print output shown at the right.

Example of data printout

Key



```

ACTION PRINT * START
TAG NO. TIC001
'99-07-01 16:09

ATT          TAG NO.
ATT          TIC001

DAMP        TIC001
0.0         S

SPAN        TIC001
100°C      °F

URV          TIC001
0.0000°C   °F





*ACTION PRINT * END
    
```

Figure 3-5 Example of Action Printing

3. Operations and Settings








3.6.11 Changing from Analog Mode to Digital Mode

This section shows the procedure for changing the ThermoPLUS from analog mode to digital mode or digital mode to analog mode.

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 6 of Section 3.4.2.	<div style="border: 1px solid black; padding: 5px; width: fit-content;">TAG TIC001 READY...</div>
2	Press the  key and then press the  key. When the message to the right is displayed, press the  key.	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">SHFT-</div> <div style="border: 1px solid black; padding: 5px; width: fit-content;">ATT TIC001 CHANGE TO DIGITAL?</div>
3	Press the  key for verification purposes.	<div style="border: 1px solid black; padding: 5px; width: fit-content;">ATT TIC001 ARE YOU SURE?</div>
4	The procedure is completed when these messages are displayed.	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">ATT TIC001 WORKING...</div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">ATT DE TIC001 DE XMTR.</div> <div style="border: 1px solid black; padding: 5px; width: fit-content;">ATT DE TIC001 READY...</div>










3.7.1 Setting the Output Signal Mode

The following procedure can be used to check and set the output signal mode shown in Table 3-3, such as “Single Range,” “Dual Range,” and “Single Range w/SV”:

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 4 of Section 3.6.11 and that digital communication is enabled.	ATT DETIC001 READY...
2	Press the  key and then press the  key.	SHIFT- DE CONFIG Single Range
3	Press the  key to display a desired output signal mode.	DE CONFIG Single Range w/SV OR DE CONFIG DUAL RANGE
4	Press the  key.	DE CONFIG ENTERED IN SFC
5	Press the  or  key until the message to the right is displayed.	DE CONFIG DOWNLOAD DATA?
6	Press the  key.	DE CONFIG WORKING...
7	When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	ATT DE TIC001 READY...






3.7.2 Setting the Information Size Mode

The following procedure can be used to check and set the information size mode “4-byte output” or “6-byte output” shown in Table 3-3:

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 4 of Section 3.6.11 and that digital communication is enabled.	ATT DE TIC001 READY...
2	Press the  key and then press the  key.	SHIFT- DE CONFIG Single Range
3	Press the  or  key to display a desired signal mode.	DE CONFIG DE -6 Byte
4	Press the  key to display a desired output signal mode.	DE CONFIG DE -4 Byte
5	Press the  key.	DE CONFIG ENTERED IN SFC
6	Press the  or  key until the message to the right is displayed.	DE CONFIG DOWNLOAD DATA?
7	Press the  key.	DE CONFIG WORKING...
8	When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	ATT DE TIC001 READY...





3.7.3 Setting the Fail-Safe Mode

The following procedure can be used to check and set the fail safe mode shown in Table 3-3:

Step	Description	SFC screen
1	Make sure that the ThermoPLUS is in the ready state described previously in step 6 of Section 3.4.2 and that digital communication is enabled..	<div style="border: 1px solid black; padding: 5px; width: fit-content;">ATT DETIC001 READY...</div>
2	Press the  key and then press the  key.	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">SHIFT-</div> <div style="border: 1px solid black; padding: 5px; width: fit-content;">DE CONFIG Single Range</div>
3	Press the  or  key to display a desired signal mode.	<div style="border: 1px solid black; padding: 5px; width: fit-content;">DE CONFIG F/S = B/O Hi</div>
4	Press the  key to display a desired output signal mode.	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">DE CONFIG F/S = B/O Lo</div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">DE CONFIG F/S = B/O LKG</div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">DE CONFIG F/S = FSO B/O Lo</div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">DE CONFIG F/S = FSO B/O Hi</div> <div style="border: 1px solid black; padding: 5px; width: fit-content;">DE CONFIG F/S = FSO, LKG</div>

Continued

Continued

Step	Description	SFC screen
5	Press the  key.	<div data-bbox="1216 436 1464 512" style="border: 1px solid black; padding: 5px;"> DE CONFIG ENTERED IN SFC </div>
6	Press the  or  key until the message to the right is displayed.	<div data-bbox="1216 615 1464 690" style="border: 1px solid black; padding: 5px;"> DE CONFIG DOWNLOAD DATA? </div>
7	Press the  key.	<div data-bbox="1216 829 1464 905" style="border: 1px solid black; padding: 5px;"> DE CONFIG WORKING... </div>
8	When this message is displayed, the ThermoPLUS can be disconnected from the SFC.	<div data-bbox="1216 1060 1464 1136" style="border: 1px solid black; padding: 5px;"> ATT DE TIC001 READY... </div>

3.8 Adjusting the Output Current

3.8.1 Setting the Constant Current Mode

Overview



















This product can be set so it will output a constant current in the range of 4 mA (0%) to 20 mA (100%). The setting of the constant current is performed in the output mode. This function is convenient for executing a loop check.

Caution

Make sure that the output mode will be canceled after the output is set. Check to ensure that the output is equivalent to the process temperature after cancellation of the output mode.

Procedure

Set the constant current source mode by performing the following procedure. In this example, the output is fixed at 50% (12 mA).

Step	Description	SFC screen
Setting		
1	Press the  key. Result • The current output is displayed.	 
2	Press the numeric keys  and  in this order.	
3	Press the  key Result • This product outputs 12 mA (50%).	 
Cancelling		
4	Press the  key. Result: • The current output is displayed.	 
5	Press the  key. Result: • The output mode has been canceled.	 
Checking		
6	Press the  key. Result: • The current output is displayed.	 







3.8.2 Canceling the Constant Current Mode

Procedure

Cancel the output mode by using the following procedure.

Note:

















Check to ensure that the output is equivalent to the process temperature after cancellation of the output mode.

Step	Description	SFC screen
Canceling		
1	Press the  key. Result: • The current output is displayed.	
2	Press the  key. Result: • The output mode has been canceled.	
Checking		
3	Press the  key. Result: • The current output is displayed.	

3.8.3 Calibrating the Output Signal



Procedure

Calibrate the output signal by using the following procedure. First, set the output to 0% (100%) and then calibrate it so that the current on an amperemeter reads 4 mA (20 mA).

Step	Description	SFC screen
1	Press the  key. Result: • The current output is displayed on the screen.	 
2	Press the  key. (If the output is set at 100%, press the  ,  AND  keys.)	
3	Press the  key. Result • The transmitter is now in the 4 mA (20 mA) constant current source mode.	 
4	Check the amperemeter to make sure that the reading on the amperemeter is 4 mA (20 mA).	
5	Press the  key.	 
6	Press the  key. Results and options: • If the reading on the amperemeter is 4 mA (20 mA), proceed to step 9. • If the reading on the amperemeter is less than 4 mA (20 mA), proceed to step 7. • If the reading on the amperemeter is greater 4 mA (20 mA), proceed to step 8.	

Continued












Continued

Step	Description	SFC screen
7	<p>Press the  key.</p> <ul style="list-style-type: none"> • After pressing the key once, check the reading on the amperemeter. • Press the key repeatedly until the reading becomes 4 mA (20 mA). • When the reading becomes 4 mA (20 mA), proceed to step 9. 	<div data-bbox="1219 426 1463 506" style="border: 1px solid black; padding: 2px;"> OUTPUT TIC001 WORKING... </div> <div data-bbox="1219 520 1463 600" style="border: 1px solid black; padding: 2px;"> OUTPUT TIC001 INCREASED 4mA # </div> <div data-bbox="1219 625 1463 705" style="border: 1px solid black; padding: 2px;"> OUTPUT TIC001 CORRECT DAC DER # </div>
8	<p>Press the  key.</p> <ul style="list-style-type: none"> • After pressing the key once, check the reading on the amperemeter. • Press the key repeatedly until the reading becomes 4 mA (20 mA). 	<div data-bbox="1219 762 1463 842" style="border: 1px solid black; padding: 2px;"> OUTPUT TIC001 WORKING... </div> <div data-bbox="1219 867 1463 947" style="border: 1px solid black; padding: 2px;"> OUTPUT TIC001 INCREASED 4mA # </div> <div data-bbox="1219 972 1463 1052" style="border: 1px solid black; padding: 2px;"> OUTPUT TIC001 CORRECT DAC ZER# </div>
9	<p>Go to “Storing Calibrated Values and Canceling the Constant Current Source Mode” on the next page.</p>	

3.8.4 Storing the Calibrated Values and Canceling the Constant Current Source Mode

Procedure

Store calibrated values and cancel the constant current source mode by using the following procedure.

Step	Description	SFC screen
1	Press the  key.	
2	Press the  and  keys. Result: • Data storage has been completed.	 
3	Press the  key. Result: • The message on the right is displayed, indicating that the current output is 0% (100%).	
4	Press the  key. Result: • The # mark disappears, indicating that the constant current source mode has been canceled.	 

3.9 Calibrating the Set Range by Inputting the Actual Temperature

3.9.1 Overview

Overview

This section describes how to calibrate upper- and lower-limit values for the set range by inputting a reference temperature into the transmitter using the SFC.

Calibrate the lower-limit value first and then the upper-limit value.

Calibration Devices

The calibration devices described as follows are usually required:

- Reference temperature generator: a generator capable of producing temperature over a range of measurement close to that of the transmitter to be tested
- Accuracy: $\pm 0.05\%FS$ or $\pm 0.1\%$ (whichever is larger)
- Power supply: 24 V DC
- Standard resistor: $250 \Omega \pm 0.005\%$
- Voltmeter: Digital voltmeter (10V DC range) with an accuracy of $\pm 0.02\%$ rdg + 1dgt
- SFC

Requirements for Calibration

CAUTION:

When conducting actual-temperature calibration, the following requirements must be met:

- The calibration must be conducted in a testing laboratory where there is no wind.
- The standard temperature is $23^{\circ}C$ ($73^{\circ}F$) and the standard humidity is 65%. (Room temperatures from 15 to $35^{\circ}C$ (50 to $95^{\circ}F$) and room humidity from 45% to 75% are acceptable if measurement at that temperature and humidity will not influence the results of measurement.)
- It is best if the accuracy of the measuring instruments be four times greater than that of the transmitter.

Assembling the Calibration Devices

The calibration devices are to be assembled as follows:
















Figure 6-6 Wiring and Piping for the Calibration Devices

3.9.2 Calibrating the Lower-Range Value

Procedure













Calibrate the lower-limit value of actual temperature using the following procedure. This procedure starts at the point when normal communication between the SFC and the transmitter has been established.

Step	Description	SFC screen
1	Press the  key	
2	Apply temperature so that the temperature gauge on the reference temperature calibration equipment generator reads 0°C. Press the  key	
3	<ul style="list-style-type: none"> The Lower Range Value that the transmitter has stored in memory is displayed. In this example, the lower-limit value is 0.00°C. 	
4	Press the  key.	
5	Press the  key twice. Result: <ul style="list-style-type: none"> The Lower Range Value is calibrated tot the current Lower Range temperature of this product. 	  
6	Press the  key. <ul style="list-style-type: none"> The message on the right is displayed, allowing confirmation of the Lower Range Value stored in the transmitter's memory. 	

3.9.3 Calibrating the Upper-limit Value

Procedure




Calibrate the upper-limit value of actual temperature using the following procedure:

Step	Description	SFC screen
1	Press the  key.	
2	Apply temperature so that the temperature gauge on the reference temperature generator reads 100°C.	
3	Press the  key. <ul style="list-style-type: none"> The Upper Range Value that the transmitter has stored in memory appears on the screen. (In this procedure, 100°C is defined as the Upper Range Value.) 	
4	Press the  key.	
5	Press the  key twice. Result: <ul style="list-style-type: none"> The Upper Range Value is calibrated to the current Upper Range temperature of this product. 	  
6	Press the  key. <ul style="list-style-type: none"> The message on the right is displayed, allowing confirmation of the Upper Range Value stored in the transmitter's memory. 	

3.9.4 Resetting Calibrated Data

Procedure

Use the following procedure to make calibrated or entered values revert to the original values in effect before calibration or data entry:

Step	Description	SFC screen
1	Press the keys  and  in this order.	<div data-bbox="1127 527 1373 604" style="border: 1px solid black; padding: 2px; text-align: center;">SHIFT</div> <div data-bbox="1127 621 1373 695" style="border: 1px solid black; padding: 2px;">ATT TIC001 RESET CORRECT?</div>
2	Press the  key. Result: <ul style="list-style-type: none"> About 2 seconds later, the message on the right is displayed, and the calibrated data reverts to the data stored at the time of the delivery of the transmitter to the customer. 	<div data-bbox="1127 737 1373 810" style="border: 1px solid black; padding: 2px;">ATT TIC001 WORKING</div> <div data-bbox="1127 837 1373 911" style="border: 1px solid black; padding: 2px;">ATT TIC001 CORRECTS RESET#</div> <div data-bbox="1127 938 1373 1012" style="border: 1px solid black; padding: 2px;">ATT TIC001 READY... #</div>









3.10 Setting Lower-Range Value as Actual Temperature

Overview

“#” mark appears when the input value is reverted to the default setting. By following the steps described below, “#” mark will disappear. Setting Lower Range Value can be done by using the actual temperature. (Refer to 3.9 “Calibrating the Set Range by Inputting the Actual Temperature.”)

Setting LRV as Actual Temperature

Follow the steps below:

Step	Description	SFC screen
1	Set the actual temperature input as LRV.	
2	Press  key.	
3	Press  key.	
4	Press  key. Result: • LRV is stored and displayed.	 

4. Troubleshooting

Maintenance Precautions

WARNING

- While this product is in operation in an explosion-proof area, opening the cover of the equipment may result in an explosion. Keep the cover closed during operation.
- This product is manufactured and shipped under Yamatake's rigorous quality control system. Do not modify this product. Doing so will cause critical damage to the product.

Maintenance

Check the following components on a periodic basis:

- Has the case, cover, or grounding cable been damaged?
- Are the grounding cable, cover, or cover-detent screws loose?
- Are the terminal screws loose?
- Is there any deterioration in the O-rings fitted to the set-screws holding the cover in position?

Troubleshooting

If this product does not function or if it malfunctions, releases gas or liquid from this product, leave it open to the atmosphere, and check the following items:

- Are there any loose or broken wires?
- Are the readings correct for power source voltage and load resistance?
- In case the ThermoPLUS is indicating "Burnout" condition, or it does not function, first conduct the status diagnosis using the SFC. (See the following pages 4.1 "Troubleshooting by SFC.")
- ThermoPLUS with LCD will display the abnormal conditions on the window. It, however, does not display the nature of erroneous condition, so use SFC to conduct the status diagnosis.

4. Troubleshooting

4.1 Troubleshooting by SFC





4.1.1 Troubleshooting and Verification of Normal Functioning

Verification of Normal Functioning and Self-Diagnosis

Using the SFC, you can verify that the transmitter is operating normally. If the transmitter has functional trouble, follow the self-diagnostic messages provided by the SFC. If abnormal conditions are encountered in the transmitter, in the process, in the SFC or in the communication system during measurement, follow self-diagnostic messages.

Procedure for Verifying Normal Functioning








When verifying normal functioning, connect the SFC to the product and perform the following procedure.

Step	Description	SFC screen
1	<p>Press the  key.</p> <p>Results and options:</p> <ul style="list-style-type: none">• When “STATUS CHECK=OK” message appears, the process of verifying normal functioning ends.• When a message other than “STATUS CHECK=OK” appears, take appropriate action by referring to the instructions given on the following pages. Proceed to step 2.	
2	<p>Results and options:</p> <ul style="list-style-type: none">• Take appropriate action by referring to the messages given on the following pages.• If there is more than one message, each individual message is displayed for 2 seconds.	 

4.1.2 If Abnormal Conditions are Encountered during Communication

Message and Action


If the “CRITICAL STATUS” message is displayed during communication, take the following action.

Message	Action
<div style="border: 1px solid black; padding: 5px; width: fit-content;">ATT TIC001 CRITICAL STATUS</div> <div style="border: 1px solid black; padding: 5px; width: fit-content;">PRESENT STATUS</div>	<p>Press the  key.</p> <p>Deal with the conditions encountered by following the displayed messages.</p> <p>Note:</p> <ul style="list-style-type: none"> • Even if the “CRITICAL STATUS” message is displayed, three keys ,  and  are still operable. • After taking action, press the  key to check that the “SELF-DIAGNOSIS RESULT OK” message is displayed.
<div style="border: 1px solid black; padding: 5px; width: fit-content;">:</div>	<p>The battery power is becoming low. Follow the instructions given in the SFC operation manual (CM2-SFC100-2001).</p>
<div style="border: 1px solid black; padding: 5px; width: fit-content;">:</div>	<ul style="list-style-type: none"> • Press the  key. <p>Deal with conditions encountered by following the displayed messages.</p> <p>If minor trouble is encountered:</p> <ul style="list-style-type: none"> • When trouble has been eliminated, the # mark will disappear. • When the # mark disappears, press the  key to display the “SELF-DIAGNOSIS RESULT OK” message.



4. Troubleshooting

4.1.3 Self-diagnostic Messages

Message

When abnormal conditions are encountered, press the  key to display a self-diagnostic message. The meaning of this message and the action to take are as follows.

If the abnormal condition seems to have occurred in the process, SFC or communication system:




Message	Description, cause	Action
	<ul style="list-style-type: none">• Receiving instrument does not respond.	<ul style="list-style-type: none">• Perform the procedure for starting communication again.• Press the  key and look at the message.• Check the connection of the loop and SFC.

If abnormal conditions seem to have occurred in the SFC or a communication system:

Message	Description, cause	Action
FAILED COMM CHK	Preface to a diagnostic message	
HI RES / LO VOLT	<ul style="list-style-type: none"> • Extra-high loop resistance • Extra-low power-supply voltage 	Adjust loop resistance. <ul style="list-style-type: none"> • Increase the voltage of the power supply.
ILLEGAL RESPONSE	Improper communication	Check the connection, wiring and power supplies.
LOW LOOP RES	Extra-low loop resistance value	Adjust the resistance value.
PRINTER FAIL!	Printer failure	Contact the sales representative or manufacturer shown in the back of the operation manual.
SFC FAULT	SFC Fault	<ul style="list-style-type: none"> • Perform the procedure for starting communication again. • If the same message is displayed, contact the supplier or manufacturer shown at the back of the operation manual.

4. Troubleshooting

If an operational mistake seems to have been made:

Message	Description, cause	Action
CORRECT LRV?	What value was entered to set the range to 0%?	Verify the entered value. If an incorrect value was entered, correct it.
CORRECT URV?	What value was entered to set the range to 100%?	Verify the entered value. If an incorrect value was entered, correct it.
CORRECT RESET #	Calibration must be performed again.	Calibrate the upper- and Lower-Range Values of the range.
ENTRY>SENS RNG	The set value is 1.0 times the Upper-Range Value of the range shown on a pressure gauge	After checking the value by pressing the  key, enter the correct value.
EXCESS SPAN COR#	Excessive span calibration	Calibrate the Upper-Range Value of the range.
EXCESS ZERO COR#	Excessive zero calibration	Calibrate the Lower-Range Value of the range.
EXCESSIVE OUTPUT	Output value required in the constant current source mode is greater than output range; (1.25% to 105%.)	After checking the value by pressing the  key, enter the correct value.
INVALID REQUEST	Operational mistake during the operation of SFC	Check the SFC operation procedure.
INVALID KEY ENTRY	<ul style="list-style-type: none"> Invalid key entry Invalid sequence of key entry 	After checking the value by pressing the  key, enter the correct value.
NOT SUPPORT	Do not use the key(s) that were pressed.	Press the correct keys.

4.1.4 If an Error Has Occurred on the ThermoPLUS Transmitter

This section describes troubleshooting using the ThermoPLUS's built-in self-diagnostic feature. The two error modes employed by the ThermoPLUS are the minor error mode and the serious error mode. The remedy depends on the error mode; therefore, be sure to check the status and take an appropriate action.

1. Minor Errors

This error mode indicates that a minor error such as an out-of-range has occurred. With the specifications for the unit with a built-in LCD, the temperature displays blink at each second. Table 4.1 lists the error messages that are displayed in the minor error mode along with the action that should be taken by the user. Use this table as a reference in the event of an error.

Table 4-1 Messages for minor errors

Cause of error	Action
I/P OUT OF SPEC	A minor error was detected because an entered value was beyond the upper-limit or lower-limit value for the sensor in use. The sensor must be replaced with an appropriate one.
AMB TEMP HI/LO	The cold junction temperature fell beyond the operating temperature range for the equipment (-40 to 85°C / -40 to 185°F). The equipment's ambient temperature must be reduced by using a screen or by cooling air with air purge or by changing to the separation type.
IN OUTPUT MODE	OUTPUT MODE for supplying constant current is in effect. This setting must be canceled using the OUTPUT and CLR keys.

2. Serious Errors

This error mode indicates that an internal error has occurred on the ThermoPLUS or that some error has occurred on the temperature sensor. With the specifications containing a built-in LCD, "Err" is displayed and the output depends on the burnout setting. The details of the error can be output as error messages using the SFC. Table 4.2 shows the error message that is displayed in this error mode along with the action that should be taken by the user. Use this table as a reference in the event of an error.

Table 4-2 Messages for serious errors

Error message	Nature of error	Action
T/C BREAK	Disconnection occurred on the sensor.	Check the wiring on the sensor. Replace thermocouples or compensation lead wire.

4.2 FAQs (Frequently Asked Questions)

This section presents frequently asked questions and the answers to troubleshooting problems.

Table 4.3 FAQs

Condition	Suggested Actions
There is no output.	Check the loop again. Is the supply voltage correct? Is the load resistance correct? Was AC 100 V applied by mistake? Are correct connection terminals used?
Communication cannot be established with the SFC.	Is the ThermoPLUS's power switch on? Is the supply voltage correct? Is the load resistance correct? Is the SFC's power switch on? Is a correct terminal used to connect the SFC? Is the loop correct?
When the SFC was used for communication, "STT" was displayed, not "ATT."	This ThermoPLUS belongs to Yamatake's conventional model STT; therefore, "STT" is the correct display on the SFC. Also for older version's SFC, "SFT" may be displayed; no need to be alarmed.
Output is not stable.	Is there any sensor error? Is the sensor type or range setting for the sensor correct? Was an attempt made to use analog specifications as digital specifications by mistake? Is the equipment used within the correct specifications, such as supply voltage and ambient temperature? Is there any external noise added electrically?
Output response is slow.	Is there any sensor error? Is an appropriate dumping time constant used? Is sensor protection pipe's delay taken into account?
Output is too high (low).	Is there any sensor error? Is the sensor type or range setting for the sensor correct?

4.3 Contact Information in the Event of an Error

If an error cannot be resolved by the troubleshooting procedures presented in this manual, contact your Yamatake's sales representative or Yamatake customer service. When you contact us, please provide the following information:

Investigation Item Entry Sheet

____/____/____
 Month Date Year

Your company name: _____ Office: _____

Your name:Contact: _____

Name of the store: _____ Person in charge: _____

Manufactured date: _____ Process number: _____

Format: _____

Setting:

Type of sensor: _____
 Sensor maker: _____
 Range: _____

Problem:

5. Maintenance

5.1 Spare Parts:

Table 5-1 lists the spare parts that are available for your ThermoPLUS Transmitter. Contact your Yamatake representative, distributor or Yamatake customer service for purchase. When ordering spare parts, please provide us with the part name and part number listed in Table 5-1 along with desired quantities.

Table 5-1 List of spare parts

#	Name	Part number	Quantity used per transmittere	Resale Units
1	Case cover (w/ O-ring)	80370406-001	1	1
2	O-ring for the case cover	80020935-842	1	10
1s	Cover (w / O-ring) standard finish	80345533-001	1	1
1a	Cover (w / O-ring) corrosion resistant finish	80345533-002	1	1
1b	Cover (w / O-ring) corrosion proof finish	80345533-003	1	1
3	Pressure-tight packing cable ground	80370411-001	2	1
4	Elbow		2	1
5	Bracket kit	80370404-002	1	1

5.2 Disassembly and Assembly

The inside of your ThermoPLUS cannot be disassembled. The maintenance the user should perform is the replacement of the O-ring that is used for the ThermoPLUS's case cover.

The parts list contains several parts that can be re-ordered in case they are lost during installation or during periodic maintenance when the pressure-tight packing cable ground may be removed.




Fig 5-1 Exploded view

6. Types of Installation

6.1 Example of Sensor Installed Separately (Single input from a temperature sensor installed on pipe)




Figure 6-1

6.2 Example of Sensor Connected Directly (Example of Installation on tank walls)




Figure 6-2

6. Types of Installation

MEMO

Document Number: CM2-ATT100-2001

Document Name: ThermoPLUS Smart Temperature
Transmitter (Remote Type)
Model ATT60/70 Operation Manual

Date: Mar., 2000
Oct., 2000 (Rev. 2)
Issued/Edited by: Yamatake Corporation

YAMATAKE