

Rosemount 3051S Series Scalable Pressure, Flow, and Level Solutions



Rosemount 3051S Series

Scalable Pressure, Flow, and Level Solutions

NOTICE

Read this manual before working with the product. For personal and system safety, and for optimum product performance, make sure you thoroughly understand the contents before installing, using, or maintaining this product.

For technical assistance, contacts are listed below:

Customer Central

Technical support, quoting, and order-related questions.

United States - 1-800-999-9307 (7:00 am to 7:00 pm CST)

Asia Pacific- 65 777 8211

Europe/ Middle East/ Africa - 49 (8153) 9390

North American Response Center

Equipment service needs.

1-800-654-7768 (24 hours—includes Canada)

Outside of these areas, contact your local Rosemount® representative.

⚠ CAUTION

The products described in this document are NOT designed for nuclear-qualified applications. Using non-nuclear qualified products in applications that require nuclear-qualified hardware or products may cause inaccurate readings.

For information on Rosemount nuclear-qualified products, contact your local Rosemount Sales Representative.

Rosemount 3051S Pressure Transmitters may be protected by one or more of the following U.S. Patent Nos. 4,370,890; 4,466,290; 4,612,812; 4,791,352; 4,798,089; 4,818,994; 4,833,922; 4,866,435; 4,926,340; 4,988,990; and 5,028,746. Mexico Patentado No. 154,961. May depend on model. Other foreign patents issued and pending.

Table of Contents

SECTION 1	
Introduction	
	Using This Manual 1-1
	Models Covered 1-2
	Service Support 1-3
SECTION 2	
Installation	
	Overview 2-1
	Safety Messages 2-1
	Warnings 2-1
	Considerations 2-2
	General 2-2
	Mechanical 2-2
	Draft Range 2-3
	Environmental 2-3
	Installation Procedures 2-5
	Mount the Transmitter 2-6
	Process Connections 2-11
	Consider Housing Rotation 2-12
	Configure Security and Alarm 2-13
	Connect Wiring and Power Up 2-15
	Remote Display Wiring and Power Up 2-17
	Quick Connect Wiring 2-19
	Conduit Electrical Connector Wiring (Option GE or GM) 2-19
	Grounding 2-20
	Installing the LCD Display 2-20
	Rosemount 305, 306 and 304 Manifolds 2-21
	Rosemount 305 Integral Manifold Installation Procedure 2-21
	Rosemount 306 In-Line Manifold Installation Procedure 2-22
	Rosemount 304 Conventional Manifold Installation Procedure 2-22
	Manifold Operation 2-23
SECTION 3	
Configuration	
	Overview 3-1
	Safety Messages 3-1
	Warnings 3-1
	Commissioning on the bench With HART 3-2
	Setting the Loop to Manual 3-2
	Wiring Diagrams 3-3
	Review Configuration Data 3-4
	HART Communicator 3-5
	Menu Tree 3-5
	Fast Key Sequence 3-6
	Check Output 3-7
	Process Variables 3-7
	Sensor Temperature 3-7
	Basic Setup 3-8
	Set Process Variable Units 3-8
	Set Output (Transfer function) 3-8
	Rerange 3-9
	Damping 3-11
	LCD Display 3-11

Rosemount 3051S Series

Detailed Setup	3-12
Failure Mode Alarm and Saturation	3-12
Alarm and Saturation Level Configuration	3-13
Alarm and Saturation Levels for Burst Mode	3-14
Alarm and Saturation Values for Multidrop Mode	3-14
Alarm Level Verification	3-14
Process Alerts	3-15
Scaled Variable Configuration	3-16
Re-mapping	3-19
Sensor Temperature Unit	3-20
Diagnostics and Service	3-20
Transmitter Test	3-20
Loop Test	3-21
Advanced Functions for HART Protocol	3-22
Saving, Recalling, and Cloning Configuration Data	3-22
Burst Mode	3-24
Multidrop Communication	3-25
Changing a Transmitter Address	3-26
Communicating with a Multidropped Transmitter	3-26
Polling a Multidropped Transmitter	3-26

SECTION 4 **Operation and** **Maintenance**

Overview	4-1
Calibration for HART Protocol	4-1
Calibration Overview	4-2
Determining Calibration Frequency	4-4
Choosing a Trim Procedure	4-5
Sensor Trim Overview	4-5
Zero Trim	4-6
Sensor Trim	4-6
Recall Factory Trim—Sensor Trim	4-7
Analog Output Trim	4-7
Digital-to-Analog Trim	4-8
Digital-to-Analog Trim Using Other Scale	4-9
Recall Factory Trim—Analog Output	4-10
Compensating for Line Pressure	4-10
Diagnostic Messages	4-12
Field Upgrades	4-14
LABELING	4-14
Upgrading Electronics	4-14

SECTION 5 **Troubleshooting**

Overview	5-1
Safety Messages	5-1
Warnings	5-1
Disassembly Procedures	5-3
Remove from Service	5-3
Remove Terminal Block	5-3
Remove Interface Assembly	5-4
Remove the SuperModule from the Housing	5-4
Reassembly Procedures	5-5
Attach the SuperModule to the PlantWeb or Junction Box Housing	5-5
Install Interface Assembly in the PlantWeb Housing	5-5
Install the Terminal Block	5-5
Reassemble the Process Flange	5-6

SECTION 6
Safety Instrumented
Systems

Safety Messages 6-1
 Warnings 6-1
Certification 6-2
3051S Safety Certified Identification 6-2
Installation 6-2
Commissioning 6-3
 Damping 6-3
 Alarm and Saturation Levels 6-3
Operation and Maintenance 6-4
 Proof Test 6-4
 Inspection 6-5
Specifications 6-5
 Failure Rate Data 6-5
 Product Life 6-5
Spare Parts 6-5

SECTION 7
Advanced HART
Diagnostics

Overview 7-1
HART Diagnostic User Interface 7-2
Statistical Process Monitoring 7-3
 Introduction 7-3
 Overview 7-4
 Assigning Statistical Values to Outputs 7-7
 SPM Configuration 7-8
 SPM Operation 7-15
 Troubleshooting the SPM Diagnostic 7-18
Variable Logging 7-19
 Overview 7-19
 Pressure Event Log 7-19
 Temperature Event Log 7-20
Advanced Process Alerts 7-21
 Overview 7-21
Rosemount 333 Hart Tri-Loop Configuration 7-24
 Overview 7-24
 Installation and Commissioning 7-24
Other Information 7-25
 Digital Trim with non-DD based communicators 7-25

APPENDIX A
Specifications and
Reference Data

Specifications A-1
 Performance Specifications A-1
 Functional Specifications A-6
 Physical Specifications A-12
Dimensional Drawings A-16
Ordering Information A-25
 Rosemount 3051S Series Coplanar A-25
 Rosemount 3051S Series In-Line A-29
 Rosemount 3051S Series Liquid Level A-32
 Seal Options (page A-33—A-34) A-33
 Transmitter Options continued from page A-32 A-34
 Rosemount 300S Series Housing “Kit” A-37
Exploded view Diagram A-39
Spare Parts A-40

Rosemount 3051S Series

APPENDIX B
Product Certifications

Approved Manufacturing Locations	B-1
European Directive Information	B-1
Ordinary Location Certification for FM	B-1
Hazardous Locations Certifications	B-1
Installation Drawings	B-6
Factory Mutual (FM)	B-6
Canadian Standards Association (CSA)	B-23
KEMA	B-36
European ATEX Directive Information	B-39
CENELEC/BASEEFA	B-39

Section 1 Introduction

Using This Manual	page 1-1
Models Covered	page 1-2
Service Support	page 1-3

USING THIS MANUAL

The sections in this manual provides information on installing, operating, and maintaining the Rosemount 3051S pressure transmitter with HART® protocol. The sections are organized as follows:

- **Section 2: Installation** contains mechanical and electrical installation instructions, and field upgrade options.
- **Section 3: Configuration** provides instruction on commissioning and operating 3051S transmitters. Information on software functions, configuration parameters, and online variables is also included.
- **Section 4: Operation and Maintenance** contains operation and maintenance techniques.
- **Section 5: Troubleshooting** provides troubleshooting techniques for the most common operating problems.
- **Section 6: Safety Instrumented Systems** contains identification, commissioning, maintenance, and operations information for the 3051S SIS Safety Transmitter.
- **Section 7: Advanced HART Diagnostics** contains procedures for installation, configuration, and operation of the 3051S HART Diagnostics option.
- **Appendix A: Specifications and Reference Data** supplies reference and specification data, as well as ordering information.
- **Appendix B: Product Certifications** contains intrinsic safety approval information, European ATEX directive information, and approval drawings.

For Rosemount 3051S with FOUNDATION fieldbus, see Manual 00809-0200-4801.

Rosemount 3051S Series

MODELS COVERED

The following 3051S pressure transmitters and the Rosemount 300S Housing Kit are covered in this manual.

Rosemount 3051S Coplanar™ Pressure Transmitter

Performance Class	Measurement Type		
	Differential	Gage	Absolute
Ultra	X	X	X
Ultra for Flow	X	–	–
Classic	X	X	X

Rosemount 3051S In-Line Pressure Transmitter

Performance Class	Measurement Type		
	Differential	Gage	Absolute
Ultra	–	X	X
Classic	–	X	X

Rosemount 3051S Liquid Level Pressure Transmitter

Performance Class	Measurement Type		
	Differential	Gage	Absolute
Classic	X	X	X

Rosemount 3051S SIS Safety Certified Transmitter

Performance Class	Measurement Type		
	Differential	Gage	Absolute
Classic	X	X	X

Rosemount 3051S HART Diagnostics Transmitter

Performance Class	Measurement Type		
	Differential	Gage	Absolute
Ultra	X	X	X
Ultra for Flow	X	–	–
Classic	X	X	X

Rosemount 300S Scalable Housing Kits

Kits are available for all models of 3051S pressure transmitters.

SERVICE SUPPORT

To expedite the return process outside of the United States, contact the nearest Rosemount representative.

Within the United States, call the Emerson Process Management Instrument and Valves Response Center using the 1-800-654-RSMT (7768) toll-free number. This center, available 24 hours a day, will assist you with any needed information or materials.

The center will ask for product model and serial numbers, and will provide a Return Material Authorization (RMA) number. The center will also ask for the process material to which the product was last exposed.

⚠ CAUTION

Individuals who handle products exposed to a hazardous substance can avoid injury if they are informed of and understand the hazard. If the product being returned was exposed to a hazardous substance as defined by OSHA, a copy of the required Material Safety Data Sheet (MSDS) for each hazardous substance identified must be included with the returned goods.

Emerson Process Management Instrument and Valves Response Center representatives will explain the additional information and procedures necessary to return goods exposed to hazardous substances.

Rosemount 3051S Series

Reference Manual
00809-0100-4801, Rev CB
January 2007

Section 2 Installation


Overview	page 2-1
Safety Messages	page 2-1
Considerations	page 2-2
Installation Procedures	page 2-5
Installing the LCD Display	page 2-20
Rosemount 305, 306 and 304 Manifolds	page 2-21

OVERVIEW


The information in this section covers installation considerations for HART protocol. A Quick Installation Guide for HART protocol (document number 00825-0100-4801) is shipped with every transmitter to describe basic installation, wiring, and startup procedures. Dimensional drawings for each Rosemount 3051S variation and mounting configuration are included in Appendix A: Specifications and Reference Data.

Instructions for performing configuration functions are given for HART Communicator version 1.8 and AMS version 7.0, with the exception of Section 7 Advanced HART Diagnostics. For convenience, HART Communicator fast key sequences are labeled “Fast Keys” for each software function below the appropriate headings.

SAFETY MESSAGES

Procedures and instructions in this section may require special precautions to ensure the safety of the personnel performing the operation. Information that raises potential safety issues is indicated with a warning symbol (). Refer to the following safety messages before performing an operation preceded by this symbol.

Warnings

 WARNING
<p>Explosions can result in death or serious injury.</p> <ul style="list-style-type: none">• Do not remove the transmitter covers in explosive environments when the circuit is live.• Fully engage both transmitter covers to meet explosion-proof requirements.• Before connecting a communicator in an explosive atmosphere, make sure the instruments in the loop are installed in accordance with intrinsically safe or non-incendive field wiring practices.• Verify that the operating atmosphere of the transmitter is consistent with the appropriate hazardous locations certifications.

WARNING

Electrical shock can result in death or serious injury.

- Avoid contact with the leads and terminals.

Process leaks could result in death or serious injury.

- Install and tighten all four flange bolts before applying pressure.
- Do not attempt to loosen or remove flange bolts while the transmitter is in service.

Replacement equipment or spare parts not approved by Rosemount Inc. for use as spare parts could reduce the pressure retaining capabilities of the transmitter and may render the instrument dangerous.

- Use only bolts supplied or sold by Rosemount Inc. as spare parts.

Improper assembly of manifolds to traditional flange can damage SuperModule™ Platform.

- For safe assembly of manifold to traditional flange, bolts must break back plane of flange web (i.e., bolt hole) but must not contact module housing.

Upper and lower unit labeling must match exactly to maintain hazardous location approvals.

- When upgrading, it is imperative that approval codes match between the SuperModule and the electronics housing.

CONSIDERATIONS

General

Measurement performance depends upon proper installation of the transmitter and impulse piping. Mount the transmitter close to the process and use minimum piping to achieve best performance. Also, consider the need for easy access, personnel safety, practical field calibration, and a suitable transmitter environment. Install the transmitter to minimize vibration, shock, and temperature fluctuation.

For a Rosemount 3051S transmitter assembled to a Rosemount 753R Web-Based Monitoring indicator, detailed 753R installation instructions can be found in the 753R Manual 00809-0100-4379.

IMPORTANT

Install the enclosed pipe plug (found in the box) in the unused conduit opening. For straight threads, a minimum of 6 threads must be engaged. For tapered threads, install the plug wrench-tight.

For material compatibility considerations, see document number 00816-0100-3045 on www.rosemount.com.

Mechanical

NOTE

For steam service or for applications with process temperatures greater than the limits of the transmitter, do not blow down impulse piping through the transmitter. Flush lines with the blocking valves closed and refill lines with water before resuming measurement.

NOTE

When the transmitter is mounted on its side, position the Coplanar flange to ensure proper venting or draining. Mount the flange as shown in Figure 2-3 on page 2-10, keeping drain/vent connections on the bottom for gas service and on the top for liquid service.

Draft Range

Installation

For the 3051S_CD0 draft range pressure transmitter, it is best to mount the transmitter with the isolators parallel to the ground. Installing the transmitter in this way reduces oil mounting effect and provides for optimal temperature performance.

Be sure the transmitter is securely mounted. Tilting of the transmitter may cause a zero shift in the transmitter output.

Reducing Process Noise

There are two recommended methods of reducing process noise: output damping and, in gage applications, reference side filtering.

Output Damping

The output damping is factory set to 3.2 seconds as a default. If the transmitter output is still noisy, increase the damping time. If faster response is needed, decrease the damping time. Damping adjustment information is available on Damping on page 3-11.

Reference Side Filtering

In gage applications it is important to minimize fluctuations in atmospheric pressure to which the low side isolator is exposed. One method of reducing fluctuations in atmospheric pressure is to attach a length of tubing to the reference side of the transmitter to act as a pressure buffer.


Another method is to plumb the reference side to a chamber that has a small vent to atmosphere. If multiple draft transmitters are being used in an application, the reference side of each device can be plumbed to a chamber to achieve a common gage reference.

Environmental

Access requirements and cover installation on page 2-5 can help optimize transmitter performance. Mount the transmitter to minimize ambient temperature changes, vibration, mechanical shock, and to avoid external contact with corrosive materials. Appendix A: Specifications and Reference Data lists temperature operating limits.

Rosemount 3051S Series

Figure 2-1. HART Installation
Flowchart



INSTALLATION PROCEDURES

For dimensional drawing information refer to Appendix A: Specifications and Reference Data on page A-16.

Process Flange Orientation

Mount the process flanges with sufficient clearance for process connections. For safety reasons, place the drain/vent valves so the process fluid is directed away from possible human contact when the vents are used. In addition, consider the need for a testing or calibration input.

Housing Rotation

See "Consider Housing Rotation" on page 2-12.

Terminal Side of Electronics Housing

Mount the transmitter so the terminal side is accessible. Clearance of 0.75 in. (19 mm) is required for cover removal. Use a conduit plug in the unused conduit opening.

Circuit Side of Electronics Housing

Provide 0.75 in. (19 mm) of clearance for units with out an LCD display. Three inches of clearance is required for cover removal if a meter is installed.

Cover Installation


Always ensure a proper seal by installing the electronics housing cover(s) so that metal contacts metal. Use Rosemount O-rings.

Cover Jam Screw

For transmitter housings shipped with a cover jam screw, as shown in Figure 2-2, the screw should be properly installed once the transmitter has been wired and powered up. The cover jam screw is intended to disallow the removal of the transmitter cover in flameproof environments without the use of tooling. Follow these steps to install the cover jam screw:

1. Verify that the cover jam screw is completely threaded into the housing.
2. Install the transmitter housing cover and verify that the cover is tight against the housing.
3. Using an M4 hex wrench, loosen the jam screw until it contacts the transmitter cover.
4. Turn the jam screw an additional 1/2 turn counterclockwise to secure the cover. (Note: Application of excessive torque may strip the threads.)
5. Verify that the cover cannot be removed.

Figure 2-2. Cover Jam Screw



Mount the Transmitter

Mounting Brackets

Facilitate mounting transmitter to a 2-in. pipe, or to a panel. The B4 Bracket (SST) option is standard for use with the Coplanar and In-Line process connections. “Coplanar Flange Mounting Configurations” on page A-18 shows bracket dimensions and mounting configurations for the B4 option.


Options B1–B3 and B7–B9 are sturdy, epoxy/polyester-painted brackets designed for use with the traditional flange. The B1–B3 brackets have carbon steel bolts, while the B7–B9 brackets have stainless steel bolts. The BA and BC brackets and bolts are stainless steel. The B1/B7/BA and B3/B9/BC style brackets support 2-inch pipe-mount installations, and the B2/B8 style brackets support panel mounting.

NOTE

Verify transmitter zero point after installation. To reset zero point, refer to “Sensor Trim Overview” on page 4-5.

Flange Bolts

The 3051S can be shipped with a Coplanar flange or a Traditional flange installed with four 1.75-inch flange bolts. Mounting bolts and bolting configurations for the Coplanar and Traditional flanges can be found on page 2-8. Stainless steel bolts supplied by Emerson Process Management are coated with a lubricant to ease installation. Carbon steel bolts do not require lubrication. No additional lubricant should be applied when installing either type of bolt. Bolts supplied by Emerson Process Management are identified by their head markings:



Bolt Installation



Only use bolts supplied with the Rosemount 3051S or sold by Emerson Process Management as spare parts. When installing the transmitter to one of the optional mounting brackets, torque the bolts to 125 in.-lb. (0,9 N-m). Use the following bolt installation procedure:

1. Finger-tighten the bolts.
2. Torque the bolts to the initial torque value using a crossing pattern.
3. Torque the bolts to the final torque value using the same crossing pattern.


Torque values for the flange and manifold adapter bolts are as follows:

Table 2-1. Bolt Installation Torque Values


Bolt Material	Initial Torque Value	Final Torque Value
CS-ASTM-A445 Standard	300 in.-lb (34 N-m)	650 in.-lb (73 N-m)
316 SST—Option L4	150 in.-lb (17 N-m)	300 in.-lb (34 N-m)
ASTM-A-193-B7M—Option L5	300 in.-lb (34 N-m)	650 in.-lb (73 N-m)
<i>Monel</i> [®] —Option L6	300 in.-lb (34 N-m)	650 in.-lb (73 N-m)
ASTM-A-453-660—Option L7	150 in.-lb (17 N-m)	300 in.-lb (34 N-m)
ASTM-A-193-B8M—Option L8	150 in.-lb (17 N-m)	300 in.-lb (34 N-m)

Rosemount 3051S Series

DIFFERENTIAL TRANSMITTER




GAGE/ABSOLUTE TRANSMITTER




NOTE

Dimensions are in inches (millimeters).

**Transmitter with
Flange Bolts**



**Transmitter with
Flange Adapters
and Flange/ Adapter Bolts**



Description	Qty	Size in in. (mm)
Differential Pressure		
Flange Bolts	4	1.75 (44)
Adapter Bolts	4	1.50 (38) ⁽¹⁾
Flange/ Adapter Bolts	4	2.88 (73)
Gage/Absolute Pressure⁽²⁾		
Flange Bolts	4	1.75 (44)
Adapter Bolts	2	1.50 (38) ⁽¹⁾
Flange/ Adapter Bolts	2	2.88(73)

(1) DIN-compliant traditional flange requires 1.75 in. (44 mm) length adapter bolts.

(2) Rosemount 3051S In-line transmitters are direct mount and do not require bolts for process connection.

Impulse Piping

The piping between the process and the transmitter must accurately transfer the pressure to obtain accurate measurements. There are five possible sources of error: pressure transfer, leaks, friction loss (particularly if purging is used), trapped gas in a liquid line, liquid in a gas line, density variations between the legs, and plugged impulse piping.

The best location for the transmitter in relation to the process pipe depends on the process itself. Use the following guidelines to determine transmitter location and placement of impulse piping:

- Keep impulse piping as short as possible.
- For liquid service, slope the impulse piping at least 1 inch per foot (8 cm per m) upward from the transmitter toward the process connection.
- For gas service, slope the impulse piping at least 1 inch per foot (8 cm per m) downward from the transmitter toward the process connection.
- Avoid high points in liquid lines and low points in gas lines.
- Make sure both impulse legs are the same temperature.
- Use impulse piping large enough to avoid friction effects and blockage.
- Vent all gas from liquid piping legs.
- When using a sealing fluid, fill both piping legs to the same level.
- When purging, make the purge connection close to the process taps and purge through equal lengths of the same size pipe. Avoid purging through the transmitter.
- Keep corrosive or hot (above 250 °F [121 °C]) process material out of direct contact with the SuperModule and flanges.
- Prevent sediment deposits in the impulse piping.
- Keep the liquid head balanced on both legs of the impulse piping.
- Avoid conditions that might allow process fluid to freeze within the process flange.

Optional Advanced HART Diagnostics Electronics

The ASP™ Diagnostics Suite in the 3051S can detect abnormal process conditions by using statistical process monitoring to help detect plugged impulse lines.

The Advanced HART Diagnostics Electronics can be ordered using option code DA1 in the transmitter model number or as a spare part (p/n 03151-9070-0001) to retrofit existing 3051S transmitters in the field.

See Section 7 of this manual for more information.

Mounting Requirements

Impulse piping configurations depend on specific measurement conditions. Refer to Figure 2-3 for examples of the following mounting configurations:

Liquid Flow Measurement

- Place taps to the side of the line to prevent sediment deposits on the process isolators.
- Mount the transmitter beside or below the taps so gases vent into the process line.
- Mount drain/vent valve upward to allow gases to vent.

Gas Flow Measurement

- Place taps in the top or side of the line.
- Mount the transmitter beside or above the taps so to drain liquid into the process line.

Steam Flow Measurement

- Place taps to the side of the line.
- Mount the transmitter below the taps to ensure that impulse piping will remain filled with condensate.
- In steam service above 250 °F (121 °C), fill impulse lines with water to prevent steam from contacting the transmitter directly and to ensure accurate measurement start-up.

NOTE

For steam or other elevated temperature services, it is important that temperatures at the process connection do not exceed the transmitter's process temperature limits. See "Process Temperature Limits" on page A-11 for details.

Figure 2-3. Coplanar Installation Examples





Figure 2-4. In-Line Installation Examples



Process Connections

3051S transmitter flange process connection size is $\frac{1}{4}$ –18 NPT. Flange adapters with $\frac{1}{2}$ –14 NPT connections are available as the D2 option. Use your plant-approved lubricant or sealant when making the process connections. The process connections on the transmitter flange are on $2\frac{1}{8}$ -inch (54 mm) centers to allow direct mounting to a three-valve or five-valve manifold. Rotate one or both of the flange adapters to attain connection centers of 2 inches (51 mm), $2\frac{1}{8}$ inches (54 mm), or $2\frac{1}{4}$ inches (57 mm).

⚠ Install and tighten all four flange bolts before applying pressure to avoid leakage. When properly installed, the flange bolts will protrude through the top of the SuperModule housing. Do not attempt to loosen or remove the flange bolts while the transmitter is in service.

To install adapters to a Coplanar flange, perform the following procedure:

1. Remove the flange bolts.
2. Leaving the flange in place, move the adapters into position with the O-ring installed.
3. Clamp the adapters and the Coplanar flange to the transmitter module using the longer of the bolts supplied.
4. Tighten the bolts. Refer to Table 2-1 on page 2-7 for torque specifications.

⚠ WARNING

Failure to install proper flange adapter O-rings can cause process leaks, which can result in death or serious injury.

The two flange adapters are distinguished by unique O-ring grooves. Only use the O-ring that is designed for its specific flange adapter, as shown below.

ROSEMOUNT 3051S/ 3051/3001/3095/2024

ROSEMOUNT 1151

Refer to the Spare Parts list in Appendix A: Specifications and Reference Data for the correct part numbers of the flange adapters and O-rings designed for 3051S transmitters.


3051-0569A01A

Whenever you remove flanges or adapters, visually inspect the Teflon[®] O-rings. Replace them if there are any signs of damage, such as nicks or cuts. If you replace the O-rings, re-torque the flange bolts after installation to compensate for cold flow. Refer to the process sensor body reassembly procedure in Section 5 Troubleshooting on page 5-6.

Consider Housing Rotation

The housing can be rotated to improve field access to wiring or to better view the optional LCD display. Perform the following procedure:

Figure 2-5. Housings



1. Loosen the housing rotation set screw.
2. First rotate the housing clockwise to the desired location. If the desired location cannot be achieved due to thread limit, rotate the housing counter clockwise to the desired location (up to 360° from thread limit).
3. Retighten the housing rotation set screw.

In addition to housing rotation, the optional LCD display can be rotated in 90-degree increments by squeezing the two tabs, pulling out, rotating and snapping back into place.

NOTE

If LCD pins are inadvertently removed from the interface board, carefully re-insert the pins before snapping the LCD display back into place.

Configure Security and Alarm

NOTE



If alarm and security adjustments are not installed, the transmitter will operate normally with the default alarm condition alarm *high* and the security *off*.

Configure Security (Write Protect)

Changes can be prevented to the transmitter configuration data with the write protection PlantWeb housing switches and Junction Box housing jumpers. Security is controlled by the security (write protect) switch/jumper located on the interface assembly or terminal block. Position the switch/jumper in the "ON" position to prevent accidental or deliberate change of configuration data.


If the transmitter write protection switch/jumper is in the "ON" position, the transmitter will not accept any "writes" to its memory. Configuration changes, such as digital trim and reranging, cannot take place when the transmitter security is on.

To reposition the switches/jumpers, follow the procedure described below.

1. Do not remove the transmitter covers in explosive atmospheres when the circuit is live. If the transmitter is live, set the loop to manual and remove power.
2.  Remove the electronics compartment cover, opposite the field terminal side on the PlantWeb housing or the terminal block cover on the Junction Box housing. Do not remove the transmitter covers in explosive atmospheres when the circuit is live.
3. Follow the procedure in Figure 2-6 to reposition the switches/jumpers as desired for the specific housing compartment.
4.  Re-install the transmitter cover. Transmitter covers must be fully engaged to meet explosion-proof requirements.

Rosemount 3051S Series

Figure 2-6. Switch and jumper configuration (option D1)



HART Communicator

Fast Keys	1, 3, 4, 5
-----------	------------

Usage Note

The HART Communicator can be used to configure the security on and off. Otherwise, if the transmitter contains the D1 option, the switch/jumper will override software write protect. To disable the zero and span buttons (local keys), for transmitters with the D1 option, follow the “Local Keys Control” on page 2-14.

AMS

Right click on the device and select “Device Configuration”, then “Config Write Protect” from the menu.

1. Enter write protect setting, click **Next**.
2. Click **Next** to acknowledge setting has changed. If hardware adjustments are activated, click **Next** to acknowledge the “Switch option detected, function disabled, write protect unchanged” screen. If the hardware adjustments are activated, the write protect will not configure.
3. Click **Finish** to acknowledge the method is complete.

Local Keys Control

Local Keys control can be configured to enable or disable the use of the local zero and span buttons.

HART Communicator

Fast Keys	1, 4, 4, 1
-----------	------------

1. Enter the fast key sequence “Local Keys Control” to bring up the “Field device info” screen.
2. Scroll down to Local Keys on the menu and use the right arrow key to configure Enable or Disable.

AMS

Right click on the device and select “Configure” from the menu.

1. In the “Device” tab, use the “Local keys” drop down menu to select Enable or Disable and click **Apply**.
2. After carefully reading the warning provided, select **yes**.

Configure Alarm Direction

The transmitter alarm direction is set by repositioning the PlantWeb housing switch or Junction Box housing jumper. Position the switch/ jumper in the HI position for fail high and in the LO position for fail low. See “Failure Mode Alarm and Saturation” on page 3-12 for more information.

HART Communicator

Fast Keys	1, 4, 2, 7, 6
------------------	---------------

Usage Note

The HART Communicator can be used to configure the alarm direction to High (HI) or Low (LO). Otherwise, if the transmitter contains the D1 option, the switch/jumper on the transmitter will override the HART Communicator.

AMS


Right click on the device and select “Device Configuration,” then “Alarm/Saturation Levels,” then “Alarm Direction” from the menu.

1. Enter desired alarm direction, click **Next**.
2. Click **Next** to acknowledge setting has changed. If hardware adjustments are activated, click **Next** to acknowledge the “Switch option detected, function disabled, alarm direction unchanged” screen. If the hardware adjustments are activated, the write protect will not configure.
3. Click **Finish** to acknowledge the method is complete.

Connect Wiring and Power Up



Use twisted pairs to yield best results. To ensure proper communication, use 24 AWG to 14 AWG wire, and do not exceed 5000 feet (1 500 meters).

Figure 2-7. HART Terminal Blocks



To make connections, perform the following procedure:

Rosemount 3051S Series

-  1. Remove the housing cover on terminal compartment side. Do not remove the cover in explosive atmospheres when the circuit is live. Signal wiring supplies all power to the transmitter.
-  2. Connect the positive lead to the terminal marked (+) and the negative lead to the terminal marked (pwr/comm -). Avoid contact with leads and terminals. Do not connect powered signal wiring to the test terminals. Power could damage the test diode.
3. Plug and seal the unused conduit connection on the transmitter housing to avoid moisture accumulation in the terminal side. Install wiring with a drip loop. Arrange the drip loop so the bottom is lower than the conduit connections and the transmitter housing.

Surges/Transients

The transmitter will withstand electrical transients of the energy level usually encountered in static discharges or induced switching transients. However, high-energy transients, such as those induced in wiring from nearby lightning strikes, can damage the transmitter.

Optional Transient Protection Terminal Block

The transient protection terminal block can be ordered as an installed option (Option Code T1 in the transmitter model number) or as a spare part to retrofit existing 3051S transmitters in the field. For a complete listing of spare part numbers for transient protection terminal blocks, refer to page A-38. A lightning bolt symbol on a terminal block identifies it as having transient protection.

Signal Wiring Grounding

Do not run signal wiring in conduit or open trays with power wiring, or near heavy electrical equipment. Ground the signal wiring at any one point on the signal loop, or leave it ungrounded. The negative terminal of the power supply is a recommended grounding point.

Power Supply 4–20 mA Transmitters

The dc power supply should provide power with less than two percent ripple. Total resistance load is the sum of resistance from signal leads and the load resistance of the controller, indicator, and related pieces. Note that the resistance of intrinsic safety barriers, if used, must be included.

See “Load Limitations” on page A-7.

NOTE

A minimum loop resistance of 250 ohms is required to communicate with a HART Communicator. If a single power supply is used to power more than one 3051S transmitter, the power supply used, and circuitry common to the transmitters, should not have more than 20 ohms of impedance at 1200 Hz.

Electrical Considerations

Proper electrical installation is necessary to prevent errors due to improper grounding and electrical noise. For Junction Box housing, shielded signal wiring should be used in high EMI/RFI environments.

Remote Display Wiring and Power Up

The Remote Mount Display and Interface system consists of a local transmitter and a remote mount LCD display assembly. The local 3051S transmitter assembly includes a Junction Box housing with a three position terminal block integrally mounted to a SuperModule. The remote mount LCD display assembly consists of a dual compartment PlantWeb housing with a seven position terminal block. See Figure 2-8 on page 2-18 for complete wiring instructions. The following is a list of necessary information specific to the Remote Mount Display system:

- Each terminal block is unique for the remote display system.
- A 316 SST housing adapter is permanently secured to the remote mount LCD display PlantWeb housing providing an external ground and a means for field mounting with the provided mounting bracket.
- A cable is required for wiring between the transmitter and remote mount LCD display. The cable length is limited to 100 ft.
- 50 ft. (option M8) or 100 ft. (option M9) cable is provided for wiring between the transmitter and remote mount LCD display. Option M7 does not include cable; see recommended specifications below:

Cable type: Recommend Belden 3084A DeviceNet cable or Belden 123084A Armored DeviceNet cable. Other comparable cable may be used as long as it has independent dual twisted shielded pair wires with an outer shield. The Power wires must be 22 AWG minimum and the CAN communication wires must be 24 AWG minimum.

Cable length: Up to 100 feet depending upon cable capacitance.

Cable capacitance: The capacitance from the CAN communications line to the CAN return line as wired must be less than 5000 picofarads total. This allows up to 50 picofarads per foot for a 100 foot cable.


Intrinsic Safety Consideration: The transmitter assembly with remote display has been approved with Belden 3084A DeviceNet cable. Alternate cable may be used as long as the transmitter with remote display and cable is configured according to the installation control drawing or certificate. Refer to appropriate approval certificate or control drawing in Appendix B for remote cable IS requirements.

 **IMPORTANT**

Do not apply power to the remote communications terminal. Follow wiring instructions carefully to prevent damage to system components.

Rosemount 3051S Series

Figure 2-8. Remote Mount Display wiring diagram



NOTE


Wire colors provided above are per Belden 3084A DeviceNet cable. Wire color may vary depending on cable selected.

Belden 3084A DeviceNet cable includes a ground shield. This shield must be connected to earth ground at either the SuperModule or the Remote Display, but not both.

Quick Connect Wiring

As standard, the 3051S Quick Connect arrives properly assembled to the SuperModule and is ready for installation. Cordsets and Field Wireable Connectors (in shaded area) are sold separately.

Figure 2-9. Rosemount 3051S Quick Connect Exploded View




IMPORTANT

If Quick Connect is ordered as a 300S spare housing or is removed from the SuperModule, follow the instructions below for proper assembly prior to field wiring.

1. Place the Quick Connect onto the SuperModule. To ensure proper pin alignment, remove coupling nut prior to installing quick connect onto SuperModule.
2. Place coupling nut over quick connect and wrench tighten to a maximum of 300 in-lb. (34 N-m).
3. Tighten the set screw using a 3/32-in hex wrench.
4. Install Cordset/ Field Wireable Connectors onto the Quick Connect. Do not over tighten.

Figure 2-10. Quick Connect Housing Pin-Out

For other wiring details, refer to pin-out drawing and the cordset manufacturer's installation instructions.



Conduit Electrical Connector Wiring (Option GE or GM)


For 3051S transmitters with conduit electrical connectors GE or GM, refer to the cordset manufacturer's installation instructions for wiring details. For FM Intrinsically Safe, non-incendive or FM FISCO Intrinsically Safe hazardous locations, install in accordance with Rosemount drawing 03151-1009 to maintain outdoor rating (NEMA 4X and IP66.) See Appendix B, page B-20.

Rosemount 3051S Series

Grounding

Transmitter Case

Always ground the transmitter case in accordance with national and local electrical codes. The most effective transmitter case grounding method is a direct connection to earth ground with minimal impedance. Methods for grounding the transmitter case include:

- **Internal Ground Connection:** The Internal Ground Connection screw is inside the terminal side of the electronics housing. The screw is identified by a ground symbol () and is standard on all 3051S transmitters.
- **External Ground Assembly:** This assembly is included with the optional transient protection terminal block (Option Code T1), and it is included with ATEX Flameproof Certification (Option Code E1), ATEX Intrinsically Safe Certification (Option Code I1), and ATEX Type n Certification (Option Code N1). The External Ground Assembly can also be ordered with the transmitter (Option Code D4), or as a spare part (03151-9060-0001).

NOTE

Grounding the transmitter case using the threaded conduit connection may not provide a sufficient ground. The transient protection terminal block (Option Code T1) will not provide transient protection unless the transmitter case is properly grounded. Use the above guidelines to ground the transmitter case. Do not run transient protection ground wire with signal wiring; the ground wire may carry excessive current if a lightning strike occurs.

INSTALLING THE LCD DISPLAY

Transmitters ordered with the LCD display will be shipped with the display installed. The LCD display requires a PlantWeb housing. Installing the display on an existing 3051S transmitter requires a small instrument screwdriver and the display kit.

In addition to housing rotation, the optional LCD display can be rotated in 90-degree increments by squeezing the two tabs, pulling out, rotating and snapping back into place.

If LCD pins are inadvertently removed from the interface board, carefully re-insert the pins before snapping the LCD display back into place.

Use the following procedure and Figure 2-11 to install the LCD display:



1. **IF** the transmitter is installed in a loop, **THEN** secure the loop and disconnect power.
2.  Remove the transmitter cover opposite the field terminal side. Do not remove the instrument covers in explosive environments when the circuit is live.
3. Remove Hardware Adjustment Module if installed. Engage the four-pin connector into the LCD display and snap into place.
4. Install the meter cover and tighten to insure metal to metal contact.


Figure 2-11. Optional LCD Display



ROSEMOUNT 305, 306 AND 304 MANIFOLDS


The Rosemount 305 is available in two designs: Traditional and Coplanar. The traditional 305 Integral Manifold can be mounted to most primary elements with mounting adapters in the market today. The Rosemount 306 In-Line Manifold is used with In-line transmitters to provide block-and-bleed valve capabilities of up to 10000 psi (690 bar). The Rosemount 304 comes in two basic styles: traditional (flange x flange and flange x pipe) and wafer. The 304 traditional manifold comes in 2, 3, and 5-valve configurations. The 304 wafer manifold comes in 3 and 5 valve configurations.

Figure 2-12. Integral Manifold Designs



Rosemount 305 Integral Manifold Installation Procedure

To install a 305 Integral Manifold to a 3051S transmitter:

1.  Inspect the Teflon SuperModule O-rings. If the O-rings are undamaged, reusing them is recommended. If the O-rings are damaged (if they have nicks or cuts, for example), replace them with new O-rings.

IMPORTANT

If replacing the O-rings, be careful not to scratch or deface the O-ring grooves or the surface of the isolating diaphragm when removing the damaged O-rings.

2. Install the Integral Manifold on the SuperModule. Use the four manifold bolts for alignment. Finger tighten the bolts, then tighten the bolts incrementally in a cross pattern to final torque value. See "Flange Bolts" on page 2-6 for complete bolt installation information and torque values. When fully tightened, the bolts should extend through the top of the module housing.
3. If the Teflon SuperModule O-rings have been replaced, the flange bolts should be re-tightened after installation to compensate for cold flow of the O-rings.
4. If applicable, install flange adapters on the process end of the manifold using the 1.75-in. flange bolts supplied with the transmitter.


Rosemount 3051S Series

NOTE

Always perform a zero trim on the transmitter/manifold assembly after installation to eliminate mounting effects. See Section 4 Operation and Maintenance, “Zero Trim” on page 4-6.

Rosemount 306 In-Line Manifold Installation Procedure

The 306 Manifold is for use only with a 3051S In-line transmitter.

 Assemble the 306 Manifold to the 3051S In-line transmitter with a thread sealant.

1. Place transmitter into holding fixture.
2. Apply appropriate thread paste or tape to threaded instrument end of the manifold.
3. Count total threads on the manifold before starting assembly.
4. Start turning the manifold by hand into the process connection on the transmitter.

NOTE

If using thread tape, be sure the thread tape does not strip when the manifold assembly is started.

5. Wrench tighten manifold into process connection. (Note: Minimum torque value is 425 in-lbs)
6. Count how many threads are still showing. (Note: Minimum engagement is 3 revolutions)
7. Subtract the number of threads showing (after tightening) from the total threads to calculate the revolutions engaged. Further tighten until a minimum of 3 rotations is achieved.
8. For block and bleed manifold, verify the bleed screw is installed and tightened. For two-valve manifold, verify the vent plug is installed and tightened.
9. Leak-check assembly to maximum pressure range of transmitter.

Rosemount 304 Conventional Manifold Installation Procedure


To install a 304 Conventional Manifold to a 3051S transmitter:

1. Align the Conventional Manifold with the transmitter flange. Use the four manifold bolts for alignment.
2. Finger tighten the bolts, then tighten the bolts incrementally in a cross pattern to final torque value. See “Flange Bolts” on page 2-6 for complete bolt installation information and torque values. When fully tightened, the bolts should extend through the top of the module housing plane of flange web (i.e. bolt hole) but must not contact module housing.
3. If applicable, install flange adapters on the process end of the manifold using the 1.75-in. flange bolts supplied with the transmitter.


Manifold Operation

Three-valve configuration shown.


In normal operation the two block valves between the process and instrument ports will be open and the equalizing valve(s) will be closed.



To zero the 3051S, close the block valve to the low pressure (downstream side) of the transmitter first.




Next, open the center (equalize) valve(s) to equalize the pressure on both sides of the transmitter.




Rosemount 3051S Series

The manifold valves are now in the proper configuration for zeroing the transmitter. To return the transmitter to service, close the equalizing valve(s) first.



Next, open the block valve on the low pressure side of the transmitter.



Section 3 Configuration

Overview	page 3-1
Safety Messages	page 3-1
Commissioning on the bench With HART	page 3-2
Review Configuration Data	page 3-4
HART Communicator	page 3-5
Check Output	page 3-7
Basic Setup	page 3-8
LCD Display	page 3-11
Detailed Setup	page 3-12
Diagnostics and Service	page 3-20
Advanced Functions for HART Protocol	page 3-22
Multidrop Communication	page 3-25

OVERVIEW

This section contains information on commissioning and tasks that should be performed on the bench prior to installation.

Instructions for performing configuration functions are given for HART Communicator version 1.8 and AMS version 7.0. For convenience, HART Communicator fast key sequences are labeled “Fast Keys” for each software function below the appropriate headings.

Example Software Function

Fast Keys	1, 2, 3, etc.
-----------	---------------

SAFETY MESSAGES

Procedures and instructions in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that raises potential safety issues is indicated by a warning symbol (⚠). Refer to the following safety messages before performing an operation preceded by this symbol.

Warnings

⚠ WARNING

Explosions can result in death or serious injury.

- Do not remove the transmitter covers in explosive environments when the circuit is live.
- Transmitter covers must be fully engaged to meet explosionproof requirements.
- Before connecting a communicator in an explosive atmosphere, make sure the instruments in the loop are installed in accordance with intrinsically safe or nonincendive field wiring practices.

Electrical shock can result in death or serious injury.

- Avoid contact with the leads and terminals. High voltage that may be present on leads can cause electrical shock.

Rosemount 3051S Series

COMMISSIONING ON THE BENCH WITH HART

Commissioning consists of testing the transmitter and verifying transmitter configuration data. 3051S transmitters can be commissioned either before or after installation. Commissioning the transmitter on the bench before installation using a 375 Field Communicator or AMS ensures that all transmitter components are in working order.

⚠ To commission on the bench, required equipment includes a power supply, a milliamp meter, and a HART Communicator or AMS. Wire equipment as shown in Figure 3-1 and Figure 3-2. Verify transmitter terminal voltage is between 10.5 - 42.4 Vdc. To ensure successful communication, a resistance of at least 250 ohms must be present between the HART Communicator loop connection and the power supply. Connect the HART Communicator leads to the terminals labeled "COMM" on the terminal block. (Connecting across the "TEST" terminals will prevent successful communication.)

Set all transmitter hardware adjustments during commissioning to avoid exposing the transmitter electronics to the plant environment after installation. Refer to "Configure Security and Alarm" on page 2-13.

When using a HART Communicator, any configuration changes made must be sent to the transmitter by using the "Send" key (F2). AMS configuration changes are implemented when the "Apply" button is clicked.

Setting the Loop to Manual

Whenever sending or requesting data that would disrupt the loop or change the output of the transmitter, set the process application loop to manual. The HART Communicator or AMS will prompt you to set the loop to manual when necessary. Acknowledging this prompt does not set the loop to manual. The prompt is only a reminder; set the loop to manual as a separate operation.

Wiring Diagrams

Bench Hook-up

Connect the bench equipment as shown in Figures 3-1 and 3-2, and turn on the HART Communicator by pressing the ON/OFF key or log into AMS. The HART Communicator or AMS will search for a HART-compatible device and indicate when the connection is made. If the HART Communicator or AMS fail to connect, it indicates that no device was found. If this occurs, refer to Section 5: Troubleshooting.

Field Hook-up

Figures 3-1 and 3-2 illustrate wiring loops for a field hook-up with a HART Communicator or AMS. The HART Communicator or AMS may be connected at "COMM" on the transmitter terminal block, across the load resistor, or at any termination point in the signal loop. Signal point may be grounded at any point or left ungrounded.

Figure 3-1. PlantWeb Wiring (4–20 mA)





Figure 3-2. Junction Box Wiring (4–20 mA)



Rosemount 3051S Series

REVIEW CONFIGURATION DATA

NOTE

Information and procedures in this section that make use of HART Communicator fast key sequences and AMS assume that the transmitter and communication equipment are connected, powered, and operating correctly.

The following is a list of factory configurations. These can be reviewed by using the HART Communicator or AMS.

HART Communicator v1.8

Enter the fast key sequence to view the configuration data.

Fast Keys	1, 5
------------------	------


Manufacturer "Rosemount"	O-Ring material
Transmitter model	Drain/Vent material
Measurement type	Number of diaphragm seals
Module configuration type	Seal type
Range	Remote seal isolator material
PV Unit	Seal fill fluid
PV Lower Sensor Limit (LSL)	Tag
PV Upper Sensor Limit (USL)	Date
PV Lower Range Value (LRV)	Descriptor
PV Upper Range Value (URV)	Message
PV minimum span	Write protect
Lower sensor trim point	Meter type
Upper sensor trim point	Local keys
Sensor trim calibration type	Universal revision
Transfer function	Field device revision
Damping	Software revision
Alarm direction	Hardware revision
High Alarm (Value)	Physical signal code
Low Alarm (Value)	Final assembly number
High saturation	Device ID
Low saturation	Burst mode
Alarm/Saturation type	Burst option
Sensor S/N	Poll address
Isolator material	Number req preams
Fill fluid	Multisensor device
Process connector	Command #39, EEPROM Control required
Process connector material	Distributor

AMS v7.0

Right click on the device and select "Configure" from the menu. Select the tabs to review the transmitter configuration data.

HART COMMUNICATOR (Version 1.8)

Menu Tree



Rosemount 3051S Series

Fast Key Sequence

The following menu indicates fast key sequences for common functions. A check (✓) indicates the basic configuration parameters. At minimum, these parameters should be verified as part of the configuration and startup procedure.

Function	HART Fast Key Sequence
Alarm Level Configuration	1, 4, 2, 7, 7
Alarm and Saturation Levels	1, 4, 2, 7
Analog Output Alarm Direction	1, 4, 2, 7, 6
Analog Output Trim	1, 2, 3, 2
Burst Mode On/Off	1, 4, 3, 3, 3
Burst Options	1, 4, 3, 3, 4
✓ Damping	1, 3, 6
Date	1, 3, 4, 1
Descriptor	1, 3, 4, 2
Digital To Analog Trim (4-20 mA Output)	1, 2, 3, 2, 1
Field Device Information	1, 4, 4, 1
LCD Display Configuration	1, 3, 7
Loop Test	1, 2, 2
Lower Sensor Trim	1, 2, 3, 3, 2
Message	1, 3, 4, 3
Number of Requested Preambles	1, 4, 3, 3, 2
Pressure Alert Configuration	1, 4, 3, 5, 3
Poll Address	1, 4, 3, 3, 1
Poll a Multidropped Transmitter	Left Arrow, 3, 1, 1
Re-mapping	1, 4, 3, 6
Rerange- Keypad Input	1, 2, 3, 1, 1
Saturation Level Configuration	1, 4, 2, 7, 8
Scaled D/A Trim (4-20 mA Output)	1, 2, 3, 2, 2
Scaled Variable Configuration	1, 4, 3, 4, 7
Self Test (Transmitter)	1, 2, 1, 1
Sensor Information	1, 4, 4, 2
Sensor Temperature	1, 1, 4
Sensor Trim	1, 2, 3, 3
Sensor Trim Points	1, 2, 3, 3, 5
Status	1, 2, 1, 2
✓ Tag	1, 3, 1
Temperature Alert Configuration	1, 4, 3, 5, 4
✓ Transfer Function (Setting Output Type)	1, 3, 5
Transmitter Security (Write Protect)	1, 3, 4, 5
✓ Units (Process Variable)	1, 3, 2
Upper Sensor Trim	1, 2, 3, 3, 3
Zero Trim	1, 2, 3, 3, 1

CHECK OUTPUT

Before performing other transmitter on-line operations, review the digital output parameters to ensure that the transmitter is operating properly and is configured to the appropriate process variables.

Process Variables

Fast Keys	1, 1
-----------	------

The process variables for the 3051S provide transmitter output, and are continuously updated. The pressure reading in both engineering units and percent of range will continue to track with pressures outside of the defined range from the lower to the upper range limit of the SuperModule.

HART Communicator v1.8

The process variable menu displays the following process variables:

- Pressure
- Percent of range
- Analog output
- Sensor temperature
- Scaled Variable (SV)
- Primary Variable (PV)

NOTE

Regardless of the range points, the 3051S will measure and report all readings within the digital limits of the sensor. For example, if the 4 and 20 mA points are set to 0 and 10 inH₂O, and the transmitter detects a pressure of 25 inH₂O, it digitally outputs the 25 inH₂O reading and a 250% of span reading. However, there may be up to ±5.0% error associated with output outside of the range points.

AMS v7.0

Right click on the device and select “Process Variables...” from the menu. The process variable screen displays the following process variables:

- Pressure
- Percent of range
- Analog output
- Sensor temperature
- Scaled Variable (SV)
- Primary Variable (PV)

Sensor Temperature

Fast Keys	1, 1, 4
-----------	---------

The 3051S contains a temperature sensor near the pressure sensor in the SuperModule. When reading this temperature, keep in mind the sensor is not a process temperature reading.

HART Communicator v1.8

Enter the fast key sequence “Sensor Temperature” to view the sensor temperature reading.

AMS v7.0

Right click on the device and select “Process Variables...” from the menu. “Snsr Temp” is the sensor temperature reading.

Rosemount 3051S Series

BASIC SETUP

Set Process Variable Units

Fast Keys	1, 3, 2
-----------	---------

The PV Unit command sets the process variable units to allow you to monitor your process using the appropriate units of measure.

HART Communicator v1.8

Enter the fast key sequence "Set Process Variable Units." Select from the following engineering units:

- inH₂O
- inHg
- ftH₂O
- mmH₂O
- mmHg
- psi
- bar
- mbar
- g/cm²
- kg/cm²
- Pa
- kPa
- torr
- atm
- MPa
- inH₂O at 4 °C
- mmH₂O at 4 °C

AMS v7.0

Right click on the device and select "Configure" from the menu. In the Basic Setup tab, use "Unit" drop down menu to select units.

Set Output (Transfer function)

Fast Keys	1, 3, 5
-----------	---------

The 3051S has two output settings: Linear and Square Root. Activate the square root output option to make analog output proportional to flow. As input approaches zero, the 3051S automatically switches to linear output in order to ensure a more smooth, stable output near zero (see Figure 3-3).

From 0 to 0.6 percent of the ranged pressure input, the slope of the curve is unity ($y = x$). This allows accurate calibration near zero. Greater slopes would cause large changes in output (for small changes at input). From 0.6 percent to 0.8 percent, curve slope equals 42 ($y = 42x$) to achieve continuous transition from linear to square root at the transition point.

NOTE

If Scaled Variable is mapped as the primary variable and square root mode is desired, select Square Root during Scaled Variable Configuration or as part of the set output configuration. Avoid duplication of Square Root configuration.

HART Communicator v1.8


Enter the fast key sequence "Set Output (Transfer function)."

AMS v7.0

Right click on the device and select "Configure" from the menu.

1. In the Basic Setup tab, use "Xfer fnctn" drop down menu to select output, click **Apply**.
2. After carefully reading the warning provided, select **yes**.

Figure 3-3. Square Root Output
Transition Point



NOTE

For a flow turndown of greater than 10:1 it is not recommended to perform a square root extraction in the transmitter. Instead, perform the square root extraction in the system.

Rerange

The Range Values command sets the 4 and 20 mA points (lower and upper range values). In practice, you may reset the transmitter range values as often as necessary to reflect changing process conditions. Changing the lower or upper range point results in similar changes to the span. For a complete listing of Range & Sensor limits, refer to the “Range & Sensor Limits” table on page A-6.

NOTE

Transmitters are shipped from Rosemount Inc. fully calibrated per request or by the factory default of full scale (span = upper range limit.)

Select from one of the methods below to rerange the transmitter. Each method is unique; examine all options closely before deciding which method works best for your process.

- Rerange with a HART Communicator only.
- Rerange with a pressure input source and a HART Communicator.
- Rerange with a pressure input source and the local zero and span buttons (option D1).
- Rerange with AMS only.
- Rerange with a pressure input source and AMS.

NOTE

If the transmitter security jumper/switch is **ON**, adjustments to the zero and span will not be able to be made. Refer to “Configure Security and Alarm” on page 2-13 for security information.

Rerange with a HART Communicator v1.8 Only

Fast Keys	1, 2, 3, 1, 1
------------------	---------------

The easiest and most popular way to rerange is to use the HART Communicator only. This method changes the values of the analog 4 and 20 mA points independently without a pressure input.

From the **HOME** screen, enter the fast key sequence “Rerange with a Communicator Only.”

1. At “Keypad Input” select 1 and use the keypad to enter lower range value.
2. From “Keypad Input” select 2 and use the keypad to enter upper range value.

Rerange with a Pressure Input Source and HART Communicator v1.8

Fast Keys	1, 2, 3, 1, 2
------------------	---------------

Reranging using the HART Communicator and a pressure source or process pressure is a way of reranging the transmitter when specific 4 and 20 mA points are unknown.

NOTE


The span is maintained when the 4 mA point is set. The span changes when the 20 mA point is set. If the lower range point is set to a value that causes the upper range point to exceed the sensor limit, the upper range point is automatically set to the sensor limit, and the span is adjusted accordingly.

1. From the **HOME** screen, enter the fast key sequence “Rerange with a Pressure Input Source and a HART Communicator” to configure lower and upper range values and follow the on-line instructions.

Rerange with a Pressure Input Source and the Local Zero and Span buttons (option D1)

Reranging using the local zero and span adjustments and a pressure source is a way of reranging the transmitter.

1. Using a pressure source with an accuracy three to ten times the desired calibrated accuracy, apply a pressure equivalent to the lower range value to the high side of the transmitter.
2. Push and hold the zero adjustment button for at least two seconds but no longer than ten seconds.
3. Apply a pressure equivalent to the upper range value to the high side of the transmitter.
4. Push and hold the span adjustment button for at least two seconds but no longer than ten seconds.



Rerange with AMS v7.0 only

Right click on the device and select “Configure” from the menu. In the Basic Setup tab, locate the Analog Output box and perform the following procedure:

1. Enter the lower range value (LRV) and the upper range value (URV) in the fields provided. Click **Apply**.
2. After carefully reading the warning provided, select **yes**.

Rerange with a Pressure Input Source and AMS v7.0

Right click on the device, select “Calibrate”, then “Apply values” from the menu.

1. Select **Next** after the control loop is set to manual.
2. From the “Apply Values” menu, follow the on-line instructions to configure lower and upper range values.
3. Select **Exit** to leave the “Apply Values” screen.
4. Select **Next** to acknowledge the loop can be returned to automatic control.
5. Select **Finish** to acknowledge the method is complete.

Damping

Fast Keys	1, 3, 6
-----------	---------

The Damp command introduces a delay in processing which increases the response time of the transmitter; smoothing variations in output readings caused by rapid input changes. Determine the appropriate damp setting based on the necessary response time, signal stability, and other requirements of the loop dynamics of your system. The damping value of your device is user selectable from 0 to 60 seconds. The current damping value can be determined by executing the HART Communicator fast keys or going to “Configure” in AMS.

HART Communicator v1.8

Enter the fast key sequence “Damping.”

AMS v7.0

Right click on the device and select “Configure” from the menu.

1. In the “Basic Setup” tab, enter the damping value in the “Damp” field, click **Apply**.
2. After carefully reading the warning provided, select **yes**.

LCD DISPLAY

The LCD display connects directly to the interface/electronics board which maintains direct access to the signal terminals. The display indicates output and abbreviated diagnostic messages. A display cover is provided to accommodate the display.

The LCD display features a four-line display and a 0-100% scaled bar graph. The first line of five characters displays the output description, the second line of seven digits displays the actual value, the third line of six characters displays engineering units and the fourth line displays “Error” when the transmitter is in alarm. The LCD display can also display diagnostic messages.

LCD Display Configuration with HART Communicator v1.8

Fast Keys	1, 3, 7
-----------	---------

The factory default LCD display setting is engineering units. The Meter Options command allows customization of the LCD display to suit application requirements. The LCD display will alternate between the selected items (up to four may be chosen):

- Pressure (Engineering Units)
- Percent of Range
- Scaled Variable
- Temperature

AMS v7.0

Right click on the device and select “Configure” from the menu.

1. In the “LCD” tab, select the desired options to suit your application needs, click **Apply**.
2. After carefully reading the warning provided, select **yes**.

DETAILED SETUP

Failure Mode Alarm and Saturation

3051S transmitters automatically and continuously perform self-diagnostic routines. If the self-diagnostic routines detect a failure, the transmitter drives the output to configured alarm values. The transmitter will also drive the output to configured saturation values if the applied pressure goes outside the 4-20 mA range values.

The transmitter will drive its output low or high based on the position of the failure mode alarm jumper, see “Configure Security and Alarm” on page 2-13.

NOTE

The failure mode alarm direction can also be configured using the HART Communicator or AMS.

3051S transmitters have three configurable options for failure mode alarm and saturation levels:

- Rosemount (Standard), see Table 3-1.
- NAMUR, see Table 3-2.
- Custom, see Table 3-3.

Table 3-1. Rosemount (Standard) Alarm and Saturation Values

Level	4–20 mA Saturation	4–20 mA Alarm
Low	3.9 mA	≤ 3.75 mA
High	20.8 mA	≥ 21.75 mA

Table 3-2. NAMUR-Compliant Alarm and Saturation Values

Level	4–20 mA Saturation	4–20 mA Alarm
Low	3.8 mA	≤ 3.6 mA
High	20.5 mA	≥ 22.5 mA

Table 3-3. Custom Alarm and Saturation Values

Level	4–20 mA Saturation	4–20 mA Alarm
Low	3.7 mA — 3.9 mA	3.6 mA — 3.8 mA
High	20.1 mA — 21.5 mA	20.2 mA — 23.0 mA

Failure mode alarm and saturation levels can be configured using a HART Communicator or AMS, see “Alarm and Saturation Level Configuration” on page 3-13. Per Table 3-3, custom alarm and saturation levels can be configured between 3.6 mA and 3.9 mA for low values and between 20.1 mA and 23 mA for high values. The following limitations exist for custom levels:

- Low alarm level must be less than the low saturation level
- High alarm level must be higher than the high saturation level
- High saturation level must not exceed 21.5 mA
- Alarm and saturation levels must be separated by at least 0.1 mA

The HART Communicator or AMS will provide an error message if a configuration rule is violated.

To configure alarm and saturation levels with a HART Communicator or AMS perform the following procedure:

Alarm and Saturation Level Configuration

Fast Keys	1, 4, 2, 7
-----------	------------

HART Communicator v1.8

1. From the **HOME** screen, follow the fast key sequence.
2. Select 7, **Config. Alarm Level** to configure alarm levels.
3. Select **OK** after setting the control loop to manual.
4. Select **OK** to acknowledge current settings.
5. Select desired setting, if “OTHER” is selected enter HI and LO custom values.
6. Select **OK** to acknowledge the loop can be returned to automatic control.
7. Select 8, **Config. Sat. Levels** to configure saturation levels.
8. Repeat steps 3-6 to configure saturation levels.

Rosemount 3051S Series

AMS v7.0

Right click on the device, select “Device Configuration”, then select “Alarm/Saturation Levels,” then “Alarm Levels” from the menu.

1. Click **Next** after setting the control loop to manual.
2. Click **Next** after acknowledging the current alarm levels.
3. Select the desired alarm settings: NAMUR, Rosemount, Other
4. If “Other” is selected, enter desired “HI Value” and “LO Value” custom values.
5. Click **Next** to acknowledge new alarm levels.
6. Select **Next** to acknowledge the loop can be returned to automatic control.
7. Select **Finish** to acknowledge the method is complete.
8. Right click on the device, select “Device Configuration,” then select “Alarm/Saturation Levels,” then “Saturation Levels” from the menu.
9. Repeat steps 2 - 8 to configure saturation levels.

Alarm and Saturation Levels for Burst Mode

Transmitters set to burst mode handle saturation and alarm conditions differently.

Alarm Conditions:

- Analog output switches to alarm value
- Primary variable is burst with a status bit set
- Percent of range follows primary variable
- Temperature is burst with a status bit set

Saturation:

- Analog output switches to saturation value
- Primary variable is burst normally
- Temperature is burst normally

Alarm and Saturation Values for Multidrop Mode

Transmitters set to multidrop mode handle saturation and alarm conditions differently.

Alarm Conditions:

- Primary variable is sent with a status bit set
- Percent of range follows primary variable
- Temperature is sent with a status bit set

Saturation:

- Primary variable is sent normally
- Temperature is sent normally

Alarm Level Verification

The transmitter alarm level should be verified before returning the transmitter to service if the following changes are made:

- Replacement of electronics board, SuperModule, or LCD display
- Alarm and saturation level configuration

This feature is also useful in testing the reaction of the control system to a transmitter in an alarm state. To verify the transmitter alarm values, perform a loop test and set the transmitter output to the alarm value (see Table 3-1, Table 3-2, and Table 3-3 on page 3-13, and “Loop Test” on page 3-21).

Process Alerts

Fast Keys	1, 4, 3, 5
-----------	------------

Process alerts allow the user to configure the transmitter to output a HART message when the configured data point is exceeded. Process alerts can be set for pressure, temperature, or both. A process alert will be transmitted continuously if the pressure or temperature set points are exceeded and the alert mode is **ON**. An alert will be displayed on a HART Communicator, AMS status screen or in the error section of the LCD display. The alert will reset once the value returns within range.

NOTE

HI alert value must be higher than the LO alert value. Both alert values must be within the pressure or temperature sensor limits.

HART Communicator v1.8

To configure the process alerts with a HART Communicator, perform the following procedure:

1. From the **HOME** screen, follow the fast key sequence “Process Alerts.”
2. Select 3, “Config Press Alerts” to configure the pressure alert.
Select 4, “Config Temp Alerts” to configure the temperature alerts.
3. Use the right arrow key to configure the HI and LO alert values.
4. Use the left arrow to move back to the process alert menu.
Select 1, “Press Alert Mode” to turn on the pressure alert mode.
Select 2, “Temp Alert Mode” to turn on the temperature alert mode.

AMS v7.0

Right click on the device and select “Configure” from the menu.

1. In the “Analog Output” tab, locate the “Configuration Pressure Alerts” box, enter “Press Hi Alert Val” and “Press Lo Alert Val” to configure the pressure alerts.
2. Configure “Press Alert Mode” to “ON” or “OFF” using the drop down menu.
3. In the “Configuration Temperature Alerts” box, enter “Temp Hi Alert Val” and “Temp Lo Alert Val” to configure the temperature alerts.
4. Configure “Temp Alert Mode” to “ON” or “OFF” using the drop down menu and click **Apply**.
5. After carefully reading the warning provided, select **yes**.

Rosemount 3051S Series

Scaled Variable Configuration

Fast Keys	1, 4, 3, 4, 7
-----------	---------------

The scaled variable configuration allows the user to create a relationship/conversion between the pressure reading and custom units.

The scaled variable configuration defines the following items:

- Scaled variable units - Custom units to be displayed.
- Scaled data options - Defines the transfer function for the application
 - a. Linear
 - b. Square root
- Pressure value position 1 - Lower known value point (possible 4 mA point) with consideration of linear offset.
- Scaled variable value position 1 - Custom unit equivalent to the lower known value point (The lower known value point may or may not be the 4 mA point.)
- Pressure value position 2 - Upper known value point (possible 20 mA point)
- Scaled variable value position 2 - Custom unit equivalent to the upper known value point (possible 20 mA point)
- Linear offset - The value required to zero out pressures effecting the desired pressure reading.
- Low flow cutoff - Point at which output is driven to zero to prevent problems caused by process noise.

NOTE

If Scaled Variable is mapped as the primary variable and square root mode is desired, select Square Root during Scaled Variable Configuration or as part of the set output configuration. Avoid duplication of Square Root configuration.

HART Communicator v1.8

To configure the scaled variable with a HART Communicator, perform the following procedure:

1. From the **HOME** screen follow the fast key sequence “Scaled Variable Configuration.”
2. Select **OK** after the control loop is set to manual.
3. Enter the scaled variable units.
 - a. Units can be up to five characters long and include A — Z, 0 — 9, -, /, %, and *. Default unit is DEFLT.
 - b. The first character is always an asterisk (*), which identifies the units displayed are scaled variable units.
4. Select scaled data options
 - a. Select linear if the relationship between PV and scaled variable units are linear. Linear prompts for two data points.
 - b. Select square root if the relationship between PV and scaled variable is square root (flow applications). Square root will prompt for one data point.

5. Enter pressure value position 1. Pressure values must be within the range of the transmitter.
 - a. (If performing a **Linear Function**) Enter the lower known value point considering any linear offset.
 - b. (If performing a **Square Root Function**) Select **OK** to acknowledge pressure value is set to zero.
6. Enter scaled variable position 1.
 - a. (If performing a **Linear Function**) Enter the lower known value point; this value must be no longer than seven digits.
 - b. (If performing a **Square Root Function**) Select **OK** to acknowledge scaled variable value is set to zero.
7. Enter pressure value position 2. Pressure values must be within the range of the transmitter.
 - a. Enter the upper known value point.
8. Enter scaled variable position 2.
 - a. (If performing a **Linear Function**) Enter custom unit equivalent to the upper known value point; this value must be no longer than seven digits.
 - b. (If performing a **Square Root Function**) Enter custom unit equivalent to the value in step 7; this value must be no longer than seven digits. Skip to step 10.
9. Enter linear offset (If performing a **Linear Function**). Skip to step 11.
10. Enter Low Flow cutoff mode (If performing a **Square Root Function**)
 - a. Select **OFF** if a low flow cutoff value is not desired.
 - b. Select **ON** if a low flow cutoff value is desired and enter this value on the next screen.
11. Select **OK** to acknowledge that the loop can be returned to automatic control.


AMS v7.0

Right click on the device and select “Device Configuration” then select “SV Config” from the menu.

1. Click **Next** after setting the control loop to manual.
2. Enter desired scaled variable units in “Enter SV units” box and click **Next**.
3. Select scaled data options: Linear or Square Root and click **Next**. If square root is selected skip to Step 9.
4. Enter pressure value position 1 and click **Next**.
5. Enter scaled variable position 1 and click **Next**.
6. Enter pressure value position 2 and click **Next**.
7. Enter scaled variable position 2 and click **Next**.
8. Enter linear offset and click **Next**. Skip to Step 15.
9. Select **Next** to acknowledge that “Pressure value for position 1 is set to zero.
10. Select **Next** to acknowledged that “Square root value for position 1 is set to zero.
11. Enter pressure value for position 2 and click **Next**.
12. Enter square root value for position 2 and click **Next**.
13. Enter low flow cutoff mode: Off or On. If off is selected skip to Step 15.
14. Enter low flow cutoff value and click **Next**.
15. Select **Next** to acknowledge that the loop can be returned to automatic control.
16. Select **Finish** to acknowledge the method is complete.

DP Level Example

Figure 3-4. Example tank



A differential transmitter is used in a level application where the span is 188 inH₂O (200 in. * 0.94 sg). Once installed on an empty tank and taps vented, the process variable reading is -209.4 inH₂O. The process variable reading is the head pressure created by fill fluid in the capillary. Based on Figure 3-4, the Scaled Variable configuration would be as follows:

Scaled Variable units:	inches
Scaled data options:	linear
Pressure value position 1:	0 inH ₂ O (0 mbar)
Scaled Variable position 1:	12 in. (305 mm)
Pressure value position 2:	188 inH ₂ O (0.47 bar)
Scaled Variable position 2:	212 in.(5385 mm)
Linear offset:	-209.4 inH ₂ O (-0.52 bar)

DP Flow Example

A differential transmitter is used in conjunction with an orifice plate in a flow application where the differential pressure at full scale flow is 125 inH₂O. In this particular application, the flow rate at full scale flow is 20,000 gallons of water per hour. Low flow cutoff is not required in this application. Based on this information, the Scaled Variable configuration would be as follows:

Scaled Variable units:	gal/h
Scaled data options:	square root
Pressure value position 2:	125 inH ₂ O (311 mbar)
Scaled Variable position 2:	20,000 gal/h (75,708 lt/hr)
Low Flow Cutoff:	0 (OFF)

NOTE

Pressure value position 1 and Scaled Variable position 1 are always set to zero for a flow application. No configuration is required.

Re-mapping

Fast Keys	1, 4, 3, 6
------------------	------------

The re-mapping function allows the transmitter primary, secondary, and tertiary variables to be configured as desired. Default configuration for transmitter variables is as shown below:

- Primary variable (PV) = Pressure
- Secondary variable (SV) = Temperature
- Tertiary variable (TV) = Scaled Variable

NOTE

Variable assigned as the primary variable drives the 4-20 mA analog output.

The scaled variable can be remapped as the primary variable if desired.

HART Communicator v1.8

From the **HOME** screen, enter the fast key sequence “Re-mapping.”

1. Select **OK** after the control loop is set to manual (see “Setting the Loop to Manual” on page 3-2).
2. Choose desired primary variable and select **Enter**.
3. Choose desired secondary variable and select **Enter**.
4. Select **OK** to acknowledge the tertiary variable setting.
5. Select **OK** to acknowledge that the loop can be returned to automatic control.

Rosemount 3051S Series

AMS v7.0

Right click on the device and select “Configure”.

1. In “Basic Setup” tab, locate “Variable Mapping” box.
2. Choose desired primary variable.
3. Choose desired secondary variable.
4. Choose desired tertiary variable.
5. Click **Apply** and then select **Next** to acknowledge the loop can be returned to automatic control.
6. Select **Finish** to acknowledge the method is complete.

Sensor Temperature Unit

Fast Keys	1, 4, 1, 2, 2
-----------	---------------

The Sensor Temperature Unit command selects between Celsius and Fahrenheit units for the sensor temperature. The sensor temperature output is accessible via HART only.

HART Communicator v1.8

Enter the fast key sequence “Sensor Temperature Unit.”

AMS v7.0

Right click on the device and select “Configure” from the menu.

1. In the “Process Input” tab, use the drop down menu “Snsr temp unit” to select F (Fahrenheit) or C (Celsius). Click **Apply**.
2. Click **Next** to acknowledge send warning.
3. Select **Finish** to acknowledge the method is complete.
4. After carefully reading the warning, select **yes**.

DIAGNOSTICS AND SERVICE

Diagnostics and service functions listed below are primarily for use after field installation. The Transmitter Test feature is designed to verify that the transmitter is operating properly, and can be performed either on the bench or in the field. The Loop Test feature is designed to verify proper loop wiring and transmitter output, and should only be performed after you install the transmitter.

Transmitter Test

Fast Keys	1, 2, 1, 1
-----------	------------

The Transmitter Test command initiates a more extensive diagnostics routine than that performed continuously by the transmitter. The test routine can quickly identify potential electronics problems. If the test detects a problem, messages to indicate the source of the problem are displayed on the HART Communicator screen.

HART Communicator v1.8

Enter the fast key sequence “Transmitter Test.”

AMS v7.0

Right click on the device and select “Diagnostics and Test,” then “Self test” from the menu.

1. Click **Next** to acknowledge test results.
2. Select **Finish** to acknowledge the method is complete.

Loop Test

Fast Keys	1, 2, 2
-----------	---------

The Loop Test command verifies the output of the transmitter, the integrity of the loop, and the operations of any recorders or similar devices installed in the loop.

HART Communicator v1.8

To initiate a loop test, perform the following procedure:

1. Connect a reference meter to the transmitter by either connecting the meter to the test terminals on the terminal block, or shunting transmitter power through the meter at some point in the loop.
2. From the **HOME** screen, enter the fast key sequence “Loop Test” to verify the output of the transmitter.
3. Select **OK** after the control loop is set to manual (see “Setting the Loop to Manual” on page 3-2).
4. Select a discrete milliamp level for the transmitter to output. At the **CHOOSE ANALOG OUTPUT** prompt select 1: 4mA, select 2: 20mA, or select 3: “Other” to manually input a value.
 - a. If you are performing a loop test to verify the output of a transmitter, enter a value between 4 and 20 mA.
 - b. If you are performing a loop test to verify alarm levels, enter the milliamp value representing an alarm state (see Table 3-1, Table 3-2, and Table 3-3 on page 3-13).
5. Check the reference meter installed in the test loop to verify that it displays the commanded output value.
 - a. If the values match, the transmitter and the loop are configured and functioning properly.
 - b. If the values do not match, the current meter may be attached to the wrong loop there may be a fault in the wiring, the transmitter may require an output trim, or the reference meter may be malfunctioning.

After completing the test procedure, the display returns to the loop test screen to choose another output value or to end loop testing.

AMS v7.0

Right click on the device and select “Diagnostics and Test,” then “Loop test” from the menu.

1. Connect a reference meter to the transmitter by either connecting the meter to the test terminals on the terminal block, or shunting transmitter power through the meter at some point in the loop.
2. Click **Next** after setting the control loop to manual.
3. Select desired analog output level. Click **Next**.
4. Click **Next** to acknowledge output being set to desired level.

Rosemount 3051S Series

5. Check the reference meter installed in the test loop to verify that it displays the commanded output value.
 - a. If the values match, the transmitter and the loop are configured and functioning properly.
 - b. If the values do not match, the current meter may be attached to the wrong loop there may be a fault in the wiring, the transmitter may require an output trim, or the reference meter may be malfunctioning.

After completing the test procedure, the display returns to the loop test screen to choose another output value or to end loop testing.

6. Select **End** and click **Next** to end loop testing.
7. Select **Next** to acknowledge the loop can be returned to automatic control.
8. Select **Finish** to acknowledge the method is complete.

ADVANCED FUNCTIONS FOR HART PROTOCOL

Saving, Recalling, and Cloning Configuration Data

Fast Keys	left arrow, 1, 2
-----------	------------------

Use the cloning feature of the HART Communicator or the AMS "User Configuration" feature to configure several 3051S transmitters similarly. Cloning involves configuring a transmitter, saving the configuration data, then sending a copy of the data to a separate transmitter. Several possible procedures exist when saving, recalling, and cloning configuration data. For complete instructions refer to the HART Communicator manual (publication no. 00809-0100-4276) or AMS on-line guides. One common method is as follows:

HART Communicator v1.8

1. Confirm and apply configuration changes to the first transmitter.

NOTE

If transmitter configuration has not been modified, "SAVE" option in step 2 will be disabled

2. Save the configuration data:
 - a. Select "SAVE" from the bottom of the HART Communicator screen.
 - b. Choose to save your configuration in either the "Internal Flash" (default) or the "Configuration EM" (Configuration Expansion Module).
 - c. Enter the name for this configuration file. The default name is the transmitter tag number.
 - d. Select "SAVE".
3. Power the receiving transmitter and connect with HART Communicator.
4. Access the HART Application menu by pressing the LEFT ARROW from the HOME/ONLINE screen.

5. Locate the saved transmitter configuration file.
 - a. Select "Offline"
 - b. Select "Saved Configuration"
 - c. Select either "Internal Flash Contents" or "Configuration EM Contents" depending on where the configuration was stored per step 2b.
6. Use the DOWN ARROW to scroll through the list of configurations in the memory module, and use the RIGHT ARROW to select and retrieve the desired configuration.
7. Select "Send" to transfer the configuration to the receiving transmitter.
8. Select "OK" after the control loop is set to manual.
9. After the configuration has been sent, select "OK" to acknowledge that the loop can be returned to automatic control.

When finished, the HART Communicator informs you of the status. Repeat steps 3 through 9 to configure another transmitter.

NOTE

The transmitter receiving cloned data must have the same software version (or later) as the original transmitter.

AMS v7.0 creating a Reusable Copy

To create a reusable copy of a configuration perform the following procedure:

1. Completely configure the first transmitter.
2. Select View then User Configuration View from the menu bar (or click the toolbar button).
3. In the User Configuration window, right click and select New from the context menu.
4. In the New window, select a device from the list of templates shown, and click **OK**.
5. The template is copied into the User Configurations window, with the tag name highlighted; rename it as appropriate and press **Enter**.

NOTE

A device icon can also be copied by dragging and dropping a device template or any other device icon from AMS Explorer or Device Connection View into the User Configurations window.

The "Compare Configurations" window appears, showing the Current values of the copied device on one side and mostly blank fields on the other (User Configuration) side.

6. Transfer values from the current configuration to the user configuration as appropriate or enter values by typing them into the available fields.
7. Click Apply to apply the values, or click **OK** to apply the values and close the window.

Rosemount 3051S Series

AMS v7.0 Applying a User Configuration

Any amount of user configurations can be created for the application. They can also be saved, and applied to connected devices or to devices in the Device List or Plant Database.

NOTE

When using AMS Revision 6.0 or later, the device to which the user configuration is applied must be the same model type as the one created in the user configuration. When using AMS Revision 5.0 or earlier, the same model type and revision number are required.

To apply a user configuration perform the following procedure:

1. Select the desired user configuration in the User Configurations window.
2. Drag the icon onto a like device in AMS Explorer or Device Connection View. The Compare Configurations window opens, showing the parameters of the target device on one side and the parameters of the user configuration on the other.
3. Transfer parameters from the user configuration to the target device as desired, Click **OK** to apply the configuration and close the window.

Burst Mode

Fast Keys	1, 4, 3, 3, 3
-----------	---------------

When configured for burst mode, the 3051S provides faster digital communication from the transmitter to the control system by eliminating the time required for the control system to request information from the transmitter. Burst mode is compatible with the analog signal. Because the HART protocol features simultaneous digital and analog data transmission, the analog value can drive other equipment in the loop while the control system is receiving the digital information. Burst mode applies only to the transmission of dynamic data (pressure and temperature in engineering units, pressure in percent of range, and/or analog output), and does not affect the way other transmitter data is accessed.

Access to information other than dynamic transmitter data is obtained through the normal poll/response method of HART communication. A HART Communicator, AMS or the control system may request any of the information that is normally available while the transmitter is in burst mode. Between each message sent by the transmitter, a short pause allows the HART Communicator, AMS or a control system to initiate a request. The transmitter will receive the request, process the response message, and then continue "bursting" the data approximately three times per second.

HART Communicator v1.8

To configure the transmitter for burst mode, perform the following step:

1. From the HOME screen, enter the fast key sequence "Burst Mode."

AMS v7.0

Right click on the device and select "Configure" from the menu.

1. In the “HART” tab, use the drop down menu to select “Burst Mode ON or OFF.” For “Burst option” select the desired properties from the drop down menu. Burst options are as follows:
 - PV
 - % range/current
 - Process vars/crnt
 - Process variables
2. After selecting options click **Apply**.
3. After carefully reading the warning provided, select **yes**.

MULTIDROP COMMUNICATION

Multidropping transmitters refers to the connection of several transmitters to a single communications transmission line. Communication between the host and the transmitters takes place digitally with the analog output of the transmitters deactivated. With smart communications protocol, up to fifteen transmitters can be connected on a single twisted pair of wires, or over leased phone lines.


Multidrop installation requires consideration of the update rate necessary from each transmitter, the combination of transmitter models, and the length of the transmission line. Communication with transmitters can be accomplished with Bell 202 modems and a host implementing HART protocol. Each transmitter is identified by a unique address (1–15) and responds to the commands defined in the HART protocol. HART Communicators and AMS can test, configure, and format a multidropped transmitter the same way as a transmitter in a standard point-to-point installation.

Figure 3-5 shows a typical multidrop network. This figure is not intended as an installation diagram.

NOTE

A transmitter in multidrop mode has the analog output fixed at 4 mA. If a meter is installed to a transmitter in multidrop mode, it will alternate the display between “current fixed” and the specified meter output(s).

Figure 3-5. Typical Multidrop Network



Rosemount 3051S Series

The 3051S is set to address zero (0) at the factory, which allows operation in the standard point-to-point manner with a 4–20 mA output signal. To activate multidrop communication, the transmitter address must be changed to a number from 1 to 15. This change deactivates the 4–20 mA analog output, sending it to 4 mA. It also disables the failure mode alarm signal, which is controlled by the upscale/downscale switch/jumper position. Failure signals in multidropped transmitters are communicated through HART messages.

Changing a Transmitter Address

Fast Keys	1, 4, 3, 3, 1
-----------	---------------

To activate multidrop communication, the transmitter poll address must be assigned a number from 1 to 15, and each transmitter in a multidropped loop must have a unique poll address.

HART Communicator v1.8

1. From the **HOME** screen, enter the fast key sequence “Changing a Transmitter Address.”

AMS v7.0

Right click on the device and select “Configure” from the menu.

1. In the “HART” tab, in “ID” box, enter poll address located in the “Poll addr” box, click **Apply**.
2. After carefully reading the warning provided, select **yes**.

Communicating with a Multidropped Transmitter

Fast Keys	Left arrow, 3, 1, 1
-----------	---------------------

HART Communicator v1.8

To communicate with a multidropped transmitter, configure the HART Communicator to poll for a non-zero address.

1. From the **HOME** screen, enter the fast key sequence “Communicating with a Multidropped Transmitter.”
2. On the polling menu, scroll down and select “Digital Poll.” In this mode, the HART Communicator automatically polls for devices at addresses 0-15 upon start up.

AMS v7.0

Click on the HART modem icon and select “Scan All Devices.”

Polling a Multidropped Transmitter

Fast Keys	Left arrow, 3, 1
-----------	------------------

Polling a multidropped loop determines the model, address, and number of transmitters on the given loop.

HART Communicator v1.8

1. From the **HOME** screen, enter the fast key sequence “Polling a Multidropped Transmitter.”

AMS v7.0

Click on the HART modem icon and select “Scan All Devices.”

Section 4 Operation and Maintenance

Overview	page 4-1
Calibration for HART Protocol	page 4-1
Field Upgrades	page 4-14

OVERVIEW

This section contains information on commissioning and operating 3051S Pressure Transmitters. Tasks that should be performed on the bench prior to installation are explained in this section.

Instructions for performing configuration functions are given for HART Communicator version 1.8 and AMS version 7.0. For convenience, HART Communicator fast key sequences are labeled “Fast Keys” for each software function below the appropriate headings.

CALIBRATION FOR HART PROTOCOL

Calibrating a 3051S transmitter may include the following procedures:

- **Rerange:** Sets the 4 and 20 mA points at required pressures.
- **Sensor Trim:** Adjusts the position of the factory sensor characterization curve to optimize performance over a specified pressure range, or to adjust for mounting effects.
- **Analog Output Trim:** Adjusts the analog output to match the plant standard or the control loop.

The 3051S SuperModule uses a microprocessor that contains information about the sensor’s specific characteristics in response to pressure and temperature inputs. A smart transmitter compensates for these sensor variations. The process of generating the sensor performance profile is called factory sensor characterization. Factory sensor characterization also provides the ability to readjust the 4 and 20 mA points without applying pressure to the transmitter.

Trim and rerange functions also differ. Reranging sets analog output to the selected upper and lower range points and can be done with or without an applied pressure. Reranging does not change the factory sensor characterization curve stored in the microprocessor. Sensor trimming requires an accurate pressure input and adds additional compensation that adjusts the position of the factory sensor characterization curve to optimize performance over a specific pressure range.

NOTE

Sensor trimming adjusts the position of the factory sensor characterization curve. It is possible to degrade performance of the transmitter if the trim is done improperly or with inaccurate equipment.

Rosemount 3051S Series

Table 4-1. Recommended Calibration Tasks

Transmitter	Bench Calibration Tasks	Field Calibration Tasks
3051S_CD 3051S_CG 3051S_L 3051S_TG, Range 1-4	<ol style="list-style-type: none"> 1. Set output configuration parameters: <ol style="list-style-type: none"> a. Set the range points. b. Set the output units. c. Set the output type. d. Set the damping value. 2. <i>Optional</i>: Perform a sensor trim. (Accurate pressure source required) 3. <i>Optional</i>: Perform an analog output trim. (Accurate multimeter required) 	<ol style="list-style-type: none"> 1. Reconfigure parameters if necessary. 2. Zero trim the transmitter to compensate for mounting effects or static pressure effects.
3051S_CA 3051S_TA 3051S_TG, Range 5	<ol style="list-style-type: none"> 1. Set output configuration parameters: <ol style="list-style-type: none"> a. Set the range points. b. Set the output units. c. Set the output type. d. Set the damping value. 2. <i>Optional</i>: Perform a sensor trim if equipment available (accurate absolute pressure source required), otherwise perform the low trim value section of the sensor trim procedure. 3. <i>Optional</i>: Perform an analog output trim (Accurate multimeter required) 	<ol style="list-style-type: none"> 1. Reconfigure parameters if necessary. 2. Perform low trim value section of the sensor trim procedure to correct for mounting position effects.

NOTE:

A HART communicator is required for all sensor and output trim procedures.

Rosemount 3051S_C Range 4 and Range 5 transmitters require a special calibration procedure when used in differential pressure applications under high static line pressure (see "Compensating for Line Pressure" on page 4-10).

Rosemount 3051S_TG Range 5 transmitters use an absolute sensor that requires an accurate absolute pressure source to perform the optional sensor trim.

Calibration Overview

Complete calibration of the 3051S pressure transmitter involves the following tasks:

Configure the analog output parameters

- Set Process Variable Units (page 3-8)
- Set Output Type (page 3-8)
- Rerange (page 3-9)
- Set Damping (page 3-11)

Calibrate the sensor

- Sensor Trim (page 4-6)
- Zero Trim (page 4-6)

Calibrate the 4–20 mA output

- 4–20 mA Output Trim (page 4-8); or
- 4–20 mA Output Trim Using Other Scale (page 4-9)


Figure 4-1 on page 4-3 illustrates 3051S transmitter data flow. Data flow can be summarized in four major steps:

1. A change in pressure is measured by a change in the sensor output (Sensor Signal).
2. The sensor signal is converted to a digital format that is understood by the microprocessor (Analog-to-Digital Signal Conversion).
3. Corrections are performed in the microprocessor to obtain a digital representation of the process input (Digital PV).
4. The Digital PV is converted to an analog value (Digital-to-Analog Signal Conversion).

Figure 4-1 also identifies the approximate transmitter location for each calibration task. Data flows from left to right, and a parameter change affects all values to the right of the changed parameter.

Not all calibration procedures should be performed for each 3051S transmitter. Some procedures are appropriate for bench calibration, but should not be performed during field calibration. Table 4-1 identifies the recommended calibration procedures for each type of 3051S transmitter for bench or field calibration.

Figure 4-1. Transmitter Data Flow with Calibration Options



NOTE
 Value on communicator screen PV line should equal the input pressure.
 Value on communicator screen AO line should equal the output device reading.

Rosemount 3051S Series

Determining Calibration Frequency

Calibration frequency can vary greatly depending on the application, performance requirements, and process conditions. Use the following procedure to determine calibration frequency that meets the needs of your application.

1. Determine the performance required for your application.
2. Determine the operating conditions.
3. Calculate the Total Probable Error (TPE).
4. Calculate the stability per month.
5. Calculate the calibration frequency.

Sample Calculation

Step 1: Determine the performance required for your application.

Required Performance: 0.30% of span

Step 2: Determine the operating conditions.

Transmitter: 3051S_CD, Range 2A [URL=250 inH₂O(623 mbar)], classic performance

Calibrated Span: 150 inH₂O (374 mbar)

Ambient Temperature Change: ± 50 °F (28 °C)

Line Pressure: 500 psig (34,5 bar)

Step 3: Calculate total probable error (TPE).

$$TPE = \sqrt{(\text{ReferenceAccuracy})^2 + (\text{TemperatureEffect})^2 + (\text{StaticPressureEffect})^2} = 0.112\% \text{ of span}$$

Where:

Reference Accuracy = ± 0.055% of span

Ambient Temperature Effect =

$$\pm \left(\frac{0.0125 \times \text{URL}}{\text{Span}} + 0.0625 \right) \text{ per } 50 \text{ }^\circ\text{F} = \pm 0.0833\% \text{ of span}$$

Span Static Pressure Effect⁽¹⁾ =

$$0.1\% \text{ reading per } 1000 \text{ psi (69 bar)} = \pm 0.05\% \text{ of span at maximum span}$$

(1) Zero static pressure effect removed by zero trimming at line pressure.

Step 4: Calculate the stability per month.

$$\text{Stability} = \pm \left[\frac{(0.125 \times \text{URL})}{\text{Span}} \right] \% \text{ of span for 5 years} = \pm 0.0035\% \text{ of span per month}$$

Step 5: Calculate calibration frequency.

$$\text{Cal. Freq.} = \frac{(\text{Req. Performance} - \text{TPE})}{\text{Stability per Month}} = \frac{(0.3\% - 0.112\%)}{0.0035\%} = 54 \text{ months}$$

Choosing a Trim Procedure

To decide which trim procedure to use, you must first determine whether the analog-to-digital section or the digital-to-analog section of the transmitter electronics needs trimming. Refer to Figure 4-1 and perform the following procedure:

1. Connect a pressure source, a HART Communicator or AMS, and a digital readout device to the transmitter.
2. Establish communication between the transmitter and the HART Communicator.
3. Apply pressure equal to the upper range point pressure.
4. Compare the applied pressure to the pressure process variable value on the Process Variables menu on the HART Communicator or the Process Variables screen in AMS. For instructions on how to access process variables, see page 3-7 of Section 3: Configuration.
 - a. If the pressure reading does not match the applied pressure (with high-accuracy test equipment), perform a sensor trim. See “Sensor Trim Overview” on page 4-5 to determine which trim to perform.
5. Compare the Analog Output (AO) line, on the HART Communicator or AMS, to the digital readout device.
 - a. If the AO reading does not match the digital readout device (with high-accuracy test equipment), perform an analog output trim. See “Analog Output Trim” on page 4-7.

Sensor Trim Overview

Trim the sensor using either sensor or zero trim functions. Trim functions vary in complexity and are application-dependent. Both trim functions alter the transmitter’s interpretation of the input signal.

Zero trim is a single-point offset adjustment. It is useful for compensating for mounting position effects and is most effective when performed with the transmitter installed in its final mounting position. Since this correction maintains the slope of the characterization curve, it should not be used in place of a sensor trim over the full sensor range.

When performing a zero trim with a manifold, refer to Manifold Operation on page 2-23.

NOTE

Do not perform a zero trim on 3051S Absolute pressure transmitters. Zero trim is zero based, and absolute pressure transmitters reference absolute zero. To correct mounting position effects on a 3051S Absolute Pressure Transmitter, perform a low trim within the sensor trim function. The low trim function provides an offset correction similar to the zero trim function, but it does not require zero-based input.

Sensor trim is a two-point sensor calibration where two end-point pressures are applied, and all output is linearized between them. Always adjust the low trim value first to establish the correct offset. Adjustment of the high trim value provides a slope correction to the characterization curve based on the low trim value. The trim values allow you to optimize performance over your specified measuring range at the calibration temperature.

Rosemount 3051S Series

Zero Trim

Fast Keys	1, 2, 3, 3, 1
-----------	---------------

NOTE

The transmitter must be within three percent of true zero (zero-based) in order to calibrate with zero trim function.

HART Communicator

Calibrate the sensor with a HART Communicator using the zero trim function as follows:

1. Vent the transmitter and attach a HART Communicator to the measurement loop.
2. From the **HOME** screen, follow the fast key sequence “Zero Trim.”
3. Follow the commands provided by the HART Communicator to complete the zero trim adjustment.

AMS

Right click on the device and select “Calibrate,” then “Zero trim” from the menu.

1. Click **Next** after setting the control loop to manual.
2. Click **Next** to acknowledge warning.
3. Click **Next** after applying appropriate pressure to sensor.
4. Select **Next** to acknowledge the loop can be returned to automatic control.
5. Select **Finish** to acknowledge the method is complete.

Sensor Trim

Fast Keys	1, 2, 3, 3
-----------	------------

NOTE

Use a pressure input source that is at least three times more accurate than the transmitter, and allow the input pressure to stabilize for ten seconds before entering any values.

HART Communicator

To calibrate the sensor with a HART Communicator using the sensor trim function, perform the following procedure:

1. Assemble and power the entire calibration system including a transmitter, HART Communicator, power supply, pressure input source, and readout device.
2. From the **HOME** screen, enter the fast key sequence under “Sensor Trim.”
3. Select 2: Lower sensor trim. The lower sensor trim value should be the sensor trim point that is closest to zero.

NOTE

Select pressure input values so that lower and upper values are equal to or outside the 4 and 20 mA points. Do not attempt to obtain reverse output by reversing the high and low points. This can be done by going to “Rerange” on page 3-9 of Section 3: Configuration. The transmitter allows approximately five percent deviation.

4. Follow the commands provided by the HART Communicator to complete the adjustment of the lower value.
5. Repeat the procedure for the upper value, replacing 2: Lower sensor trim with 3: Upper sensor trim in Step 3.

AMS

Right click on the device and select “Calibrate,” then “Sensor trim” from the menu.

1. Select “Lower sensor trim.” The lower sensor trim value should be the sensor trim point that is closest to zero.
2. Click **Next** after setting the control loop to manual.
3. Click **Next** after applying appropriate pressure to sensor.
4. Select **Next** to acknowledge the loop can be returned to automatic control.
5. Select **Finish** to acknowledge the method is complete.
6. Right click on the device and select “Calibrate,” select “Sensor trim” from the menu.
7. Select “Upper sensor trim” and repeat steps 2-5.

**Recall Factory Trim—
Sensor Trim**

Fast Keys	1, 2, 3, 4, 1
-----------	---------------

The Recall Factory Trim—Sensor Trim command allows the restoration of the as-shipped factory settings of the sensor trim. This command can be useful for recovering from an inadvertent zero trim of an absolute pressure unit or inaccurate pressure source.

HART Communicator

Enter the fast key sequence “Recall Factory Trim—Sensor Trim.”

AMS

Right click on the device and select “Calibrate,” then “Recall Factory Trim” from the menu.

1. Click **Next** after setting the control loop to manual.
2. Select “Sensor trim” under “Trim to recall” and click **Next**.
3. Click **Next** to acknowledge restoration of trim values is complete.
4. Select **Next** to acknowledge the loop can be returned to automatic control.
5. Select **Finish** to acknowledge the method is complete.

Analog Output Trim

The Analog Output Trim commands allow you to adjust the transmitter’s current output at the 4 and 20 mA points to match the plant standards. This command adjusts the digital to analog signal conversion (see Figure 4-1 on page 4-3).

Rosemount 3051S Series

Digital-to-Analog Trim

Fast Keys	1, 2, 3, 2, 1
-----------	---------------

HART Communicator

To perform a digital-to-analog trim with a HART Communicator, perform the following procedure.

1. From the **HOME** screen, enter the fast key sequence “Digital-to-Analog Trim.” Select **OK** after setting the control loop to manual, see “Setting the Loop to Manual” on page 3-2.
2. Connect an accurate reference milliamp meter to the transmitter at the **CONNECT REFERENCE METER** prompt. Connect the positive lead to the positive terminal and the negative lead to the test terminal in the transmitter terminal compartment, or shunt power through the reference meter at some point.
3. Select **OK** after connecting the reference meter.
4. Select **OK** at the **SETTING FLD DEV OUTPUT TO 4 MA** prompt. The transmitter outputs 4.0 mA.
5. Record the actual value from the reference meter, and enter it at the **ENTER METER VALUE** prompt. The HART Communicator prompts you to verify whether or not the output value equals the value on the reference meter.
6. Select 1: Yes, if the reference meter value equals the transmitter output value, or 2: No if it does not.
 - a. If 1 is selected: Yes, proceed to Step 7.
 - b. If 2 is selected: No, repeat Step 5.
7. Select **OK** at the **SETTING FLD DEV OUTPUT TO 20 MA** prompt, and repeat Steps 5 and 6 until the reference meter value equals the transmitter output value.
8. Select **OK** after the control loop is returned to automatic control.

AMS

Right click on the device and select “Calibrate,” then “D/A Trim” from the menu.

1. Click **Next** after setting the control loop to manual.
2. Click **Next** after connecting the reference meter.
3. Click **Next** at the “Setting fld dev output to 4mA” screen.
4. Record the actual value from the reference meter, and enter it at the “Enter meter value” screen and click **Next**.
5. Select **Yes**, if the reference meter value equals the transmitter output value, or **No** if it does not. Click **Next**.
 - a. If Yes is selected, proceed to Step 6.
 - b. If No is selected, repeat Step 4.
6. Click **Next** at the “Setting fld dev output to 20mA” screen.
7. Repeat Step 4 - Step 5 until the reference meter equals the transmitter output value.
8. Select **Next** to acknowledge the loop can be returned to automatic control.
9. Select **Finish** to acknowledge the method is complete.

Digital-to-Analog Trim Using Other Scale

Fast Keys	1, 2, 3, 2, 2
-----------	---------------

The Scaled D/A Trim command matches the 4 and 20 mA points to a user selectable reference scale other than 4 and 20 mA (for example, 1 to 5 volts if measuring across a 250 ohm load, or 0 to 100 percent if measuring from a Distributed Control System (DCS)). To perform a scaled D/A trim, connect an accurate reference meter to the transmitter and trim the output signal to scale, as outlined in the Output Trim procedure.

NOTE

Use a precision resistor for optimum accuracy. If you add a resistor to the loop, ensure that the power supply is sufficient to power the transmitter to a 20 mA output with additional loop resistance.

HART Communicator

Enter the fast key sequence “Digital-to-Analog Trim Using Other Scale.”

AMS

Right click on the device and select “Calibrate,” then “Scaled D/A trim” from the menu.

1. Click **Next** after setting the control loop to manual.
2. Select **Change** to change scale, click **Next**.
3. Enter Set scale-Lo output value, click **Next**.
4. Enter Set scale-Hi output value, click **Next**.
5. Click **Next** to proceed with Trim.
6. Click **Next** after connecting the reference meter.
7. Click **Next** at the “Setting fld dev output to 4 mA” screen.
8. Record the actual value from the reference meter, and enter it at the “Enter meter value” screen and click **Next**.
9. Select **Yes**, if the reference meter value equals the transmitter output value, or **No** if it does not. Click **Next**.
 - a. If Yes is selected, proceed to Step 10.
 - b. If No is selected, repeat Step 8.
10. Click **Next** at the “Setting fld dev output to 20mA” screen.
11. Repeat Step 8 - Step 9 until the reference meter equals the transmitter output value.
12. Select **Next** to acknowledge the loop can be returned to automatic control.
13. Select **Finish** to acknowledge the method is complete.

Rosemount 3051S Series

Recall Factory Trim— Analog Output

Fast Keys	1, 2, 3, 4, 2
-----------	---------------

The Recall Factory Trim—Analog Output command allows the restoration of the as-shipped factory settings of the analog output trim. This command can be useful for recovering from an inadvertent trim, incorrect Plant Standard or faulty meter.

HART Communicator

Enter the fast key sequence “Recall Factory Trim—Analog Output.”

AMS

Right click on the device and select “Calibrate,” then “Recall Factory Trim” from the menu.

1. Click **Next** after setting the control loop to manual.
2. Select “Analog output trim” under “Trim to recall” and click **Next**.
3. Click **Next** to acknowledge restoration of trim values is complete.
4. Select **Next** to acknowledge the loop can be returned to automatic control.
5. Select **Finish** to acknowledge the method is complete.

Compensating for Line Pressure

The Rosemount 3051S Range 4 and 5 pressure transmitters require a special calibration procedure when used in differential pressure applications. The purpose of this procedure is to optimize transmitter performance by reducing the effect of static line pressure in these applications. The 3051S differential pressure transmitters (Ranges 0, 1, 2, and 3) do not require this procedure because optimization occurs in the sensor.

Applying high static pressure to the 3051S Range 4 and Range 5 pressure transmitters causes a systematic shift in the output. This shift is linear with static pressure; correct it by performing the “Sensor Trim” procedure on page 4-6.

The following specifications show the static pressure effect for the 3051S Range 4 and Range 5 transmitters used in differential pressure applications:

Zero Effect:

± 0.1% of the upper range limit per 1000 psi (69 bar) for line pressures from 0 to 2000 psi (0 to 138 bar)

For line pressures above 2000 psi (138 bar), the zero effect error is ± 0.2% of the upper range limit plus an additional ± 0.2% of upper range limit error for each 1000 psi (69 bar) of line pressure above 2000 psi (138 bar).

Example: Line pressure is 3000 psi (207 bar). Zero effect error calculation:

$$\pm \{0.2 + 0.2 \times [3 \text{ kpsi} - 2 \text{ kpsi}]\} = \pm 0.4\% \text{ of the upper range limit}$$

Span Effect:

Correctable to ±0.2% of reading per 1000 psi (69 bar) for line pressures from 0 to 3626 psi (0 to 250 bar)

The systematic span shift caused by the application of static line pressure is -1.00% of reading per 1000 psi (69 bar) for Range 4 transmitters, and -1.25% of reading per 1000 psi (69 bar) for Range 5 transmitters.

Use the following example to compute corrected input values.

Example

A transmitter with model number 3051S_CD4 will be used in a differential pressure application where the static line pressure is 1200 psi (83 bar). The transmitter output is ranged with 4 mA at 500 inH₂O (1,2 bar) and 20 mA at 1500 inH₂O (3,7 bar).

To correct for systematic error caused by high static line pressure, first use the following formulas to determine corrected values for the low trim and high trim.

$$LT = LRV + S \times (LRV) \times P$$

Where: LT = Corrected Low Trim Value
 LRV = Lower Range Value
 S = -(Span shift per specification)
 P = Static Line Pressure

$$HT = URV + S \times (URV) \times P$$

Where: HT = Corrected High Trim Value
 URV = Upper Range Value
 S = -(Span shift per specification)
 P = Static Line Pressure

In this example:

URV = 1500 inH₂O (3.74 bar)
LRV = 500 inH₂O (1.25 bar)
P = 1200 psi (82.74 bar)
S = ± 0.01/1000

To calculate the low trim (LT) value:

LT = 500 + (0.01/1000)(500)(1200)
LT = 506 inH₂O (1.26 bar)

To calculate the high trim (HT) value:

HT = 1500 + (0.01/1000)(1500)(1200)
HT = 1518 inH₂O (3.78 bar)

Complete a 3051S sensor trim and enter the corrected values for low trim (LT) and high trim (HT), refer to "Sensor Trim" on page 4-6.

Enter the corrected input values for low trim and high trim through the HART Communicator keypad after you apply the value of pressure as the transmitter input.

NOTE

After sensor trimming 3051S Range 4 and 5 transmitters for high differential pressure applications, verify that the 4 and 20 mA points are at values using the HART Communicator. For the example above, this would be 500 and 1500 respectively. The zero effect can be eliminated by doing a zero sensor trim at line pressure after installation without affecting the completed calibration.

Rosemount 3051S Series

Diagnostic Messages

In addition to output, the LCD display displays abbreviated operation, error, and warning messages for troubleshooting. Messages appear according to their priority; normal operating messages appear last. To determine the cause of a message, use a HART Communicator or AMS to further interrogate the transmitter. A description of each LCD diagnostic message follows.

Error Indicator

An error indicator message appears on the LCD display to warn of serious problems affecting the operation of the transmitter. The meter displays an error message until the error condition is corrected, "ERROR" appears at the bottom of the display, and analog output is driven to the specified alarm level. No other transmitter information is displayed during an alarm condition.

FAIL MODULE

The SuperModule is malfunctioning. Possible sources of problems include:

Pressure or temperature updates are not being received in the SuperModule.

A non-volatile memory fault that will affect transmitter operation has been detected in the module by the memory verification routine.

Some non-volatile memory faults are user-repairable. Use a HART Communicator or AMS to diagnose the error and determine if it is repairable. Any error message that ends in "Factory" is not repairable. In cases of non-user-repairable errors, replace the SuperModule. See "Disassembly Procedures" on page 5-3.

FAIL CONFIG

A memory fault has been detected in a location that could effect transmitter operation, and is user-accessible. To correct this problem, use a HART Communicator or AMS to interrogate and reconfigure the appropriate portion of the transmitter memory.

Warnings

Warnings appear on the LCD display to alert you of user-repairable problems with the transmitter, or current transmitter operations. Warnings appear alternately with other transmitter information until the warning condition is corrected or the transmitter completes the operation that warrants the warning message.

PV LIMIT

The primary variable read by the transmitter is outside of the transmitter's range.

NONPV LIMIT

A non-primary variable read by the transmitter is outside of the transmitter's range.

CURR SAT

The primary variable read by the module is outside of the specified range, and the analog output has been driven to saturation levels.

XMRT INFO

A non-volatile memory fault has been detected in the transmitter memory by the memory verification routine. The memory fault is in a location containing transmitter information. To correct this problem, use a HART Communicator or AMS to interrogate and reconfigure the appropriate portion of the transmitter memory. This warning does not effect the transmitter operation.

PRESS ALERT

A HART alert when the pressure variable read by the transmitter is outside of the user set alert limits.

TEMP ALERT

A HART alert when the sensor temperature variable read by the transmitter is outside of the user set alert limits.

Operation

Normal operation messages appear on the LCD display to confirm actions or inform you of transmitter status. Operation messages are displayed with other transmitter information, and warrant no action to correct or alter the transmitter settings.

LOOP TEST

A loop test is in progress. During a loop test or 4–20 mA trim, the analog output is set to a fixed value. The meter display alternates between the current selected in milliamps and “LOOP TEST.”

ZERO PASS

The zero value, set with the local zero adjustment button, has been accepted by the transmitter, and the output should change to 4 mA.

ZERO FAIL

The zero value, set with the local zero adjustment button, exceeds the maximum range down allowed for a particular range, or the pressure sensed by the transmitter exceeds the sensor limits.

SPAN PASS

The span value, set with the local span adjustment button, has been accepted by the transmitter, and the output should change to 20 mA.

SPAN FAIL

The span value, set with the local span adjustment button, exceeds the maximum range down allowed for a particular range, or the pressure sensed by the transmitter exceeds the sensor limits.

KEYS DISABL

This message appears during reranging with the integral zero and span buttons and indicates that the transmitter local zero and span adjustments have been disabled. The adjustments have been disabled by software commands from the HART Communicator or AMS. Keys are disabled when write protect jumper is “ON.” If alarm and security adjustments are not installed, the transmitter will operate normally with the default alarm condition alarm high and the security off.


STUCK KEY

The zero or span button is stuck in the depressed state or pushed too long.

Rosemount 3051S Series

FIELD UPGRADES

Labeling

 Each housing and each SuperModule is labeled individually, so it is imperative that the approval codes on each label match exactly during upgrade. The label on the SuperModule reflects the replacement model code for reordering an assembled unit. The housing labeling will only reflect the approvals and communication protocol of the housing.

Upgrading Electronics

The PlantWeb housing allows for electronics upgrades. Different electronics assemblies provide new functionality and are easily interchanged for upgrade. Keyed slots guide the assemblies into place, and assemblies are secured with two provided screws. If the transmitter you are intending to upgrade does not have a PlantWeb housing, refer to the spare parts section on page A-38 for ordering information.

The D1 option is available for local hardware adjustments. This option is available for both the PlantWeb and Junction Box housings. In order to use zero, span, alarm and security functions, replace the existing PlantWeb assembly with the Hardware Adjustment Interface Assembly (p/n 03151-9017-0001). Install the LCD display or hardware adjustment module to activate the hardware adjustments.

The DA1 option is available for Advanced HART Diagnostics. This option requires the use of the PlantWeb housing. In order to gain full access to the Advanced HART Diagnostic capabilities, simply add the 3051S HART Diagnostics Electronics assembly (p/n 03151-9070-0001). Before replacing the existing assembly with the new 3051S Diagnostics Electronics assembly, record the transmitter configuration. Transmitter configuration data must be reentered after adding the Advanced HART Diagnostics electronics assembly before putting the transmitter back into operation.

Refer to "Disassembly Procedures" on page 5-3 for information on assembly.

Section 5 Troubleshooting

Overview	page 5-1
Safety Messages	page 5-1
Disassembly Procedures	page 5-3
Reassembly Procedures	page 5-5

OVERVIEW

Table 5-1 provides summarized maintenance and troubleshooting suggestions for the most common operating problems.

If you suspect malfunction despite the absence of any diagnostic messages on the HART Communicator display, follow the procedures described here to verify that transmitter hardware and process connections are in good working order. Always deal with the most likely checkpoints first.

SAFETY MESSAGES

Procedures and instructions in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that raises potential safety issues is indicated by a warning symbol (⚠). Refer to the following safety messages before performing an operation preceded by this symbol.

Warnings (⚠)


⚠ WARNING
<p>Explosions can result in death or serious injury.</p> <ul style="list-style-type: none">• Do not remove the transmitter covers in explosive environments when the circuit is live.• Transmitter covers must be fully engaged to meet explosion proof requirements.• Before connecting a communicator in an explosive atmosphere, make sure that the instruments in the loop are installed according to intrinsically safe or nonincendive field wiring practices.
<p>Improper installation or repair of the SuperModule with high pressure option (P0) could result in death or serious injury.</p> <ul style="list-style-type: none">• For safe assembly, the high pressure SuperModule must be installed with ASTM A193 Class 2 Grade B8M Bolts and either a 305 manifold or a DIN-compliant traditional flange.
<p>Static electricity can damage sensitive components.</p> <ul style="list-style-type: none">• Observe safe handling precautions for static-sensitive components.

Rosemount 3051S Series

Table 5-1. Rosemount 3051S troubleshooting table

Symptom	Corrective Actions
Transmitter milliamp reading is zero	<ul style="list-style-type: none"> Verify power is applied to signal terminals Check power wires for reversed polarity Verify terminal voltage is 10.5 to 42.4 V dc Check for open diode across test terminal
Transmitter Not Communicating with HART Communicator	<ul style="list-style-type: none"> Verify the output is between 4 and 20 mA or saturation levels Verify clean DC Power to transmitter (Max AC noise 0.2 volts peak to peak) Check loop resistance, 250 Ω minimum (PS voltage -transmitter voltage/loop current) Check if unit is addressed properly
Transmitter milliamp reading is low or high	<ul style="list-style-type: none"> Verify applied pressure Verify 4 and 20 mA range points Verify output is not in alarm condition Verify if 4 – 20 mA output trim is required
Transmitter will not respond to changes in applied pressure	<ul style="list-style-type: none"> Check test equipment Check impulse piping or manifold for blockage Verify applied pressure is between the 4 and 20 mA set points Verify output is not in alarm condition Verify transmitter is not in Loop Test mode
Digital Pressure Variable reading is low or high	<ul style="list-style-type: none"> Check test equipment (verify accuracy) Check impulse piping for blockage or low fill in wet leg Verify transmitter is calibrated properly Verify pressure calculations for application
Digital Pressure Variable reading is erratic	<ul style="list-style-type: none"> Check application for faulty equipment in pressure line Verify transmitter is not reacting directly to equipment turning on/off Verify damping is set properly for application
Milliamp reading is erratic	<ul style="list-style-type: none"> Verify power source to transmitter has adequate voltage and current Check for external electrical interference Verify transmitter is properly grounded Verify shield for twisted pair is only grounded at one end
Transmitter output is normal but LCD is off Diagnostics indicates an LCD problem	<ul style="list-style-type: none"> Replace LCD

DISASSEMBLY PROCEDURES

 Do not remove the instrument cover in explosive atmospheres when the circuit is live.

Remove from Service

Be aware of the following:

- Follow all plant safety rules and procedures.
- Isolate and vent the process from the transmitter before removing the transmitter from service.
- Remove all electrical leads and conduit.
- Detach the process flange by removing the four flange bolts and two alignment screws that secure it.
- Do not scratch, puncture, or depress the isolating diaphragms.
- Clean isolating diaphragms with a soft rag and a mild cleaning solution, and rinse with clear water.
- Whenever you remove the process flange or flange adapters, visually inspect the Teflon o-rings. Replace the o-rings if they show any signs of damage, such as nicks or cuts. If they are not damaged, reuse them.

The 3051S transmitter is attached to the process connection by four bolts and two cap screws. Remove the bolts and separate the transmitter from the process connection. Leave the process connection in place and ready for re-installation.

The 3051S in-line transmitter is attached to the process by a single hex nut process connection. Loosen the hex nut to separate the transmitter from the process.

Remove Terminal Block


Electrical connections are located on the terminal block in the compartment labelled "FIELD TERMINALS."

PlantWeb Housing

Loosen the two small screws located at the 10 o'clock and 4 o'clock positions, and pull the entire terminal block out.

Junction Box Housing

Loosen the two small screws located at the 8 o'clock and 4 o'clock positions, and pull the entire terminal block out. This procedure will expose the SuperModule connector, see Figure 5-1.




Rosemount 3051S Series

Remove Interface Assembly

The Standard Interface Assembly, Adjustment Interface Assembly, Safety Certified Electronics Assembly (with yellow casing), or HART Diagnostics Electronics Assembly (black casing with white label) is located in the compartment opposite the terminal side in the PlantWeb housing. To remove the assembly, perform the following procedure.

1. Remove the housing cover opposite the field terminal side.
2. Remove the LCD Display or Adjustment Module, if applicable. To do this, hold in the two clips and pull outward. This will provide better access to the two screws located on the Standard Interface Assembly, Adjustment Interface Assembly, Safety Certified Electronics Assembly, or HART Diagnostics Electronics Assembly.
3. Loosen the two small screws located on the assembly in the 8 o'clock and 2 o'clock positions.
4. Pull out the assembly to expose and locate the SuperModule connector, see Figure 5-1.
5. Grasp the SuperModule connector and pull upwards (avoid pulling wires). Housing rotation may be required to access locking tabs. (PlantWeb housing only)

Figure 5-1. SuperModule connector view




Remove the SuperModule from the Housing

IMPORTANT

To prevent damage to the SuperModule cable, disconnect it from the PlantWeb assembly or Junction Box terminal block before you remove the SuperModule from the housing.

1. Loosen the housing rotation set screw with a $\frac{3}{32}$ -inch hex wrench, then rotate back one full turn.
2. Unscrew the housing from the SuperModule.



REASSEMBLY PROCEDURES

IMPORTANT

The V-Seal must be installed at the bottom of the housing.

Attach the SuperModule to the PlantWeb or Junction Box Housing



1. Apply a light coat of low temperature silicon grease to the SuperModule threads and o-ring.
2. Thread the housing completely onto the SuperModule. The housing must be no more than one full turn from flush with the SuperModule to comply with explosion-proof requirements.
3. Tighten the housing rotation set screw using a $\frac{3}{32}$ -inch hex wrench.

Install Interface Assembly in the PlantWeb Housing



1. Apply a light coat of low temperature silicon grease to the SuperModule connector.
2. Insert the SuperModule connector into the top of the SuperModule.
3. Gently slide the assembly into the housing, making sure the pins from the PlantWeb housing properly engage the receptacles on the assembly.
4. Tighten the captive mounting screws.
5. Attach the PlantWeb housing cover and tighten so that metal contacts metal to meet explosion-proof requirements.

Install the Terminal Block

PlantWeb Housing



1. Gently slide the terminal block into the housing, making sure the pins from the PlantWeb housing properly engage the receptacles on the terminal block.
2. Tighten the captive screws on the terminal block.
3. Attach the PlantWeb housing cover and tighten so that metal contacts metal to meet explosion-proof requirements.

Junction Box Housing



1. Apply a light coat of low temperature silicon grease to the SuperModule connector.
2. Insert the SuperModule connector into the top of the SuperModule.
3. Push the terminal block into the housing and hold for screw position alignment.
4. Tighten the captive mounting screws.
5. Attach the Junction Box housing cover and tighten so that metal contacts metal to meet explosion-proof requirements.

Rosemount 3051S Series

NOTE

If the installation uses a manifold, see “Rosemount 305, 306 and 304 Manifolds” on page 2-21.

Reassemble the Process Flange

1. Inspect the SuperModule Teflon O-rings. If the O-rings are undamaged, reusing them is recommended. If the O-rings are damaged (if they have nicks or cuts, for example), replace them with new O-rings.

NOTE

If replacing the O-rings, be careful not to scratch or deface the O-ring grooves or the surface of the isolating diaphragm when removing the damaged O-rings.

2. Install the process flange on the SuperModule. To hold the process flange in place, install the two alignment screws to finger tight (screws are not pressure retaining). Do not overtighten; this will affect module-to-flange alignment.
3. Install the appropriate flange bolts.
 - a. If the installation requires a $\frac{1}{4}$ -18 NPT connection(s), use four 1.75-in. flange bolts. Go to **step d**.
 - b. If the installation requires a $\frac{1}{2}$ -14 NPT connection(s), use four 2.88-in. process flange/adaptor bolts. For gage pressure configurations, use two 2.88-in. bolts and two 1.75-in. bolts. Go to **step c**.
 - c. Hold the flange adapters and adapter o-rings in place while finger-tightening the bolts. Go to **step e**.
 - d. Finger tighten the bolts.
 - e. Tighten the bolts to the initial torque value using a crossed pattern. See Table 5-2 for appropriate torque values.
 - f. Tighten the bolts to the final torque value using a crossed pattern. See Table 5-2 for appropriate torque values. When fully tightened, the bolts should extend through the top of the module housing.
 - g. If the installation uses a conventional manifold, then install flange adapters on the process end of the manifold using the 1.75-in. flange bolts supplied with the transmitter.

Table 5-2. Bolt Installation
Torque Values

Bolt Material	Initial Torque Value	Final Torque Value
CS-ASTM-A445 Standard	300 in-lb. (34 N-m)	650 in-lb. (73 N-m)
316 SST—Option L4	150 in-lb. (17 N-m)	300 in-lb. (34 N-m)
ASTM-A-193-B7M—Option L5	300 in-lb. (34 N-m)	650 in-lb. (73 N-m)
<i>Monel</i> [®] —Option L6	300 in-lb. (34 N-m)	650 in-lb. (73 N-m)
ASTM-A-453-660—Option L7	150 in-lb. (17 N-m)	300 in-lb. (34 N-m)
ASTM-A-193-B8M—Option L8	150 in-lb. (17 N-m)	300 in-lb. (34 N-m)

4. If you replaced the Teflon SuperModule o-rings, re-torque the flange bolts after installation to compensate for cold flow.
5. Install the drain/vent valve.
 - a. Apply sealing tape to the threads on the seat. Starting at the base of the valve with the threaded end pointing toward the installer, apply two clockwise turns of sealing tape.
 - b. Take care to place the opening on the valve so that process fluid will drain toward the ground and away from human contact when the valve is opened.
 - c. Tighten the drain/vent valve to 250 in-lb. (28.25 N-m).

NOTE

After replacing o-rings on Range 1 transmitters and re-installing the process flange, expose the transmitter to a temperature of 185 °F (85 °C) for two hours. Then re-tighten the flange bolts in a cross pattern, and again expose the transmitter to a temperature of 185 °F (85 °C) for two hours before calibration.

Rosemount 3051S Series

Reference Manual
00809-0100-4801, Rev CB
January 2007

Section 6 Safety Instrumented Systems

Safety Messages	page 6-1
Certification	page 6-2
3051S Safety Certified Identification	page 6-2
Installation	page 6-2
Commissioning	page 6-3
Operation and Maintenance	page 6-4
Specifications	page 6-5
Spare Parts	page 6-5

SAFETY MESSAGES

Procedures and instructions in this section may require special precautions to ensure the safety of the personnel performing the operations. Information that raises potential safety issues is indicated by a warning symbol (⚠). Refer to the following safety messages before performing an operation preceded by this symbol.

Warnings

⚠ WARNING
<p>Explosions can result in death or serious injury.</p> <ul style="list-style-type: none">• Do not remove the transmitter covers in explosive environments when the circuit is live.• Transmitter covers must be fully engaged to meet explosion-proof requirements.• Before connecting a communicator in an explosive atmosphere, make sure the instruments in the loop are installed in accordance with intrinsically safe or nonincendive field wiring practices.
⚠ WARNING
<p>Electrical shock can result in death or serious injury.</p> <ul style="list-style-type: none">• Avoid contact with the leads and terminals. High voltage that may be present on leads can cause electrical shock.

Rosemount 3051S Series

CERTIFICATION

The 3051S safety certified pressure transmitter is certified to:
Low Demand; Type B
SIL 2 Capability for hardware (single use transmitter)
SIL 3 Capability for software (multiple use transmitter)

3051S SAFETY CERTIFIED IDENTIFICATION

All 3051S transmitters must be identified as safety certified before installing into SIS systems.

NOTE

There are two versions of safety certified 3051S pressure transmitters. For transmitters with a yellow SIS circuit board installed, please refer to Manual Supplement 00809-0700-4801.

To identify a safety certified 3051S:

1. Connect a HART host to the transmitter.
2. Check the software to verify that the software revision is 7 or higher.

Fast Key Sequence - 1, 5

Revision #'s	
Fld Dev Rev	7
Software Rev	7
Hardware Rev	16

3. Verify that option code QT is included in the transmitter model code.

INSTALLATION

No special installation is required in addition to the standard installation practices outlined in this document. Always ensure a proper seal by installing the electronics housing cover(s) so that metal contacts metal if housing is used.

Environmental limits are available in the 3051S Product Data Sheet (document number 00813-0100-4801). This document can be found at www.rosemount.com/safety/certtechdocumentation.htm.

The loop should be designed so the terminal voltage does not drop below 10.5 Vdc when the transmitter output is 23.0 mA.

If hardware security switches are installed, the security switch should be in the "ON" position during normal operation. See Figure 6-2, "Security and alarm configuration (option D1)" on page 6-4. If hardware security switches are not installed, security should be "ON" in the software to prevent accidental or deliberate change of configuration data during normal operation.

COMMISSIONING

To commission the 3051S Safety Certified Transmitter, use the HART “Menu Tree” on page 3-5 and “Fast Key Sequence” on page 3-6.

NOTE

Transmitter output is not safety-rated during the following: configuration changes, multidrop, and loop test. Alternative means should be used to ensure process safety during transmitter configuration and maintenance activities.

For more information on the 375 Field Communicator see document 00809-0100-4276. AMS help can be found in the AMS on-line guides within the AMS system.

Damping


User-selected damping will affect the transmitters ability to respond to changes in the applied process. The *damping value + response time* should not exceed the loop requirements.

Fast Key Sequence - 1, 3, 6

Alarm and Saturation Levels

DCS or safety logic solver should be configured to match transmitter configuration. Figure 6-1 identifies the three alarm levels available and their operation values.

Figure 6-1. Alarm Levels



(1) Transmitter Failure, hardware or software alarm in LO position.
 (2) Transmitter Failure, hardware or software alarm in HI position.
 (3) High alarm must be at least 0.1 mA higher than the high saturation value.
 (4) Low alarm must be at least 0.1 mA lower than the low saturation value.

Setting the alarm values and direction varies whether the hardware switch option is installed. You can use a HART master or communicator to set the Alarm and Saturation values


Switches installed

1. If using a communicator, use the following fast key sequence to set the Alarm and Saturation values.
Alarm Levels - Fast Key; 1, 4, 2, 7, 7
Saturation Levels - Fast Key; 1, 4, 2, 7, 8
2. Manually set the direction for the Alarm to HI or LO using the ALARM switch as shown in Figure 6-2.

Switches not installed

3. If using a communicator, use the following fast key sequence to set the Alarm and Saturation values and the Alarm Direction:
Alarm Levels - Fast Key; 1, 4, 2, 7, 7
Saturation Levels - Fast Key; 1, 4, 2, 7, 8
Alarm Direction Fast Key; 1, 4, 2, 7, 6

Figure 6-2. Security and alarm configuration (option D1)



OPERATION AND MAINTENANCE

Proof Test

The following proof tests are recommended.

Proof test results and corrective actions taken must be documented at www.rosemount.com/safety/certtechdocumentation.htm (*Report a Failure button*) in the event that an error is found in the safety functionality.

Use "Fast Key Sequence" on page 3-6 to perform a Loop Test, Analog Output Trim, or Sensor Trim.

Proof Test 1

Conducting an analog output Loop Test satisfies the proof test requirements and will detect more than 52% of DU failures not detected by the 3051S_C or 3051S_L automatic diagnostics, and more than 62% of DU failures not detected by the 3051S_T automatic diagnostics.

Required tools: HART host/communicator and mA meter.

1. On HART host/communicator enter the Fast Key Sequence 1, 2, 2.
2. Select "4 Other."
3. Enter the milliampere value representing a high alarm state.
4. Check the reference meter to verify the mA output corresponds to the entered value.
5. Enter the milliampere value representing a low alarm state.
6. Check the reference meter to verify the mA output corresponds to the entered value.
7. Document the test results per your requirements.

Proof Test 2

This proof test, when combined with the Proof Test 1, will detect over 92% of DU failures not detected by the 3051S_C or 3051S_L automatic diagnostics, and over 95% of DU failures not detected by the 3051S_T automatic diagnostics.

Required tools: HART host/communicator and pressure calibration equipment.

1. Perform a minimum two point sensor calibration check using the 4-20mA range points as the calibration points.
2. Check the reference mA meter to verify the mA output corresponds to the pressure input value.
3. If necessary, use one of the "Trim" procedures on page 4-5.
4. Document the test results per your requirements.

NOTE

The user determines the proof test requirements for impulse piping.

Inspection

Visual Inspection

Not required

Special Tools

Not required

Product Repair

The 3051S is repairable by major component replacement.

All failures detected by the transmitter diagnostics or by the proof-test must be reported. Feedback can be submitted electronically at www.rosemount.com/safety/certtechdocumentation.htm (*Report a Failure button*).

SPECIFICATIONS

The 3051S must be operated in accordance to the functional and performance specifications provided in the 3051S Product Data Sheet (document number 00813-0100-4801).

Failure Rate Data

The FMEDA report includes failure rates and common cause Beta factor estimates.

The report is available at www.rosemount.com/safety/certtechdocumentation.htm.

Product Life

50 years – based on worst case component wear-out mechanisms – not based on wear-out of process wetted materials

Report any safety related product information at <http://www.rosemount.com/safety/certtechdocumentation.htm>.

SPARE PARTS

Additional spare parts are available in Appendix A: Specifications and Reference Data.

Rosemount 3051S Series

Reference Manual
00809-0100-4801, Rev CB
January 2007

Section 7 **Advanced HART Diagnostics**

Overview	page 7-1
HART Diagnostic User Interface	page 7-2
Statistical Process Monitoring	page 7-3
Variable Logging	page 7-19
Advanced Process Alerts	page 7-21
Rosemount 333 Hart Tri-Loop Configuration	page 7-24
Other Information	page 7-25

OVERVIEW

The 3051S Pressure Transmitter with Advanced HART Diagnostics is an extension of the Rosemount 3051S Scalable Pressure transmitter and takes full advantage of the architecture. The 3051S SuperModule™ Platform generates the pressure measurement. The Diagnostic Feature Board is mounted in the PlantWeb housing and plugs into the top of the SuperModule. The Diagnostics Feature Board communicates with the SuperModule and produces standard 4 – 20 mA and HART outputs while adding advanced diagnostic capability. The HART diagnostics are designated by the option code “DA1” in the model number. All options with the exception of the Foundation Fieldbus and Safety Instrumented Systems output codes, quick connect, and remote displays can be used with the Advanced HART Diagnostics Feature board.

The HART Diagnostic transmitter has four distinct diagnostic functions that can be used separately or in conjunction with each other to detect and alert users to conditions that were previously undetectable, or provide powerful troubleshooting tools.

1. Time Stamp – The HART Diagnostic Transmitter features an Operational Hours clock whose purpose is two-fold.
 - a. Provides user the total number of operating hours of the transmitter.
 - b. Provides an elapsed “Time Since” event indication or time stamping for all diagnostics.

All time values are non-volatile and displayed in the following format: yy:ddd:hh:mm:ss (years:days:hours:minutes:seconds). The time stamping capability significantly enhances the user’s ability to troubleshoot measurement issues, particularly transient events that may be too fast to capture with DCS or PLC trending or historian capabilities.

Rosemount 3051S Series

2. Statistical Process Monitoring (SPM) – The 3051S HART Diagnostic Transmitter features patented SPM technology to detect changes in the process, process equipment or installation conditions of the transmitter. This is done by modeling the process' noise signature (using the statistical values of mean and standard deviation) under normal conditions and then comparing the baseline values to current values over time. If a significant change in the current values is detected, the transmitter can generate alerts or alarms, depending on configuration. The condition is time stamped and is also noted on the LCD. The statistical values are also available as secondary variables from the transmitter via HART if a user is interested in their own analysis or generating their own alarms or alerts.
3. Advanced Process Alerts – These alerts in the 3051S HART Diagnostics transmitter are similar to the Process Pressure and Sensor Temperature Alerts in the standard 3051S transmitter, with the addition of time stamping to document the start and elapsed time of the alert condition. Upon detection of a Process Alert condition, a HART "Alert" message is generated. The LCD will also indicate the condition.
4. Variable Logging – The 3051S HART diagnostic transmitter logs the following values: Minimum and Maximum Pressure, Minimum and Maximum Temperature, and total elapsed time in overpressure or over temperature conditions. Each of these are independently time stamped.

HART DIAGNOSTIC USER INTERFACE

The Rosemount 3051S HART Diagnostic transmitter is available with the new Enhanced EDDL interface; DD revision 3051S HDT Dev. 1 Rev. 1 is required. The following screen shots are taken from Emerson Process Management's AMS™ Device Manager, version 7.6 or higher. Screens from other hosts that support Enhanced EDDL will look very similar. All diagnostic information and configuration can be found under the Diagnostic tab.

Figure 7-1. Diagnostics Entry Screen




Figure 7-1 is the diagnostics entry screen. From this set of screens the transmitter's diagnostic condition can quickly be surmised. All diagnostic information from the transmitter has been categorized as either "Failed", "Maintenance", or "Advisory". The user can also easily select any of the three diagnostic functions, **Statistical Process Monitoring**, **Variable Logging**, and **Process Alerts**, to review, monitor, or configure.


STATISTICAL PROCESS MONITORING

Introduction

Emerson Process Management has developed a unique technology, Statistical Process Monitoring, that provides a means for early detection of abnormal situations in a process environment. The technology is based on the premise that virtually all dynamic processes have a unique noise or variation signature when operating normally. Changes in these signatures may signal that a significant change will occur or has occurred in the process, process equipment, or transmitter installation. For example, the noise source may be equipment in the process such as a pump or agitator, the natural variation in the DP value caused by turbulent flow, or a combination of both.

The sensing of the unique signature begins with the combination of a high speed sensing device, such as the Rosemount 3051S Pressure Transmitter, with patented software resident in a Diagnostics Feature Board to compute statistical parameters that characterize and quantify the noise or variation. These statistical parameters are the mean and standard deviation of the input pressure. Filtering capability is provided to separate slow changes in the process due to setpoint changes from the process noise or variation of interest. Figure 7-2 shows an example of how the standard deviation value (σ) is affected by changes in noise level while the mean or average value (μ) remains constant. The calculation of the statistical parameters within the device is accomplished on a parallel software path to the path used to filter and compute the primary output signal (such as the 4 - 20 mA output). The primary output is not affected in any way by this additional capability.

Figure 7-2. Changes in process noise or variability and affect on statistical parameters




The device can provide the statistical information to the user in two ways. First, the statistical parameters can be made available to the host system directly via HART communication protocol or HART to other protocol converters. Once available, the system may make use of these statistical parameters to indicate or detect a change in process conditions. In the simplest example, the statistical values may be stored in the DCS historian. If a process upset or equipment problem occurs, these values can be examined to determine if changes in the values foreshadowed or indicated the process upset. The statistical values can then be made available to the operator directly, or made available to alarm or alert software.

Second, the device has internal software that can be used to baseline the process noise or signature via a learning process. Once the learning process is completed, the device itself can detect significant changes in the noise or variation, and communicate an alarm via the 4 – 20 mA output and/or alert via HART. Typical applications are detection of plugged impulse lines, change in fluid composition, or equipment related problems.

Overview

A block diagram of the Statistical Process Monitoring (SPM) diagnostic is shown in Figure 7-3. The pressure process variable is input to a module where basic high pass filtering is performed on the pressure signal. The mean (or average) is calculated on the unfiltered pressure signal, the standard deviation calculated from the filtered pressure signal. These statistical values are available via HART and handheld communication devices like the 375 Field Communicator or asset management software like Emerson Process Management's AMS™ Device Manager. The values can also be assigned as secondary variables from the device for 4-20 mA communication to the user through other devices like the Rosemount 333 HART Tri-loop (see page 7-24 for more information).


Figure 7-3. Block diagram of the Statistical Process Monitoring diagnostic resident in 3051S HART Diagnostics Transmitter



SPM also contains a learning module that establishes the baseline values for the process. Baseline values are established under user control at conditions considered normal for the process and installation. These baseline values are made available to a decision module that compares the baseline values to the most current values of the mean and standard deviation. Based on sensitivity settings and actions selected by the user via the control input, the diagnostic generates alarms, alerts, or takes other actions when a significant change is detected in either value.

Rosemount 3051S Series

Figure 7-4. Simplified SPM flowchart



Further detail of the operation of the SPM diagnostic is shown in the Figure 7-4 flowchart. This is a simplified version showing operation using the default values. While SPM continuously calculates the mean and standard deviation values, the learning and decision modules must be turned on to operate. Once enabled, SPM enters the learning/verification mode. The baseline mean and standard deviation are calculated over a period of time controlled by the user (Learning/Monitoring Period; default is 3 minutes). The status will be "Learning". A check is performed to make sure that the process has a sufficiently high noise or variability level (above the low level of internal noise inherent in the transmitter itself). If the level is too low, the diagnostic will continue to calculate baseline values until the criteria is satisfied (or turned off). A second set of values is calculated and compared to the original set to verify that the measured process is stable and repeatable. During this period, the status will change to "Verifying". If the process is stable, the diagnostic will use the last set of values as baseline values and move to "Monitoring" status. If the process is unstable, the diagnostic will continue to verify until stability is achieved. The stability criteria are also user defined.

In the “Monitoring” mode, new mean and standard deviation values are continuously calculated, with new values available every second. The mean value is compared to the baseline mean value. If the mean has changed by a significant amount, the diagnostic can automatically return to the “Learning” mode. The diagnostic does this because a significant change in mean is likely due to a change in process operation and can result in a significant change in noise level (i.e. standard deviation) as well. If the mean has not changed, the standard deviation value is compared to the baseline value. If the standard deviation has changed significantly relative to the baseline, exceeding preset sensitivity settings, this may indicate a change has occurred in the process, equipment, or transmitter installation and an alert is generated via HART.


NOTE

The Statistical Process Monitoring diagnostic capability in the Rosemount 3051S HART Pressure Transmitter calculates and detects significant changes in statistical parameters derived from the input pressure signal. These statistical parameters relate to the variability of and the noise signals present in the pressure signal. It is difficult to predict specifically which noise sources may be present in a given pressure measurement application, the specific influence of those noise sources on the statistical parameters, and the expected changes in the noise sources at any time. Therefore, Rosemount cannot absolutely warrant or guarantee that Statistical Process Monitoring will accurately detect each specific condition under all circumstances.

Assigning Statistical Values to Outputs

The mean and standard deviation values can be made available to other systems via HART communications or devices that convert HART variables to analog 4 – 20 mA outputs, such as Rosemount’s 333 Tri-Loop. Either value can be assigned to be a secondary or tertiary variable. This is accomplished on the **Variable Mapping** screen. See Figure 7-5.

Figure 7-5. Selection of statistical values as secondary variables.



SPM Configuration

Figure 7-6. Main screen for Statistical Process Monitoring





Figure 7-6 is the entry screen for the Statistical Process Monitoring diagnostic. This screen is the main screen for the SPM diagnostic results and status.

The process for correct operation of the SPM diagnostic is:

- Configure the diagnostic using the **Configuration** and **Verification Criteria** screens
- Enable the diagnostic on the **Status** screen

The configuration process starts with basic configuration on the **Configuration** screen, Figure 7-7. The configurable fields are:

Figure 7-7. SPM diagnostic configuration screen



Learn/Monitor Period:

This is the learning and monitoring time period that the SPM diagnostic uses to sample the pressure signal. The mean and standard deviation values determined during the learning period will become the Baseline values. Decreasing this period can speed up the set up time. Increasing this value will give a better baseline value for noisier processes, or if rapid changes in the process value result in significant increases in the standard deviation value, causing false trips of the “High Variation Detected” alert. The Learning/Monitoring Period is always in minutes. The default value is 3 minutes. The valid range is 1 to 60 minutes.

High Pass Filter

This filter is used to remove slow process changes so the diagnostic only focuses on the process noise. For the majority of applications, there is no reason to turn this off. The default value is “On”.

Power Interruption

This is used to direct what the diagnostic should do in the case of a power interruption or if the diagnostic is manually disabled and then enabled. The options are:

Monitor

When SPM restarts, the diagnostic enters the Monitoring Mode and uses the baseline values computed before the interruption.

Relearn

When SPM restarts, the diagnostic restarts in the Learning Mode and will recalculate new baseline values.

Default is “Monitor.”

Rosemount 3051S Series

Detection Configuration

Sensitivity configuration contains two functions. The first function establishes the sensitivity/diagnostic trip values. The second determines what action the transmitter is to take if the diagnostic trips. Either of these can be changed at any time without interrupting the diagnostic.

Figure 7-8. Sensitivity Configuration

The screenshot shows a 'Detection Configuration' window with two main sections: 'Sensitivity' and 'Action'. Under 'Sensitivity', there are two dropdown menus: 'Variation Change' and 'Mean Change', both set to 'Medium'. Under 'Action', there are two dropdown menus: 'Alert' and 'Relearn', both set to their respective default values.

Figure 7-8 shows the default sensitivity configuration. High, medium, low and custom are the available choices, and are explained in more detail in Table 7-1 and Table 7-2.

Figure 7-9. Sensitivity set to Custom

The screenshot shows the 'Detection Configuration' window with 'Custom Sensitivity' parameters. The 'Sensitivity' section has 'Variation Change' and 'Mean Change' set to 'Custom'. The 'Custom Sensitivity' section has 'Variability Chang...' and 'Mean Change C...' both set to '100 %'. The 'Action' section has 'Alert' and 'Relearn' set to their default values.

Figure 7-9 shows the “Custom Sensitivity” parameters if “Custom” is selected for Variable Change or Mean Change. The user must exit this screen and then return to this screen for these parameters to appear after “Custom” is selected.

Figure 7-10 illustrates how the sensitivity selection is displayed graphically on the **SPM Status** screen. Grey lines appear after the Learning/Verification process to indicate the trip levels. These values, along with the baseline and current mean and standard deviation values, are also available on the **Operational Values** screen.

Figure 7-10. **SPM Status** screen showing the sensitivity settings




Table 7-1. Standard Deviation Sensitivity choices (regardless of transmitter type)

Low	An 80% change from the baseline value will trip the diagnostic.
Medium ⁽¹⁾	A 60% change from the baseline value will trip the diagnostic.
High	A 40% change from the baseline will trip the diagnostic.
Custom	Adjustable from 1% to 10000%.

(1) Default.

Table 7-2. Mean Sensitivity choices

	DP	GP/AP
Low	40% of baseline or 4% of span whichever is greater	20% of span
Medium ⁽¹⁾	20% of baseline or 2% of span whichever is greater	10% of span
High	10% of baseline or 1% of span whichever is greater	5% of span
Custom	Adjustable from 1 to 10000% of value	Adjustable from 1 to 10000% of span

(1) Default.

Figure 7-11. Sensitivity settings description




Figure 7-11 Illustrates how the sensitivity selection affects the diagnostic trip values.

The second configuration setting is the action the transmitter is to take if the diagnostic trips. The options are:

None

With this option selected, the transmitter provides no indication that any of the trip values were exceeded.

Alert

With this option selected, a diagnostic trip will only activate a HART Alert. The HART Diagnostic Alert will be displayed on any host that can communicate with the transmitter, a hand-held HART communicator, or on the LCD indicator if installed.

Alarm

With this option selected, a diagnostic trip will activate a HART Alert and will cause the mA output to go to the selected Failure Alarm level. The HART Diagnostic message will be displayed on any host that can communicate with the transmitter, a hand-held HART communicator, or on the LCD indicator if installed. See page 3-12 for configuration of alarm values.

Relearn

This option is available only for the MEAN. With this option selected, if a change in the mean exceeds the sensitivity settings, the SPM diagnostic automatically reverts back to the learn/verify process. This option is typically used if:

- a. A mean change is normal or is of no interest
- b. A change in the Mean causes a change in the Standard Deviation requiring a new Standard Deviation baseline for the diagnostic. This is common for flow applications.

The default is “Relearn”.


Table 7-3. SPM Diagnostic Configuration defaults

Parameter	Default
Learning/Monitoring Period	3 minutes
High Pass Filter	ON
Power Interruption	Monitor
Variation Change Sensitivity	Medium
Variation Change Action	Alert
Mean Change Sensitivity	Medium
Mean Change Action	Relearn

SPM Verification Criteria

The **Verification Criteria** screen lists the parameters the SPM diagnostic uses during the verification process to verify that the process has sufficient noise and is also stable and repeatable. Figure 7-12 shows the three parameters.

Figure 7-12. Verification criteria screen



Insufficient Variation

The SPM diagnostic uses process noise to detect abnormal situations. Typically this check is on to insure there is sufficient noise for proper operation. In a normally quiet application where noise is the abnormal situation, this can be turned off. Default is ON.

Table 7-4. Insufficient Variation Selections

Parameter	Definition
On	Perform insufficient variation check (default)
Off	Do not perform insufficient variation check

Standard Deviation and Mean Verification Criteria

The Standard Deviation and Mean configuration parameters define the maximum deviation from the original Baseline values derived during the Learning/Verification Mode. If these maximum values are exceeded, the diagnostic will not start/go to the Monitoring Mode, but will continue Verifying. It is best to keep these values to the minimum amount for the particular application. If the diagnostic will not leave the Verify Mode, these values should be increased. If the diagnostic remains in the verify mode at the highest level, the Learning/Monitoring period should be increased.

Table 7-5. Standard Deviation Verification Criteria

Parameter	Definition
None	Do not perform any standard deviation checks
10%	Stay in the Verification Mode if the difference between the Learning Baseline Standard Deviation and the Verification pass is greater than 10%
20% ⁽¹⁾	Stay in the Verification Mode if the difference between the Learning Baseline Standard Deviation and the Verification pass is greater than 20%
30%	Stay in the Verification Mode if the difference between the Learning Baseline Standard Deviation and the Verification pass is greater than 30%

(1) Default.


Table 7-6. Mean Verification Criteria

Parameter	Definition
None	Do not perform any mean checks
3 * ⁽¹⁾	Stay in the Verification Mode if the difference between the Learning Baseline Mean and the Verification pass Mean is greater than 3 times the Standard Deviation
6 *	Stay in the Verification Mode if the difference between the Learning Baseline Mean and the Verification pass Mean is greater than 6 times the Standard Deviation
2%	Stay in the Verification Mode if the difference between the Learning Baseline mean and the Verification pass mean is greater than 2%

(1) Default.


Figure 7-13. **Operational Values** Screen

The **Operational Values** screen contains the parameter values used in the SPM diagnostic in tabular form.



SPM Operation

Figure 7-14. Turning on the SPM diagnostic



Turning ON the SPM Diagnostic

The SPM diagnostic is enabled by selecting ON in the “Control” section shown on Figure 7-14. Upon selecting ON in the “Control” section, the diagnostic will automatically begin “Learning” with the following exception: if valid baseline values have been previously established and “Monitor” has been selected as the option for Power Interruption on the **Configuration** Screen, then the diagnostic will bypass Learning and begin Monitoring immediately. The diagnostic status will stay in the Learning mode for the Learning Period specified on the Configuration screen. After the learning period is complete, the Mode will change to Verifying and a blue line will appear on the charts indicating the learned baseline value. Upon completion of the Verify mode, the diagnostic will use the parameters selected on the Verification Criteria page to validate the baseline value. After the Verifying period the Mode will switch to Monitoring and grey lines that indicate the sensitivity setting will appear on the charts.

Detection

If the SPM diagnostic detects a Standard Deviation or Mean change outside the threshold values, one of the indicators in the SPM Status box will illuminate red, indicating if there has been a mean change, an increase in noise or variability (High Variation Detected) or a decrease (Low Variation Detected), the transmitter will take the action as determined by the user in the configuration. The LCD will also indicate the diagnostic condition. The “Time Since Detection” clock in the Time box will start incrementing. The diagnostic condition is latched and the “Time Since Detection” clock will continue to increment until the diagnostic is reset or turned off.

Interpreting Results

The SPM diagnostic can be used to detect installation, process and equipment changes, or problems. However, as the diagnostic is based on detecting changes in process noise or variability, there are many possible reasons or sources for the change in values and detection. Following are some possible causes and solutions if a diagnostic event is detected:

Table 7-7. Possible causes of SPM diagnostic events

Diagnostic Condition	Potential Cause	Corrective Action
High Variation Detected	Plugged impulse line (DP only)	Follow facility procedure to check for and clear plugged impulse lines. Both lines must be checked as the SPM diagnostic cannot determine if the plug is on the high or low side. Conditions that lead to plugging on one side may lead to an eventual plug on the other side.
	Aeration or aeration increase (liquid flows)	a) If aeration is undesired, take necessary steps to eliminate aeration b) If the measurement is DP Flow and aeration is not desired, move primary element to another location in the process piping to ensure it remains full (no air) under all conditions.
	Liquid present or amount of liquid increased (gas or steam flows)	If liquid is undesired, take necessary steps to eliminate liquid in gas or steam flow
	Solids present or solids level increased	If solids are undesired, take necessary steps to eliminate
	Control loop problem (valve stiction, controller issue, etc.)	Review loop for control problems
	Rapid change of process variable mean value	Rapid changes in the process variable can result in indication of high variation. If undesired, make sure SPM High Pass filter is turned ON (SPM, Operations screen). Increase the Learn/Monitor period (SPM, Operations screen; three minutes is default value, can increase to 60 minutes maximum)
	Process or equipment change or problem has resulted in an increase in the pressure noise level.	Check process equipment
Low Variation Detected	Plugged impulse line (DP/AP/GP)	Follow facility procedure to check for and clear plugged impulse lines. Both lines must be checked as the SPM diagnostic cannot determine if the plug is on the high or low side (DP devices only). Conditions that lead to plugging on one side may lead to an eventual plug on the other side.
	Aeration decrease	If decrease is normal, reset and relearn. If not, check process and equipment for change in operating conditions.
	Decrease of liquid content in gas or steam flow	If decrease is normal, reset and relearn. If not, check process and equipment for change in operating conditions.
	Decrease in solids content	If decrease is normal, reset and relearn. If not, check process and equipment for change in operating conditions.
	Reduction in variability in process	If decrease is normal, reset and relearn. If not, check process and equipment for change in operating conditions. For example, a stuck control valve can reduce variability.
Mean Change Detected	Significant process setpoint change	If change is normal, reset and relearn. Consider changing mean change detection to automatically relearn. If change is not expected, check process and equipment for change in operating conditions.

Rosemount 3051S Series

Resetting SPM

The two options for resetting the SPM diagnostic are:

Reset

When Reset is selected the system will ask for confirmation and then will clear the status indicators in the SPM and reset the “Time Since Detection” clock in the time section back to zero. This will clear any alarms or alerts that have been set, and clear any indications from the LCD, if attached.

Reset and relearn

Selecting this option will do all the Reset option does and the Learning/Verifying cycle will begin.

Troubleshooting the SPM Diagnostic

Users are encouraged to pretest the SPM diagnostic if possible. For example, if the diagnostic is to be used to detect plugged impulse lines, and if root valves are present in the installation, the user should set up the diagnostic as described earlier, then alternately close the high then the low side root valve to simulate a plugged impulse line. Using the SPM status screen, the user can then note the changes to the standard deviation values under the closed conditions and adjust the sensitivity values as needed.

SPM Diagnostic Issue	Action
SPM diagnostic status indicates insufficient variability and will not leave learning or verifying mode	Process has very low noise. Turn off insufficient variability check (Verification Criteria screen). SPM diagnostic will be unable to detect a significant decrease in noise level.
SPM diagnostic will not leave verifying mode	Process is unstable. Increase learning sensitivity checks (Verification Criteria screen). If this does not correct the issue, increase the learning verification period to match or exceed the cycle time of the instability of the process. If maximum time does not correct the problem, process is not a candidate for SPM diagnostic. Correct stability issue or turn off diagnostic.
SPM diagnostic does not detect a known condition	With the condition present, but the process operating, go to the SPM Status or Operational Values screen and note the current statistical values and compare to the baseline and threshold values. Adjust the sensitivity values until a trip of the diagnostic occurs.
SPM diagnostic indicates “High Variation Detected” when no diagnostic event has occurred	The most likely cause is a fast change in the value of the process variable. Direction of the change is not important. Increase the learning/monitoring period to better filter out increases in standard deviation.

VARIABLE LOGGING

Overview

The 3051S HART Diagnostic transmitter's Variable Logging can be used in a number of ways. Figure 7-15 shows the **Pressure Event Logging** screen. Figure 7-16 shows the **Temperature Event Logging** screen. On both of these screens there are two basic sets of functionality. The first function is the logging and time-stamping of the minimum and maximum pressures and sensor temperatures. The second function is logging and time-stamping of over pressure or over temperature conditions, events that could have an effect on the life of the transmitter.

Pressure Event Log

Min Value


The meter indicates the lowest pressure the transmitter has measured since the last reset. The Time Since clock indicates the elapsed time since the minimum pressure was measured. Keep in mind that the lowest pressure does not necessarily mean a negative or vacuum pressure. The value given is either the most positive pressure put on the Low side or the most negative or vacuum pressure put on the High side of the transmitter in the case of a DP transmitter.

Max Value

The meter indicates the highest pressure the transmitter has measured since the last reset. The Time Since clock indicates the elapsed time since the maximum pressure was measured. Keep in mind that the highest pressure does not necessarily mean a positive pressure. The value given is either the most positive pressure put on the High side or the most negative or vacuum pressure put on the Low side of the transmitter in the case of DP device.

Both the Min and Max values can be reset independently. A Reset will reset the Time Since clock and sets the pressure to the currently measured value.

Figure 7-15. Pressure event logging screen



Rosemount 3051S Series

Time Outside Sensor Limits gives the operator/maintenance personnel an indication of possible misapplication of the transmitter. The Lower and Upper operate the same. They both include a Time Since 1st Event and Total time.

Time Since 1st Event

The elapsed time since the first over-pressure was detected since the last reset. This time can be reset by selecting the Reset Time Since Event.

Total Time

This is the accumulated time the pressure sensor has been in an over-pressure condition. This elapsed total time is independent of the number of events or frequency; it is the total or sum time the transmitter was in this condition. These values are not resettable.

Reset Time Since Event

Selecting this reset will set the Since First Event for both Above Sensor limit and Below Sensor limit to zero.

Reset All Sensor Events

Selecting this will reset all values on this screen to zero with the exception of Total Operating time, the Total Time above the sensor limit and the Total Time below the sensor limit. These values are not resettable.

Temperature Event Log

Min Value


The meter indicates the lowest temperature the transmitter has measured since the last reset. The Time Since clock indicates the elapsed time since that temperature was measured.

Max Value

The meter indicates the highest temperature the transmitter has measured since the last reset. The Time Since clock indicates elapsed time since that temperature was measured.

Both the Min and Max values can be reset independently. Selecting the Reset will reset the Time Since clock and set the temperature to the currently measured value.

Figure 7-16. Temperature Event Logging screen



Time Outside Sensor Limits gives the operator/maintenance personnel an indication of possible misapplication of the transmitter. The Lower and Upper operate the same. They both include a Time Since 1st Event and Total time.

Time Since 1st Event

The elapsed time since the first over temperature condition was detected since the last reset. This time can be reset by selecting the Reset Time Since Event.

Total Time

The accumulated time the transmitter has been in an over temperature condition. This elapsed total time is independent of the number of events or frequency, it is the total or sum time it was in this condition.

Reset Time Since Event

Selecting this reset will set the Since First Event for both Above sensor limit and Below Sensor limit to zero.

Reset All Sensor Events

Selecting this will reset everything on this page to zero with the exception of Total Operating time and the Total Time above the sensor limit and the Total Time below the sensor limit. These values are not resettable.


ADVANCED PROCESS ALERTS

Overview

The HART Diagnostic transmitter adds time stamping capability to the Process Alerts function in the standard 3051S. Figure 7-17 is the **Pressure Process Alert** screen. Figure 7-18 is the **Sensor Temperature Process Alert** screen. The functionality is identical.

Process alerts can be used in addition to alarms or alerts generated in the control system to indicate problems with the process or installation. For example, the temperature alert can be used to signal operators or maintenance personnel that heat tracing lines need to be turned on in the winter or turned off in the spring.

Figure 7-17. Process Pressure Alerts screen



Pressure Alert Setting

This is the configuration section for the Pressure Process Alert. Selecting ON enables the diagnostic. The High Alert Value and the Low Alert Value are the trip values for the diagnostic. These values are represented on the graph by red lines. If the applied pressure goes above or below the Alert Values, the button next to Pressure alert will illuminate red, the LCD will indicate a Pressure Alert, and any HART communicator/master will indicate a Pressure Alert. An active alert will not affect the transmitter's 4 – 20 mA output.

Total Above

This is the total time the transmitter's input pressure was above the High Alert value.

Total Below

This is the total time the transmitter's input pressure was below the Low Alert Value.


Since Event

This is the elapsed time since the first Pressure Alert event. Subsequent events will increment the Total Above or Total Below values, but this value will remain unchanged.

Reset Pressure Alert Events

Selecting this will reset all time stamp values to zero.

Figure 7-18. Temperature Process Alerts screen



Temperature Alert Setting

This is the configuration section for the Temperature Process Alert. Selecting ON enables the diagnostic. The High Alert Value and the Low Alert Value are the trip values for the diagnostic. These values are represented on the graph by red lines. If the ambient temperature of the transmitter goes above or below the Alert Values, the button next to Temperature alert will illuminate red, the LCD will indicate a Temperature Alert, and any HART communicator/master will indicate a Temperature Alert. An active alert will not affect the transmitter's output.

Total Above

This is the total time the transmitter's sensor temperature measurement was above the High Alert value.

Total Below

This is the total time the transmitter's sensor temperature measurement was below the Low Alert Value.

Since Event

This is the elapsed time since the first Temperature Alert event. Subsequent events will increment the Total Above or Total Below values, but this value will remain unchanged.

Reset Temperature Alert Events

Selecting this will reset all time stamp values to zero.

Rosemount 3051S Series

ROSEMOUNT 333 HART TRI-LOOP CONFIGURATION

Overview


The Rosemount 333 HART Tri-Loop can be used in conjunction with the Rosemount 3051S with Advanced HART Diagnostics to acquire up to two more variables via 4-20mA analog signals. The additional two outputs are selected by the user and can include: Pressure, Temperature, Scaled Variable, Standard Deviation, or Mean.

Installation and Commissioning

Below are the four major steps to commission the 3051S and Tri-Loop. Further detail on these steps can be found in the Tri-Loop Instruction manual.

1. Check the 3051S Variable assignments and remap as necessary to assign the two variables intended to be the Tri-Loop output for the Secondary (Second) and the Tertiary (Third) variables. Take note of the Secondary and Tertiary variable information including variable, variable name, and variable units as it will be necessary to duplicate this exactly in the Tri-Loop for proper operation.
2. Connect the 3051S to the 333 Tri-Loop. The 3051S 4-20mA output connects to the 333 Burst Input. See Figure 7-19.

Figure 7-19. Tri-Loop Wiring Diagram



3. Configure the Tri-Loop. The Channel configuration must be identical to the variables mapped in the 3051S. **Note:** The Tri Loop default address is 1. The HART host must be configured to Poll for the 333 in order to find the Tri-Loop.
4. Enable Burst mode in the 3051S. The Burst Mode must be ON and the Burst Option must be set to Process Vars/Crnt.

OTHER INFORMATION

Digital Trim with non-DD based communicators

The 3051S Pressure Transmitter with Advanced Diagnostics makes use of its Device Description to support an enhanced digital trim function. Use of a non-DD based host or communicator may require repeat trims to achieve maximum accuracy.

Rosemount 3051S Series

Reference Manual
00809-0100-4801, Rev CB
January 2007

Appendix A Specifications and Reference Data

Performance Specifications	page A-1
Functional Specifications	page A-6
Physical Specifications	page A-12
Dimensional Drawings	page A-16
Ordering Information	page A-25
Exploded view Diagram	page A-39
Spare Parts	page A-40

SPECIFICATIONS

Performance Specifications

For zero-based spans, reference conditions, silicone oil fill, glass-filled TFE o-rings, SST materials, *Coplanar* flange (3051S_C) or 1/2 in.- 14 NPT (3051S_T) process connections, digital trim values set to equal range points.

Conformance to specification ($\pm 3\sigma$ (Sigma))

Technology leadership, advanced manufacturing techniques and statistical process control ensure specification conformance to $\pm 3\sigma$ or better.

Reference Accuracy

Models	Ultra ^{(1) (2)}	Classic ^{(1) (2)}	Ultra for Flow ^{(1) (3)}
3051S_CD, CG			
Ranges 2 - 4	$\pm 0.025\%$ of span. For spans less than 10:1, $\pm \left[0.005 + 0.0035 \left(\frac{URL}{span} \right) \right] \%$ of span	$\pm 0.055\%$ of span. For spans less than 10:1, $\pm \left[0.015 + 0.005 \left(\frac{URL}{span} \right) \right] \%$ of span	$\pm 0.04\%$ of reading up to 8:1 DP turndown from URL; $\pm [0.04 + 0.0023 (URL/RDG^{(4)})] \%$ reading to 200:1 DP turndown from URL
Range 5	$\pm 0.05\%$ of span. For spans less than 10:1, $\pm \left[0.005 + 0.0045 \left(\frac{URL}{span} \right) \right] \%$ of span	$\pm 0.065\%$ of span. For spans less than 10:1, $\pm \left[0.015 + 0.005 \left(\frac{URL}{span} \right) \right] \%$ of span	
Range 1	$\pm 0.09\%$ of span. For spans less than 15:1, $\pm \left[0.015 + 0.005 \left(\frac{URL}{span} \right) \right] \%$ of span	$\pm 0.10\%$ of span. For spans less than 15:1, $\pm \left[0.025 + 0.005 \left(\frac{URL}{span} \right) \right] \%$ of span	
Range 0	$\pm 0.09\%$ of span. For spans less than 2:1 = $\pm 0.045\%$ of URL	$\pm 0.10\%$ of span. For spans less than 2:1 = $\pm 0.05\%$ of URL	

Rosemount 3051S Series

Models	Ultra ^{(1) (2)}	Classic ^{(1) (2)}	Ultra for Flow ^{(1) (3)}
3051S_T			
Ranges 1 - 4	±0.025% of span. For spans less than 10:1, $\pm\left[0.004\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	±0.055% of span. For spans less than 10:1, $\pm\left[0.0065\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	
Range 5	±0.04% of span. For spans less than 10:1, $\pm\left[0.004\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	±0.065% of span. For spans less than 10:1, $\pm\left[0.0065\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	
3051S_CA			
Ranges 1 - 4	±0.025% of span. For spans less than 10:1, $\pm\left[0.004\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	±0.055% of span. For spans less than 10:1, $\pm\left[0.0065\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	
Range 0	±0.075% of span. For spans less than 5:1, $\pm\left[0.025 + 0.01\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	±0.075% of span. For spans less than 5:1, $\pm\left[0.025 + 0.01\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	
3051S_L			
	±0.065% of span. For spans less than 10:1, $\pm\left[0.015 + 0.005\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	±0.065% of span. For spans less than 10:1, $\pm\left[0.015 + 0.005\left(\frac{\text{URL}}{\text{span}}\right)\right]\%$ of span	

(1) Stated reference accuracy equations include terminal based linearity, hysteresis, and repeatability.

(2) For FOUNDATION fieldbus transmitters, use calibrated range in place of span.

(3) Ultra for Flow applicable for CD Ranges 2-3 only. For calibrated spans from 1:1 to 2:1 of URL, add ±0.005% of span analog output error.

(4) RDG refers to transmitter reading.

Total Performance

Models	Ultra ⁽¹⁾	Classic ⁽¹⁾	Ultra for Flow ⁽¹⁾⁽²⁾
3051S_			
CD Ranges 2-3	±0.1% of span; for ±50°F (28°C)	±0.15% of span; for ±50°F (28°C)	±0.1% of reading; for ±50°F (28°C)
CG Ranges 2-5	temperature changes; 0-100%	temperature changes; 0-100%	temperature changes; 0-100%
T Ranges 2-4	relative humidity, up to 740 psi	relative humidity, up to 740 psi	relative humidity, up to 740 psi
CA Ranges 2-4	(51 bar) line pressure (CD only), from 1:1 to 5:1 rangedown.	(51 bar) line pressure (CD only), from 1:1 to 5:1 rangedown.	(51 bar) line pressure, over 8:1 DP turndown from URL.


(1) Total performance is based on combined errors of reference accuracy, ambient temperature effect, and line pressure effect.
(2) Ultra for Flow applicable for CD Ranges 2-3 only.

Long Term Stability

Models	Ultra and Ultra for Flow	Classic
3051S_		
CD Ranges 2 - 5	±0.20% of URL for 10 years; for ±50°F (28°C)	±0.125% of URL for 5 years; for ±50°F (28°C)
CG Ranges 2 - 5	temperature changes, up to 1000 psi (68,9 bar)	temperature changes, up to 1000 psi (68,9 bar)
T Ranges 1 - 5 and CA Ranges 1 - 4	line pressure (CD only)	line pressure (CD only)

Dynamic Performance

	4 - 20 mA (HART®) ⁽¹⁾	Fieldbus protocol ⁽²⁾	Typical Transmitter Response Time
Total Response Time (Td + Tc)⁽³⁾:			
3051S_C, Ranges 2 - 5:	100 milliseconds	152 milliseconds	
Range 1:	255 milliseconds	307 milliseconds	
Range 0:	700 milliseconds	752 milliseconds	
3051S_T:	100 milliseconds	152 milliseconds	
3051S_L:	See <i>Instrument Toolkit</i> ™.	See <i>Instrument Toolkit</i>	
Dead Time (Td)⁽⁴⁾	45 milliseconds (nominal)	97 milliseconds	
Update Rate	3051S 22 times per second	22 times per second	



(1) Dead time and update rate apply to all models and ranges; analog output only
(2) Transmitter fieldbus output only, segment macro-cycle not included.
(3) Nominal total response time at 75 °F (24 °C) reference conditions. For option code DA1, add 40 milliseconds () to 4-20 mA (HART®) total response time values.
(4) For option code DA1, dead time (Td) is 85 milliseconds (nominal).

Ambient Temperature Effect

Models	Ultra	Classic	Ultra for Flow ⁽¹⁾
3051S_CD, CG	per 50 °F (28 °C)	per 50 °F (28 °C)	
	Range 2 - 5 ⁽³⁾ ± (0.009% URL + 0.025% span) from 1:1 to 10:1 ± (0.018% URL + 0.08% span) from >10:1 to 200:1	± (0.0125% URL + 0.0625% span) from 1:1 to 5:1 ± (0.025% URL + 0.125% span) from >5:1 to 100:1	From -40 to 185 °F (-40 to 85 °C): ±0.13% reading up to 8:1 DP turndown from URL; ±[0.13 + 0.0187 (URL/RDG ⁽²⁾)]% reading to 100:1 DP turndown from URL
	Range 0 ± (0.25% URL + 0.05% span) from 1:1 to 30:1	± (0.25% URL + 0.05% span) from 1:1 to 30:1	
Range 1 ± (0.1% URL + 0.25% span) from 1:1 to 50:1	± (0.1% URL + 0.25% span) from 1:1 to 50:1		
3051S_T	Ranges 2 - 4 ± (0.009% URL + 0.025% span) from 1:1 to 10:1 ± (0.018% URL + 0.08% span) from >10:1 to 200:1	± (0.0125% URL + 0.0625% span) from 1:1 to 5:1 ± (0.025% URL + 0.125% span) from >5:1 to 100:1	
	Range 5 ± (0.05% URL + 0.075% span) from 1:1 to 10:1	± (0.05% URL + 0.075% span) from 1:1 to 5:1	
	Range 1 ± (0.0125% URL + 0.0625% span) from 1:1 to 5:1 ± (0.025% URL + 0.125% span) from >5:1 to 200:1	± (0.0125% URL + 0.0625% span) from 1:1 to 5:1 ± (0.025% URL + 0.125% span) from >5:1 to 100:1	
3051S_CA	Ranges 2 - 4 ± (0.009% URL + 0.025% span) from 1:1 to 10:1 ± (0.018% URL + 0.08% span) from >10:1 to 200:1	± (0.0125% URL + 0.0625% span) from 1:1 to 5:1 ± (0.025% URL + 0.125% span) from >5:1 to 100:1	
	Range 0 ± (0.1% URL + 0.25% span) from 1:1 to 30:1	± (0.1% URL + 0.25% span) from 1:1 to 30:1	
	Range 1 ± (0.0125% URL + 0.0625% span) from 1:1 to 5:1 ± (0.025% URL + 0.125% span) from >5:1 to 100:1	± (0.0125% URL + 0.0625% span) from 1:1 to 5:1 ± (0.025% URL + 0.125% span) from >5:1 to 100:1	
3051S_L	See <i>Instrument Toolkit</i> [™] .	See <i>Instrument Toolkit</i> .	

- (1) Ultra for Flow applicable for CD Ranges 2-3 only.
 (2) RDG refers to transmitter reading.
 (3) Use Classic specification for 3051S_CD Range 5 Ultra.

Line Pressure Effect

For line pressures above 2000 psi (137,9 bar) and ranges 4-5, see the 3051S reference manual (document number 00809-0100-4801).

Models	Ultra and Ultra for Flow	Classic
3051S_CD	Zero Error⁽¹⁾	Zero Error⁽¹⁾
	Range 2 - 3 ± 0.025% URL per 1000 psi (69 bar)	± 0.05% URL per 1000 psi (69 bar)
	Range 0 ± 0.125% URL per 100 psi (6,89 bar) Range 1 ± 0.25% URL per 1000 psi (69 bar)	± 0.125% URL per 100 psi (6,89 bar) ± 0.25% URL per 1000 psi (69 bar)
	Span Error	Span Error
Range 2 - 3	± 0.1% of reading per 1000 psi (69 bar)	± 0.1% of reading per 1000 psi (69 bar)
Range 0	± 0.15% of reading per 100 psi (6,89 bar)	± 0.15% of reading per 100 psi (6,89 bar)
Range 1	± 0.4% of reading per 1000 psi (69 bar)	± 0.4% of reading per 1000 psi (69 bar)

- (1) Zero error can be calibrated out

Mounting Position Effects

Models	Ultra, Ultra for Flow, and Classic
3051S_C	Zero shifts up to ± 1.25 inH ₂ O (3,11 mbar), which can be calibrated out; no span effect
3051S_L	With liquid level diaphragm in vertical plane, zero shift of up to 1 inH ₂ O (25,4 mmH ₂ O); with diaphragm in horizontal plane, zero shift of up to 5 inH ₂ O (127 mmH ₂ O) plus extension length on extended units; all zero shifts can be calibrated out; no span effect
3051S_T and 3051S_CA	Zero shifts to 2.5 inH ₂ O (63,5 mmH ₂ O), which can be calibrated out; no span effect

Vibration Effect

Less than $\pm 0.1\%$ of URL when tested per the requirements of IEC60770-1 field or pipeline with high vibration level (10-60 Hz 0.21mm displacement peak amplitude / 60-2000 Hz 3g).

Housing Style codes 1J, 1K, 1L, 2J

Less than $\pm 0.1\%$ of URL when tested per the requirements of IEC60770-1 field with general application or pipeline with low vibration level (10-60 Hz 0.15mm displacement peak amplitude / 60-500 Hz 2g).

Power Supply Effect

All Models:

Less than $\pm 0.005\%$ of calibrated span per volt

Electromagnetic Compatibility (EMC)

All Models:

Meets all relevant requirements of IEC/EN 61326 and NAMUR NE-21.

Transient Protection (Option T1)

All Models:

Meets IEEE C62.41, Category B

6 kV crest (0.5 μ s - 100 kHz)

3 kV crest (8 \times 20 microseconds)

6 kV crest (1.2 \times 50 microseconds)

General Specifications:

Response Time: < 1 nanosecond

Peak Surge Current: 5000 amps to housing

Peak Transient Voltage: 100 V dc

Loop Impedance: < 25 ohms

Applicable Standards: IEC61000-4-4, IEC61000-4-5

NOTE:

Calibrations at 68 °F (20 °C) per ASME Z210.1 (ANSI)

Rosemount 3051S Series

Functional Specifications

Range and Sensor Limits

Range	Minimum Span 3051S_		Range and Sensor Limits 3051S_			
	Ultra and Ultra for Flow ⁽¹⁾	Classic	Upper (URL)	Lower (LRL)		
				3051S_CD ⁽²⁾	3051S_CG, LG ⁽³⁾	3051S_LD ⁽³⁾
0	0.1 inH ₂ O (0,25 mbar)	0.1 inH ₂ O (0,25 mbar)	3.0 inH ₂ O (7,5 mbar)	-3.0 inH ₂ O (-7,5 mbar)	NA	NA
1	0.5 inH ₂ O (1,24 mbar)	0.5 inH ₂ O (1,24 mbar)	25.0 inH ₂ O (62,3 mbar)	-25.0 inH ₂ O (-62,3 mbar)	-25.0 inH ₂ O (-62,3 mbar)	-25.0 inH ₂ O (-62,3 mbar)
2	1.3 inH ₂ O (3,11 mbar)	2.5 inH ₂ O (6,23 mbar)	250.0 inH ₂ O (0,62 bar)	-250.0 inH ₂ O (-0,62 bar)	-250.0 inH ₂ O (-0,62 bar)	-250.0 inH ₂ O (-0,62 bar)
3	5.0 inH ₂ O (12,4 mbar)	10.0 inH ₂ O (24,9 mbar)	1000.0 inH ₂ O (2,49 bar)	-1000.0 inH ₂ O (-2,49 bar)	-393.0 inH ₂ O (-979 mbar)	-1000.0 inH ₂ O (-2,49 bar)
4	1.5 psi (103,4 mbar)	3.0 psi (206,8 mbar)	300.0 psi (20,7 bar)	-300.0 psi (-20,7 bar)	-14.2 psig (-979 mbar)	-300.0 psi (-20,7 bar)
5	10.0 psi (689,5 mbar)	20.0 psi (1,38 bar)	2000.0 psi (137,9 bar)	-2000.0 psi (-137,9 bar)	-14.2 psig (-979 mbar)	-2000.0 psi (-137,9 bar)

- (1) Ultra for Flow applicable for CD Ranges 2 – 3 only.
(2) Lower (LRL) is 0 inH₂O (0 mbar) for Ultra for Flow.
(3) When specifying a 3051S_L Ultra, use Classic minimum span.

3051S_T Range and Sensor Limits

Range	Minimum Span		Upper (URL)	Lower (LRL) (Abs.)	Lower ⁽¹⁾ (LRL) (Gage)
	Ultra	Classic			
1	0.3 psi (20,7 mbar)	0.3 psi (20,7 mbar)	30 psi (2,07 bar)	0 psia (0 bar)	-14.7 psig (-1,01 bar)
2	0.75 psi (51,7 mbar)	1.5 psi (0,103 bar)	150 psi (10,34 bar)	0 psia (0 bar)	-14.7 psig (-1,01 bar)
3	4 psi (275,8 mbar)	8 psi (0,55 bar)	800 psi (55,16 bar)	0 psia (0 bar)	-14.7 psig (-1,01 bar)
4	20 psi (1,38 bar)	40 psi (2,76 bar)	4000 psi (275,8 bar)	0 psia (0 bar)	-14.7 psig (-1,01 bar)
5	1000 psi (68,9 bar)	2000 psi (137,9 bar)	10000 psi (689,5 bar)	0 psia (0 bar)	-14.7 psig (-1,01 bar)

- (1) Assumes atmospheric pressure of 14.7 psig.

3051S_CA, LA⁽¹⁾ Range and Sensor Limits

Range	Minimum Span		Upper (URL)	Lower (LRL)
	Ultra	Classic		
0 ⁽²⁾	0.167 psia (11,5 mbar)	0.167 psia (11,5 mbar)	5 psia (0,34 bar)	0 psia (0 bar)
1	0.3 psia (20,7 mbar)	0.3 psia (20,7 mbar)	30 psia (2,07 bar)	0 psia (0 bar)
2	0.75 psia (51,7 mbar)	1.5 psia (0,103 bar)	150 psia (10,34 bar)	0 psia (0 bar)
3	4 psia (275,8 mbar)	8 psia (0,55 bar)	800 psia (55,16 bar)	0 psia (0 bar)
4	20 psia (1,38 bar)	40 psia (2,76 bar)	4000 psia (275,8 bar)	0 psia (0 bar)

- (1) When specifying a 3051S_L Ultra, use Classic minimum span.
(2) Range 0 is not available for 3051S_LA.

Service

Liquid, gas, and vapor applications

4–20 mA/HART

Zero and Span Adjustment

Zero and span values can be set anywhere within the range.
Span must be greater than or equal to the minimum span.

Output

Two-wire 4–20 mA is user-selectable for linear or square root output. Digital process variable superimposed on 4–20 mA signal, available to any host that conforms to the HART protocol.

Power Supply

External power supply required.

Standard transmitter (4–20 mA): 10.5 to 42.4 V dc with no load


3051S HART Diagnostics transmitter: 12 to 42 Vdc with no load

Load Limitations

Maximum loop resistance is determined by the voltage level of the external power supply, as described by:

Standard Transmitter


Maximum Loop Resistance = $43.5 * (\text{Power Supply Voltage} - 10.5)$



The HART communicator requires a minimum loop resistance of 250Ω for communication.

3051S HART Diagnostics Transmitter (option code DA1)

Maximum Loop Resistance = $43.5 * (\text{Power Supply Voltage} - 12.0)$



The HART communicator requires a minimum loop resistance of 250Ω for communication.

ASP™ Diagnostics Suite for HART (Option Code DA1)

The 3051S provides Abnormal Situation Prevention indication for a breakthrough in diagnostic capability. The New 3051S ASP™ Diagnostics Suite for HART includes Statistical Process Monitoring (SPM), variable logging with time stamp and advanced process alerts. The enhanced EDDL graphic display provides an intuitive and user-friendly interface to better visualize these diagnostics.

The integral SPM technology calculates the mean and standard deviation of the process variable 22 times per second and makes them available to the user. The 3051S uses these values and highly flexible configuration options for customization to detect many user-defined or application specific abnormal situations (e.g. detecting plugged impulse lines and fluid composition change). Variable logging with time stamp and advanced process alerts capture valuable process and sensor data to enable quick troubleshooting of application and installation issues.

FOUNDATION fieldbus

Power Supply

External power supply required; transmitters operate on 9.0 to 32.0 V dc transmitter terminal voltage.

Current Draw

17.5 mA for all configurations (including LCD display option)

FOUNDATION fieldbus Parameters

Schedule Entries	14 (max.)
Links	30 (max.)
Virtual Communications Relationships (VCR)	20 (max.)

Standard Function Blocks

Resource Block

- Contains hardware, electronics, and diagnostic information.

Transducer Block

- Contains actual sensor measurement data including the sensor diagnostics and the ability to trim the pressure sensor or recall factory defaults.

LCD Block

- Configures the local display.

2 Analog Input Blocks

- Processes the measurements for input into other function blocks. The output value is in engineering or custom units and contains a status indicating measurement quality.

PID Block with Auto-tune

- Contains all logic to perform PID control in the field including cascade and feed forward. Auto-tune capability allows for superior tuning for optimized control performance.

Backup Link Active Scheduler (LAS)

The transmitter can function as a Link Active Scheduler if the current link master device fails or is removed from the segment.

Software Upgrade in the Field

Software for the 3051S with FOUNDATION fieldbus is easy to upgrade in the field using the FOUNDATION fieldbus Common Device Software Download procedure.

PlantWeb Alerts

Enable the full power of the PlantWeb digital architecture by diagnosing instrumentation issues, communicating advisory, maintenance, and failure details, and recommending a solution.

Advanced Control Function Block Suite

(Option Code A01)

Input Selector Block

- Selects between inputs and generates an output using specific selection strategies such as minimum, maximum, midpoint, average, or first "good."

Arithmetic Block

- Provides pre-defined application-based equations including flow with partial density compensation, electronic remote seals, hydrostatic tank gauging, ratio control and others.

Signal Characterizer Block

- Characterizes or approximates any function that defines an input/output relationship by configuring up to twenty X, Y coordinates. The block interpolates an output value for a given input value using the curve defined by the configured coordinates.

Integrator Block

- Compares the integrated or accumulated value from one or two variables to pre-trip and trip limits and generates discrete output signals when the limits are reached. This block is useful for calculating total flow, total mass, or volume over time.

Output Splitter Block

- Splits the output of one PID or other control block so that the PID will control two valves or other actuators.

Control Selector Block

- Selects one of up to three inputs (highest, middle, or lowest) that are normally connected to the outputs of PID or other control function blocks.

Block	Execution Time
Resource	-
Transducer	-
LCD Block	-
Analog Input 1, 2	20 milliseconds
PID with Auto-tune	35 milliseconds
Input Selector	20 milliseconds
Arithmetic	20 milliseconds
Signal Characterizer	20 milliseconds
Integrator	20 milliseconds
Output Splitter	20 milliseconds
Control Selector	20 milliseconds

Fully Compensated Mass Flow Block (Option Code H01)

Calculates fully compensated mass flow based on differential pressure with external process pressure and temperature measurements over the fieldbus segment. Configuration for the mass flow calculation is easily accomplished using the Rosemount Engineering Assistant.

ASP™ Diagnostics Suite for FOUNDATION fieldbus (Option Code D01)

The 3051S ASP™ Diagnostics Suite for FOUNDATION fieldbus provides Abnormal Situation Prevention indication and enhanced EDDL graphic displays for easy visual analysis.

The integral Statistical Process Monitoring (SPM) technology calculates the mean and standard deviation of the process variable 22 times per second and makes them available to the user. The 3051S uses these values and highly flexible configuration options for customization to detect many user-defined or application specific abnormal situations (e.g. detecting plugged impulse lines and fluid composition change).

Overpressure Limits

Transmitters withstand the following limits without damage:

3051S_CD, CG

- Range 0: 750 psi (51,7 bar)
- Range 1: 2000 psig (137,9 bar)
- Ranges 2–5: 3626 psig (250,0 bar)
- 4500 psig (310,3 bar) for option code P9
- 6092 psig (420 bar) for option code P0 (3051S2CD only)

3051S_CA

- Range 0: 60 psia (4,13 bar)
- Range 1: 750 psia (51,7 bar)
- Range 2: 1500 psia (103,4 bar)
- Range 3: 1600 psia (110,3 bar)
- Range 4: 6000 psia (413,7 bar)

3051S_TG, TA

- Range 1: 750 psi (51,7 bar)
- Range 2: 1500 psi (103,4 bar)
- Range 3: 1600 psi (110,3 bar)

Range 4: 6000 psi (413,7 bar)
Range 5: 15000 psi (1034,2 bar)

3051S_LD, LG, LA

Limit is flange rating or sensor rating, whichever is lower (see the table below).

Standard	Type	CS Rating	SST Rating
ANSI/ASME	Class 150	285 psig	275 psig
ANSI/ASME	Class 300	740 psig	720 psig
ANSI/ASME	Class 600	1480 psig	1440 psig
<i>At 100 °F (38 °C), the rating decreases with increasing temperature, per ANSI/ASME B16.5.</i>			
DIN	PN 10–40	40 bar	40 bar
DIN	PN 10/16	16 bar	16 bar
DIN	PN 25/40	40 bar	40 bar
<i>At 248 °F (120 °C), the rating decreases with increasing temperature, per DIN 2401.</i>			

Static Pressure Limit

3051S_CD Only

Operates within specifications between static line pressures of 0.5 psia and 3626 psig;
4500 psig (310,3 bar) for option code P9
6092 psig (420 bar) for option code P0 (3051S2CD only)
Range 0: 0.5 psia to 750 psig (0,03 to 51,71 bar)
Range 1: 0.5 psia to 2000 psig (0,03 to 137,90 bar)

Burst Pressure Limits

Coplanar or traditional process flange

- 10000 psig (689,5 bar).

3051S_T:

- Ranges 1–4: 11000 psi (758,4 bar)
- Range 5: 26000 psig (1792,64 bar)

Temperature Limits

Ambient

–40 to 185 °F (–40 to 85 °C)

With LCD display⁽¹⁾: –40 to 175 °F (–40 to 80 °C)

With option code P0: –4 to 185 °F (–20 to 85 °C)

⁽¹⁾ LCD display may not be readable and LCD updates will be slower at temperatures below –4 °F (–20 °C).

Storage

–50 to 230 °F (–46 to 110 °C)

With LCD display: –40 to 185 °F (–40 to 85 °C)

Process Temperature Limits

At atmospheric pressures and above.

3051S_C Coplanar	
Silicone Fill Sensor ⁽¹⁾	
with Coplanar Flange	-40 to 250 °F (-40 to 121 °C) ⁽²⁾
with Traditional Flange	-40 to 300 °F (-40 to 149 °C) ⁽²⁾⁽³⁾
with Level Flange	-40 to 300 °F (-40 to 149 °C) ⁽²⁾
with 305 Integral Manifold	-40 to 300 °F (-40 to 149 °C) ⁽²⁾⁽³⁾
Inert Fill Sensor ⁽¹⁾	0 to 185 °F (-18 to 85 °C) ⁽⁴⁾⁽⁵⁾
3051S_T In-Line (Process Fill Fluid)	
Silicone Fill Sensor ⁽¹⁾	-40 to 250 °F (-40 to 121 °C) ⁽²⁾
Inert Fill Sensor ⁽¹⁾	-22 to 250 °F (-30 to 121 °C) ⁽²⁾
3051S_L Low-Side Temperature Limits	
Silicone Fill Sensor ⁽¹⁾	-40 to 250 °F (-40 to 121 °C) ⁽²⁾
Inert Fill Sensor ⁽¹⁾	0 to 185 °F (-18 to 85 °C) ⁽²⁾
3051S_L High-Side Temperature Limits (Process Fill Fluid)	
Syltherm [®] XLT	-102 to 302 °F (-75 to 150 °C)
D. C. [®] Silicone 704 ⁽⁶⁾	32 to 500 °F (0 to 260 °C)
D. C. Silicone 200	-49 to 401 °F (-45 to 205 °C)
Inert (Halocarbon)	-49 to 320 °F (-45 to 160 °C)
Glycerin and Water	5 to 203 °F (-15 to 95 °C)
Neobee M-20 [®]	5 to 437 °F (-15 to 225 °C)
Propylene Glycol and Water	5 to 203 °F (-15 to 95 °C)

- (1) Process temperatures above 185 °F (85 °C) require derating the ambient limits by a 1.5:1 ratio.
- (2) 220 °F (104 °C) limit in vacuum service; 130 °F (54 °C) for pressures below 0.5 psia.
- (3) -20 °F (-29 °C) is the lower process temperature limit with option code P0.
- (4) 160 °F (71 °C) limit in vacuum service.
- (5) Not available for 3051S_CA.
- (6) Upper limit of 600 °F (315 °C) is available with 1199 seal assemblies mounted away from the transmitter with the use of capillaries and up to 500 °F (260 °C) with direct mount extension.

Humidity Limits

0–100% relative humidity

Turn-On Time

Performance within specifications less than 2 seconds (typical) after power is applied to the transmitter

Volumetric Displacement

Less than 0.005 in³ (0.08 cm³)

Damping

Analog output response to a step input change is user-selectable from 0 to 60 seconds for one time constant. This software damping is in addition to sensor module response time.

Failure Mode Alarm

HART 4-20mA (output option codes A)

If self-diagnostics detect a gross transmitter failure, the analog signal will be driven offscale to alert the user. Rosemount standard (default), NAMUR, and custom alarm levels are available (see Table A-1 below).

High or low alarm signal is software-selectable or hardware-selectable via the optional switch (option D1).

Table A-1. Alarm Configuration

	High Alarm	Low Alarm
Default	≥ 21.75 mA	≤ 3.75 mA
NAMUR compliant ⁽¹⁾	≥ 22.5 mA	≤ 3.6 mA
Custom levels ⁽²⁾	20.2 - 23.0 mA	3.6 - 3.8 mA

(1) Analog output levels are compliant with NAMUR recommendation NE 43, see option codes C4 or C5.

(2) Low alarm must be 0.1 mA less than low saturation and high alarm must be 0.1 mA greater than high saturation.

3051S Safety Certified Transmitter Failure Values

Safety accuracy: 2.0%⁽¹⁾

Safety response time: 1.5 seconds

(1) A 2% variation of the transmitter mA output is allowed before a safety trip. Trip values in the DCS or safety logic solver should be derated by 2%.

Physical Specifications

Electrical Connections

¹/₂-14 NPT, G¹/₂, and M20 × 1.5 (CM20) conduit. HART interface connections fixed to terminal block for Output code A.

Process Connections

3051S_C

¹/₄-18 NPT on 2¹/₈-in. centers

¹/₂-14 NPT and RC ¹/₂ on 2-in. (50.8mm), 2¹/₈-in. (54.0 mm), or 2¹/₄-in. (57.2mm) centers (process adapters)

3051S_T

¹/₂-14 NPT female,

Non-Threaded instrument flange (available in SST for Range 1-4 transmitters only),

G¹/₂ A DIN 16288 Male (available in SST for Range 1-4 transmitters only), or

Autoclave type F-250-C (Pressure relieved ⁹/₁₆-18 gland thread; ¹/₄ OD high pressure tube 60° cone; available in SST for Range 5 transmitters only).

3051S_L

High pressure side: 2-in. (50.8mm), 3-in. (72 mm), or 4-in. (102mm), ASME B 16.5 (ANSI) Class 150, 300 or 600 flange; 50, 80 or 100 mm, DIN 2501 PN 40 or 10/16 flange

Low pressure side: ¹/₄-18 NPT on flange, ¹/₂-14 NPT on process adapter

Process-Wetted Parts

Process Isolating Diaphragms

Isolating Diaphragm Material	3051S_			
	CD, CG	T	CA	L
316L SST	•	•	•	See Below
Hastelloy C-276 [®]	•	•	•	
Monel 400	•		•	
Tantalum	•			
Gold-plated Monel 400	•		•	
Gold-plated 316L SST	•		•	

Drain/Vent Valves

316 SST, Hastelloy C-276, or Monel 400 material (Monel is not available with 3051S_L).

Process Flanges and Adapters

Plated carbon steel,

CF-8M (Cast version of 316 SST, material per ASTM-A743), CW-12MW (Cast version of Hastelloy C-276, material per ASTM-A494),

M-30C (Cast version of Monel 400, material per ASTM-A494).

Wetted O-rings

Glass-filled TFE
(Graphite-filled TFE with Isolating Diaphragm code 6)

3051S_L Process Wetted Parts

Flanged Process Connection (Transmitter High Side)

Process Diaphragms, Including Process Gasket Surface

316L SST, *Hastelloy C-276*, or Tantalum

Extension

CF-3M (Cast version of 316L SST, material per ASTM-A743), or CW-12MW (Cast version of *Hastelloy C*, material ASTM A494); fits schedule 40 and 80 pipe

Mounting Flange

Zinc-cobalt plated CS or 316 SST

Reference Process Connection (Transmitter Low Side)

Isolating Diaphragms

316L SST or *Hastelloy C-276*

Reference Flange and Adapter

CF-3M (Cast version of 316L SST, material per ASTM-A743)

Non-Wetted Parts

Electronics Housing

Low-copper aluminum or CF-3M (Cast version of 316L SST) NEMA 4X, IP 66, IP 68

Coplanar Sensor Module Housing

CF-3M (Cast version of 316L SST)

Bolts

Plated carbon steel per ASTM A449, Type 1

Austenitic 316 SST

ASTM A 453, Class A, Grade 660

ASTM A 193, Grade B7M

ASTM A 193, Class 2, Grade B8M

Monel

Sensor Module Fill Fluid

Silicone or inert halocarbon (Inert is not available with 3051S_CA). In-Line series uses Fluorinert® FC-43.

Process Fill Fluid (Liquid Level Only)

3051S_L: *Syltherm XLT*, *D.C. Silicone 704*,
D.C. Silicone 200, inert, glycerin and water,
Neobee M-20, propylene glycol and water.

Paint

Polyurethane

Cover O-rings

Buna-N

Shipping Weights for 3051S

Table A-2. *SuperModule* Platform weights

SuperModule Platform	Weight in lb. (kg)
<i>Coplanar</i> ⁽¹⁾	3.1 (1,4)
In-Line	1.4 (0,6)

(1) Flange and bolts not included.

Table A-3. Transmitter weights without options

Complete Transmitter⁽¹⁾	Add Weight In lb (kg)
3051S_C with junction box housing	6.9 (3,1)
3051S_T with junction box housing	3.3 (1,5)
3051S_C with <i>PlantWeb</i> housing	7.2 (3,3)
3051S_T with <i>PlantWeb</i> housing	3.6 (1,6)

(1) Fully functional transmitter with terminal block, covers, and SST flange.

Table A-4. 3051S_L weights without options

Flange	Flush lb. (kg)	2-in. Ext. lb (kg)	4-in. Ext. lb (kg)	6-in. Ext. lb (kg)
2-in., 150	12.5 (5,7)	—	—	—
3-in., 150	17.5 (7,9)	19.5 (8,8)	20.5 (9,3)	21.5 (9,8)
4-in., 150	23.5 (10,7)	26.5 (12,0)	28.5 (12,9)	30.5 (13,8)
2-in., 300	17.5 (7,9)	—	—	—
3-in., 300	22.5 (10,2)	24.5 (11,1)	25.5 (11,6)	26.5 (12,0)
4-in., 300	32.5 (14,7)	35.5 (16,1)	37.5 (17,0)	39.5 (17,9)
2-in., 600	15.3 (6,9)	—	—	—
3-in., 600	25.2 (11,4)	27.2 (12,3)	28.2 (12,8)	29.2 (13,2)
DN 50 / PN 40	13.8 (6,2)	—	—	—
DN 80 / PN 40	19.5 (8,8)	21.5 (9,7)	22.5 (10,2)	23.5 (10,7)
DN 100 / PN 10/16	17.8 (8,1)	19.8 (9,0)	20.8 (9,5)	21.8 (9,9)
DN 100 / PN 40	23.2 (10,5)	25.2 (11,5)	26.2 (11,9)	27.2 (12,3)

Table A-5. Transmitter option weights

Option Code	Option	Add lb (kg)
1J, 1K, 1L	SST <i>PlantWeb</i> housing	3.4 (1,5)
2J	SST Junction Box housing	3.3 (1,5)
7J	SST Quick Connect	0.35 (0,16)
2A, 2B, 2C	Aluminum Junction Box housing	1.2 (0,5)
1A, 1B, 1C	Aluminum <i>PlantWeb</i> housing	1.2 (0,5)
M5	LCD display for aluminum <i>PlantWeb</i> housing ⁽¹⁾ , LCD display for SST <i>PlantWeb</i> housing ⁽¹⁾	0.8 (0,4) 1.72 (0,8)
B4	SST mounting bracket for <i>Coplanar</i> flange	0.6 (0,3)
B1, B2, B3	Mounting Bracket for Traditional flange	2.3 (1,0)
B7, B8, B9	Mounting Bracket for Traditional flange with SST bolts	2.3 (1,0)
BA, BC	SST Bracket for Traditional flange	2.3 (1,0)
F12, F22	SST Traditional flange ⁽²⁾	3.3 (1,5)
F13, F23	Traditional flange (<i>Hastelloy</i>)	2.7 (1,2)
E12, E22	SST <i>Coplanar</i> flange ⁽²⁾	1.9 (0,9)
F14, F24	Traditional flange (<i>Monel</i>)	2.6 (1,2)
F15, F25	Traditional Flange (SST with <i>Hastelloy</i> D/V)	2.5 (1,1)
G21	Level flange—3 in., 150	10.8 (4,9)
G22	Level flange—3 in., 300	14.3 (6,5)
G11	Level flange—2 in., 150	10.7 (4,9)
G12	Level flange—2 in., 300	14.0 (6,4)
G31	DIN Level flange, SST, DN 50, PN 40	8.3 (3,8)
G41	DIN Level flange, SST, DN 80, PN 40	13.7 (6,2)

(1) Includes LCD display connector board and display cover

(2) Includes mounting bolts

Item	Weight In lb. (kg)
Aluminum standard cover	0.4 (0,2)
SST standard cover	1.26 (0,6)
Aluminum display cover	0.7 (0,3)
SST display cover	1.56 (0,7)
LCD display ⁽¹⁾	0.1 (0,1)
Junction Box terminal block	0.3 (0,1)
<i>PlantWeb</i> terminal block	0.2 (0,1)

(1) Display only


Rosemount 3051S Series

DIMENSIONAL DRAWINGS


Dimensions are in inches (millimeters).

Process adapters (option D2) and Rosemount 305 integral manifolds must be ordered with the transmitter.


PlantWeb Housing with Coplanar SuperModule Platform and 305 Coplanar Integral Manifold




PlantWeb Housing with Coplanar SuperModule Platform and Coplanar Flange




Junction Box Housing with Coplanar SuperModule Platform and Coplanar Flange




Quick Connect with Coplanar SuperModule Platform and Coplanar Flange




Rosemount 3051S Series




PlantWeb Housing with Coplanar SuperModule Platform and 305 Traditional Integral Manifold





PlantWeb Housing with Coplanar SuperModule Platform and Traditional Flange



Rosemount 3051S Series








Rosemount 3051S Series

In-line Mounting Configurations with Optional Mounting Bracket

Pipe Mount




Panel Mount




3051S_L Liquid Level


Flush Flanged Configuration



Extended Flanged Configuration





Optional Flushing Connection Ring (Lower Housing)



Flushing Connection

Diaphragm Assembly and Mounting Flange



Rosemount 3051S Series

Table A-6. 3051S_L Dimensional Specifications

Except where indicated, dimensions are in inches (millimeters).

Class	Pipe Size	Flange Thickness A	Bolt Circle Diameter B	Outside Diameter C	No. of Bolts	Bolt Hole Diameter	Extension Diameter ⁽¹⁾ D	O.D. Gasket Surface E
ASME B16.5 (ANSI) 150	2 (51)	0.69 (18)	4.75 (121)	6.0 (152)	4	0.75 (19)	NA	3.6 (92)
	3 (76)	0.88 (22)	6.0 (152)	7.5 (191)	4	0.75 (19)	2.58 (66)	5.0 (127)
	4 (102)	0.88 (22)	7.5 (191)	9.0 (229)	8	0.75 (19)	3.5 (89)	6.2 (158)
ASME B16.5 (ANSI) 300	2 (51)	0.82 (21)	5.0 (127)	6.5 (165)	8	0.75 (19)	NA	3.6 (92)
	3 (76)	1.06 (27)	6.62 (168)	8.25 (210)	8	0.88 (22)	2.58 (66)	5.0 (127)
	4 (102)	1.19 (30)	7.88 (200)	10.0 (254)	8	0.88 (22)	3.5 (89)	6.2 (158)
ASME B16.5 (ANSI) 600	2 (51)	1.00 (25)	5.0 (127)	6.5 (165)	8	0.75 (19)	NA	3.6 (92)
	3 (76)	1.25 (32)	6.62 (168)	8.25 (210)	8	0.88 (22)	2.58 (66)	5.0 (127)
DIN 2501 PN 10–40	DN 50	20 mm	125 mm	165 mm	4	18 mm	NA	4.0 (102)
DIN 2501 PN 25/40	DN 80	24 mm	160 mm	200 mm	8	18 mm	65 mm	5.4 (138)
	DN 100	24 mm	190 mm	235 mm	8	22 mm	89 mm	6.2 (158)
DIN 2501 PN 10/16	DN 100	20 mm	180 mm	220 mm	8	18 mm	89 mm	6.2 (158)

Class	Pipe Size	Process Side F	Lower Housing G		
			1/4 NPT	1/2 NPT	H
ASME B16.5 (ANSI) 150	2 (51)	2.12 (54)	0.97 (25)	1.31 (33)	6.66 (169)
	3 (76)	3.6 (91)	0.97 (25)	1.31 (33)	6.66 (169)
	4 (102)	3.6 (91)	0.97 (25)	1.31 (33)	6.66 (169)
ASME B16.5 (ANSI) 300	2 (51)	2.12 (54)	0.97 (25)	1.31 (33)	6.66 (169)
	3 (76)	3.6 (91)	0.97 (25)	1.31 (33)	6.66 (169)
	4 (102)	3.6 (91)	0.97 (25)	1.31 (33)	6.66 (169)
ASME B16.5 (ANSI) 600	2 (51)	2.12 (54)	0.97 (25)	1.31 (33)	8.66 (219)
	3 (76)	3.6 (91)	0.97 (25)	1.31 (33)	8.66 (219)
DIN 2501 PN 10–40	DN 50	2.4 (61)	0.97 (25)	1.31 (33)	6.66 (169)
DIN 2501 PN 25/40	DN 80	3.6 (91)	0.97 (25)	1.31 (33)	6.66 (169)
	DN 100	3.6 (91)	0.97 (25)	1.31 (33)	6.66 (169)
DIN 2501 PN 10/16	DN 100	3.6 (91)	0.97 (25)	1.31 (33)	6.66 (169)

(1) Tolerances are 0.040 (1,02), -0.020 (0,51).

ORDERING INFORMATION

Rosemount 3051S Series *Coplanar*

Model	Transmitter Type			
3051S	Scalable pressure transmitter			
Code	Performance Class			
1	Ultra: 0.025% span accuracy, 200:1 rangedown, 10-year stability, limited 12-year warranty			
3 ⁽¹⁾	Ultra for Flow: 0.04% reading accuracy, 200:1 rangedown, 10-year stability, limited 12-year warranty			
2	Classic: 0.055% span accuracy, 100:1 rangedown, 5-year stability			
Code	Connection Type			
C	<i>Coplanar</i>			
Code	Measurement Type ⁽²⁾			
D	Differential			
G	Gage			
A	Absolute			
Code	Pressure Range			
	Differential	Gage	Absolute	
0A ⁽³⁾	-3 to 3 inH ₂ O (-7,47 to 7,47 mbar)	N/A	0 to 5 psia (0 to 0,34 bar)	
1A	-25 to 25 inH ₂ O (-62,2 to 62,2 mbar)	-25 to 25 inH ₂ O (-62,2 to 62,2 mbar)	0 to 30 psia (0 to 2,06 bar)	
2A	-250 to 250 inH ₂ O (-623 to 623 mbar)	-250 to 250 inH ₂ O (-623 to 623 mbar)	0 to 150 psia (0 to 10,34 bar)	
3A	-1000 to 1000 inH ₂ O (-2,5 to 2,5 bar)	-393 to 1000 inH ₂ O (-0,98 to 2,5 bar)	0 to 800 psia (0 to 55,2 bar)	
4A	-300 to 300 psi (-20,7 to 20,7 bar)	-14.2 to 300 psig (-0,98 to 21 bar)	0 to 4000 psia (0 to 275,8 bar)	
5A	-2000 to 2000 psi (-137,9 to 137,9 bar)	-14.2 to 2000 psig (-0,98 to 137,9 bar)	N/A	
Code	Isolating Diaphragm			
2 ⁽⁴⁾	316L SST			
3 ⁽⁴⁾	<i>Hastelloy C-276</i>			
4	<i>Monel 400</i>			
5 ⁽⁵⁾	Tantalum			
6	Gold-plated <i>Monel 400</i> <i>Note: Includes graphite-filled TFE o-ring.</i>			
7	Gold-plated 316L SST			
Code	Process Connection ⁽⁶⁾	Size	Material Type ⁽⁷⁾	
			Flange Material	Drain Vent
000	None			
A11	Assemble to Rosemount 305 integral manifold			
A12	Assemble to 304 or AMF manifold and 316 SST traditional flange			
B11 ⁽⁸⁾	Assemble to one Rosemount 1199 diaphragm seal			
B12 ⁽⁸⁾	Assemble to two Rosemount 1199 diaphragm seals			
C11	Assemble to Rosemount 405 primary element			
D11	Assemble to Rosemount 1195 integral orifice and Rosemount 305 integral manifold			
EA2	Assemble to Rosemount <i>Annubar</i> Primary Element with <i>Coplanar</i> flange		316 SST	316 SST
EA3	Assemble to Rosemount <i>Annubar</i> Primary Element with <i>Coplanar</i> flange		<i>Hastelloy C-276</i>	<i>Hastelloy C-276</i>
EA5	Assemble to Rosemount <i>Annubar</i> Primary Element with <i>Coplanar</i> flange		316 SST	<i>Hastelloy C-276</i>
E11	<i>Coplanar</i> flange	1/4-18 NPT	CS	316 SST
E12	<i>Coplanar</i> flange	1/4-18 NPT	316 SST	316 SST
E13 ⁽⁴⁾	<i>Coplanar</i> flange	1/4-18 NPT	<i>Hastelloy C-276</i>	<i>Hastelloy C-276</i>
E14	<i>Coplanar</i> flange	1/4-18 NPT	<i>Monel 400</i>	<i>Monel 400</i>
E15 ⁽⁴⁾	<i>Coplanar</i> flange	1/4-18 NPT	316 SST	<i>Hastelloy C-276</i>
E16 ⁽⁴⁾	<i>Coplanar</i> flange	1/4-18 NPT	CS	<i>Hastelloy</i>
E21	<i>Coplanar</i> flange	RC 1/4	CS	316 SST
E22	<i>Coplanar</i> flange	RC 1/4	316 SST	316 SST
E23 ⁽⁴⁾	<i>Coplanar</i> flange	RC 1/4	<i>Hastelloy C-276</i>	<i>Hastelloy C-276</i>
E24	<i>Coplanar</i> flange	RC 1/4	<i>Monel 400</i>	<i>Monel 400</i>
E25 ⁽⁴⁾	<i>Coplanar</i> flange	RC 1/4	316 SST	<i>Hastelloy C-276</i>
E26 ⁽⁴⁾	<i>Coplanar</i> flange	RC 1/4	CS	<i>Hastelloy C-276</i>
F12	Traditional flange	1/4-18 NPT	316 SST	316 SST
F13 ⁽⁴⁾	Traditional flange	1/4-18 NPT	<i>Hastelloy C-276</i>	<i>Hastelloy C-276</i>

Rosemount 3051S Series

F14	Traditional flange	1/4–18 NPT	Monel 400	Monel 400	
F15 ⁽⁴⁾	Traditional flange	1/4–18 NPT	316 SST	Hastelloy C-276	
F22	Traditional flange	RC 1/4	316 SST	316 SST	
F23 ⁽⁴⁾	Traditional flange	RC 1/4	Hastelloy C-276	Hastelloy C-276	
F24	Traditional flange	RC 1/4	Monel 400	Monel 400	
F25 ⁽⁴⁾	Traditional flange	RC 1/4	316 SST	Hastelloy C-276	
F32	Bottom vent traditional flange	1/4–18 NPT	316 SST	316 SST	
F52	DIN-compliant traditional flange	1/4–18 NPT	316 SST	316 SST	7/16-in. bolting
F62	DIN-compliant traditional flange	1/4–18 NPT	316 SST	316 SST	M10 bolting
F72	DIN-compliant traditional flange	1/4–18 NPT	316 SST	316 SST	M12 bolting
G11	Vertical mount level flange	2-in. ANSI class 150	316 SST		
G12	Vertical mount level flange	2-in. ANSI class 300	316 SST		
G14 ⁽⁴⁾	Vertical mount level flange	2-in. ANSI class 150	Hastelloy C-276		
G15 ⁽⁴⁾	Vertical mount level flange	2-in. ANSI class 300	Hastelloy C-276		
G21	Vertical mount level flange	3-in. ANSI class 150	316 SST		
G22	Vertical mount level flange	3-in. ANSI class 300	316 SST		
G24 ⁽⁴⁾	Vertical mount level flange	3-in. ANSI class 150	Hastelloy C-276		
G25 ⁽⁴⁾	Vertical mount level flange	3-in. ANSI class 300	Hastelloy C-276		
G31	Vertical mount level flange	DIN- DN 50 PN 40	316 SST		
G41	Vertical mount level flange	DIN- DN 80 PN 40	316 SST		

Code	Output ⁽⁹⁾
A	4–20 mA with digital signal based on HART protocol
F ⁽¹⁰⁾	FOUNDATION fieldbus protocol

Code	Housing Style	Material ⁽⁷⁾	Conduit Entry Size
00	None (<i>SuperModule</i> Platform only, no housing included)		
01 ⁽¹¹⁾	Assemble to Rosemount 753R Web-Based Monitoring Indicator		
1A	<i>PlantWeb</i> housing	Aluminum	1/2–14 NPT
1B	<i>PlantWeb</i> housing	Aluminum	M20 x 1.5 (CM20)
1C	<i>PlantWeb</i> housing	Aluminum	G ¹ / ₂
1J	<i>PlantWeb</i> housing	316L SST	1/2–14 NPT
1K	<i>PlantWeb</i> housing	316L SST	M20 x 1.5 (CM20)
1L	<i>PlantWeb</i> housing	316L SST	G ¹ / ₂
2A	Junction Box housing	Aluminum	1/2–14 NPT
2B	Junction Box housing	Aluminum	M20 x 1.5 (CM20)
2C	Junction Box housing	Aluminum	G ¹ / ₂
2J	Junction Box housing	316L SST	1/2–14 NPT
2E	Junction Box Housing with output for remote display and interface	Aluminum	1/2–14 NPT
2F	Junction Box Housing with output for remote display and interface	Aluminum	M20 x 1.5 (CM20)
2G	Junction Box Housing with output for remote display and interface	Aluminum	G ¹ / ₂
2M	Junction Box Housing with output for remote display and interface	316L SST	1/2–14 NPT
7J ⁽¹²⁾	Quick Connect (A size Mini, 4-pin male termination)	316L SST	

Code	Options
------	---------

PlantWeb Control Functionality

A01 ⁽¹³⁾	FOUNDATION fieldbus Advanced Control Function Block Suite
---------------------	---

PlantWeb Diagnostic Functionality

D01 ⁽¹³⁾	FOUNDATION fieldbus Diagnostics Suite
DA1 ⁽¹⁴⁾	HART Diagnostics Suite

PlantWeb Enhanced Measurement Functionality

H01 ⁽¹³⁾⁽¹⁵⁾	Fully Compensated Mass Flow Block
-------------------------	-----------------------------------

Code	Options
------	---------

Mounting Brackets⁽¹⁶⁾

B4	<i>Coplanar</i> flange bracket, all SST, 2-in. pipe and panel
B1	Traditional flange bracket, CS, 2-in. pipe
B2	Traditional flange bracket, CS, panel
B3	Traditional flange flat bracket, CS, 2-in. pipe
B7	Traditional flange bracket, B1 with SST bolts
B8	Traditional flange bracket, B2 with SST bolts

B9	Traditional flange bracket, B3 with SST bolts
BA	Traditional flange bracket, B1, all SST
BC	Traditional flange bracket, B3, all SST
Special Configuration (Software)	
C1 ⁽¹⁷⁾	Custom software configuration <i>Note: A Configuration Data Sheet must be completed, see 00806-0100-4801.</i>
C3	Gage pressure calibration on Rosemount 3051S_CA4 only
C4	NAMUR alarm and saturation levels, high alarm
C5 ⁽¹⁷⁾	NAMUR alarm and saturation levels, low alarm
C6 ⁽¹⁷⁾	Custom alarm and saturation signal levels, high alarm <i>Note: Requires option code C1, custom software configuration. A Configuration Data Sheet must be completed, see 00806-0100-4801.</i>
C7 ⁽¹⁷⁾	Custom alarm and saturation signal levels, low alarm <i>Note: Requires option code C1, custom software configuration. A Configuration Data Sheet must be completed, see 00806-0100-4801.</i>
C8 ⁽¹⁷⁾	Low alarm (standard Rosemount alarm and saturation levels)
Special Configuration (Hardware)	
D1 ⁽¹⁷⁾	Hardware adjustments (zero, span, alarm, security) <i>Note: Not available with housing style codes 00, 01, 2E, 2F, 2G, 2M, 5A, or 7J.</i>
D2 ⁽¹⁶⁾	Process adapters 1/2-14 NPT
D4	External ground screw assembly
D5 ⁽¹⁶⁾	Delete transmitter drain/vent valves (install plugs)
D7 ⁽¹⁶⁾	Coplanar flange without drain/vent ports
D8 ⁽¹⁶⁾	Ceramic drain/vent valves
D9 ⁽¹⁶⁾	RC 1/2 process adapters
Product Certifications⁽¹⁸⁾	
E1	ATEX Flameproof
I1	ATEX Intrinsically Safe
IA	ATEX FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only
N1	ATEX Type n
K1	ATEX Flameproof, Intrinsically Safe, Type n, Dust (combination of E1, I1, N1, and ND)
ND	ATEX Dust
E4	JIS Flameproof
E5	FM Explosion-proof
I5	FM Intrinsically Safe, Non-Incendive
IE	FM FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only
K5	FM Explosion-proof, Intrinsically Safe, Non-Incendive (combination of E5 and I5)
E6	CSA Explosion-proof, Division 2
I6	CSA Intrinsically Safe
IF	CSA FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only
K6	CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E6 and I6)
D3 ⁽¹⁹⁾	Measurement Canada Accuracy Approval
E7	SAA Flameproof, Dust Ignition-proof
I7	IECEx Intrinsically Safe
IG	IECEx FISCO Intrinsically Safe
N7	IECEx Type n
K7	SAA Flameproof, Dust Ignition-proof, IECEx Intrinsically Safe, and Type n (combination of E7, I7, and N7)
KA	ATEX and CSA Flameproof, Intrinsically Safe (combination of E1, I1, E6, and I6) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>
KB	FM and CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E5, E6, I5, and I6) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>
KC	FM and ATEX Explosion-proof, Intrinsically Safe, Non-Incendive (combination of E5, E1, I5, and I1) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>
KD	FM, CSA, and ATEX Explosion-proof, Intrinsically Safe (combination of E5, I5, E6, I6, E1, and I1) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>
DW ⁽²⁰⁾	NSF Drinking Water Approval
Alternate Materials of Construction	
L1	Inert sensor fill fluid (differential and gage only) <i>Note: Silicone fill fluid is standard.</i>
L2	Graphite-filled Teflon [®] (PTFE) o-ring
L4 ⁽¹⁶⁾	Austenitic 316 SST bolts

Rosemount 3051S Series

L5 ⁽¹⁶⁾	ASTM A 193, Grade B7M bolts
L6 ⁽¹⁶⁾	Monel bolts
L7 ⁽¹⁶⁾	ASTM A 453, Class A, Grade 660 bolts
L8 ⁽¹⁶⁾	ASTM A 193, Class 2, Grade B8M bolts
Digital Display⁽²¹⁾	
M5	PlantWeb LCD Display
M7 ⁽²²⁾	Remote mount LCD display and interface, no cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output <i>Note: Use Belden 3084A cable or equivalent. Contact an Emerson Process Management representative for additional information.</i>
M8 ⁽²²⁾	Remote mount LCD display and interface, 50 ft. (15 m) cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output
M9 ⁽²²⁾	Remote mount LCD display and interface, 100 ft. (31 m) cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output
Special Procedures	
P1	Hydrostatic testing with certificate
P2 ⁽¹⁶⁾	Cleaning for special services
P3 ⁽¹⁶⁾	Cleaning for less than 1PPM chlorine/fluorine
P9	4500 psig (310 bar) static pressure limit (Rosemount 3051S_CD only)
P0 ⁽²³⁾	6092 psig (420 bar) static pressure limit (Rosemount 3051S2CD only)
Special Certifications	
Q4	Calibration certificate
QP	Calibration certificate and tamper evident seal
Q8	Material traceability certification per EN 10204 3.1.B
QS ⁽²⁴⁾	Prior-use certificate of FMEDA Data
QT ⁽²⁵⁾	Safety certified to IEC 61508 with certificate of FMEDA data
Q16	Surface finish certification for sanitary remote seals
Terminal Blocks	
T1 ⁽²⁶⁾	Transient terminal block
T2 ⁽²⁷⁾	Terminal block with WAGO® spring clamp terminals
T3 ⁽²⁷⁾	Transient terminal block with WAGO spring clamp terminals
Conduit Electrical Connector	
GE ⁽²⁸⁾	M12, 4-pin, Male Connector (eurofast®)
GM ⁽²⁸⁾	A size Mini, 4-pin, Male Connector (minifast®)

Typical Model Number: 3051S1CD 2A 2 E12 A 1A DA1 B4 M5

- (1) Not available with Housing code 01. This option is only available with range codes 2A and 3A, 316L SST isolating diaphragm and silicone fill fluid.
- (2) Performance Class code 3 is available with Measurement Type code D only.
- (3) 3051S_CD0 is only available with traditional flange, 316 SST diaphragm material, silicone fill fluid, and Bolting option L4.
- (4) Materials of Construction comply with metallurgical requirements highlighted within NACE MR0175/ISO 15156 for sour oil field production environments. Environmental limits apply to certain materials. Consult latest standard for details. Selected materials also conform to NACE MR0103 for sour refining environments.
- (5) Tantalum diaphragm material is only available for ranges 2A - 5A, differential and gage.
- (6) Process connection option codes B12, C11, D11, EA2, EA3 and EA5 are only available on differential Measurement Type, code D.
- (7) Material specified is cast as follows: CF-8M is the cast version of 316 SST, CF-3M is the cast version of 316L SST, CW-12MW is the cast version of Hastelloy C-276, M-30C is the cast version of Monel 400. For housing, material is aluminum with polyurethane paint.
- (8) Consult an Emerson Process Management representative for performance specifications.
- (9) For spare SuperModule Platforms, select output code A.
- (10) Requires PlantWeb housing.
- (11) Available with output code A only. Not available with approvals. See Rosemount 753R Product Data Sheet, 00813-0100-4379, to specify Web-Based Monitoring Indicator. Does not integrate into plant host systems.
- (12) Available with output code A only. Available approvals are FM Intrinsically Safe, Non-Incendive (option code I5), ATEX Intrinsically Safe (option code I1), or IECEx Intrinsically Safe (option code I7). Contact an Emerson Process Management representative for additional information.
- (13) Requires PlantWeb housing and output code F.
- (14) Requires PlantWeb housing and output code A. Includes Hardware Adjustments as standard. Not available with option code QT.
- (15) Requires Rosemount Engineering Assistant to configure.
- (16) Not available with process connection option code A11.
- (17) Not available with output code F or Housing code 01.
- (18) Valid when SuperModule Platform and housing have equivalent approvals.
- (19) Requires PlantWeb housing and Hardware Adjustments option code D1. Limited availability depending on transmitter type and range. Contact an Emerson Process Management representative for additional information.
- (20) Requires 316L SST wetted materials, glass-filled TFE O-ring (standard), and Process Connection code E12 or F12.
- (21) Not available with Housing code 01 or 7J.
- (22) Not available with output code F, Housing code 01, option code DA1, or option code QT.
- (23) Requires 316L SST or Hastelloy C-276 diaphragm material, assemble to Rosemount 305 integral manifold or DIN-compliant traditional flange process connection, and bolting option L8. Limited to Pressure Range (Differential), ranges 2A - 5A.
- (24) Not available with Housing code 01.
- (25) Not available with output code F. Not available with housing code 01 or 7J.
- (26) Not available with Housing code 00, 01, 5A, or 7J.
- (27) Available with output code A and PlantWeb housing only.
- (28) Not available with Housing code 00, 01, 5A, or 7J. Available with Intrinsically Safe approvals only. For FM Intrinsically Safe, Non-Incendive approval (option code I5) or FM FISCO Intrinsically Safe approval (option code IE), install in accordance with Rosemount drawing 03151-1009 to maintain outdoor rating (NEMA 4X and IP66).

Rosemount 3051S Series In-Line

Model	Transmitter Type		
3051S	Scalable pressure transmitter		
Code	Performance Class		
1	Ultra: 0.025% span accuracy, 200:1 rangedown, 10-year stability, limited 12-year warranty		
2	Classic: 0.055% span accuracy, 100:1 rangedown, 5-year stability		
Code	Device Type		
T	In-Line		
Code	Measurement Type		
G	Gage		
A	Absolute		
Code	Pressure Range		
	TG	TA	
1A	-14.7 to 30 psi (-1,0 to 2,1 bar)	0 to 30 psia (2,1 bar)	
2A	-14.7 to 150 psi (-1,0 to 10,3 bar)	0 to 150 psia (10,3 bar)	
3A	-14.7 to 800 psi (-1,0 to 55 bar)	0 to 800 psia (55 bar)	
4A	-14.7 to 4000 psi (-1,0 to 276 bar)	0 to 4000 psia (276 bar)	
5A	-14.7 to 10000 psi (-1,0 to 689 bar)	0 to 10000 psia (689 bar)	
Code	Isolating Diaphragm / Process Connection Material		
2 ⁽¹⁾	316L SST		
3 ⁽¹⁾	Hastelloy C-276		
Code	Process Connection Style		
A11	Assemble to Rosemount 306 integral manifold		
B11 ⁽²⁾	Assemble to one Rosemount 1199 diaphragm seal		
E11	1/2-14 NPT female		
F11	Non-threaded instrument-flange (I-flange) (Range 1-4 only)		
G11	G1/2 A DIN 16288 male (Range 1-4 only)		
H11	Coned and threaded, compatible with autoclave type F-250-C (Range 5A only)		
Code	Output ⁽³⁾		
A	4-20 mA with digital signal based on HART protocol		
F ⁽⁴⁾	FOUNDATION fieldbus protocol		
Code	Housing Style	Materials ⁽⁵⁾	Conduit Entry Size
00	None (<i>SuperModule</i> Platform only, no housing included)		
01 ⁽⁶⁾	Assemble to Rosemount 753R Web-Based Monitoring Indicator		
1A	PlantWeb housing	Aluminum	1/2-14 NPT
1B	PlantWeb housing	Aluminum	M20 x 1.5 (CM20)
1C	PlantWeb housing	Aluminum	G1/2
1J	PlantWeb housing	316L SST	1/2-14 NPT
1K	PlantWeb housing	316L SST	M20 x 1.5 (CM20)
1L	PlantWeb housing	316L SST	G 1/2
2A	Junction Box housing	Aluminum	1/2-14 NPT
2B	Junction Box housing	Aluminum	M20 x 1.5 (CM20)
2C	Junction Box housing	Aluminum	G 1/2
2J	Junction Box housing	316L SST	1/2-14 NPT
2E	Junction Box housing with output for remote interface	Aluminum	1/2-14 NPT
2F	Junction Box housing with output for remote interface	Aluminum	M20 x 1.5 (CM20)
2G	Junction Box housing with output for remote interface	Aluminum	G1/2
2M	Junction Box housing with output for remote interface	316L SST	1/2-14 NPT
7J ⁽⁷⁾	Quick Connect (A size Mini, 4-pin male termination)	316L SST	
Code	Options		
PlantWeb Control Functionality			
A01 ⁽⁸⁾	FOUNDATION fieldbus Advanced Control Function Block Suite		
PlantWeb Diagnostic Functionality			
D01 ⁽⁸⁾	FOUNDATION fieldbus Diagnostics Suite		
DA1 ⁽⁹⁾	HART Diagnostics Suite		

Rosemount 3051S Series

PlantWeb Enhanced Measurement Functionality

H01⁽⁸⁾⁽¹⁰⁾ Fully Compensated Mass Flow Block

Code Options

Mounting Bracket

B4 Bracket, all SST, 2-in. pipe and panel

Special Configuration (Software)⁽¹¹⁾

C1⁽¹¹⁾ Custom software configuration

Note: A Configuration Data Sheet must be completed, see 00806-0100-4801.

C4⁽¹¹⁾ NAMUR alarm and saturation values, high alarm

C5⁽¹¹⁾ NAMUR alarm and saturation values, low alarm

C6⁽¹¹⁾ Custom alarm and saturation signal levels, high alarm

Note: Requires option code C1, custom software configuration. A Configuration Data Sheet must be completed, see 00806-0100-4801.

C7⁽¹¹⁾ Custom alarm and saturation signal levels, low alarm

Note: Requires option code C1, custom software configuration. A Configuration Data Sheet must be completed, see 00806-0100-4801.

C8⁽¹¹⁾ Low alarm (Standard Rosemount alarm and saturation signal levels)

Special Configuration (Hardware)

D1⁽¹¹⁾ Hardware adjustments (zero, span, alarm, security)

Note: Not available with Housing Style codes 00, 01, 2E, 2F, 2G, 2M, 5A, or 7J.

D4 External ground screw assembly

Product Certifications⁽¹²⁾

E1 ATEX Flameproof

I1 ATEX Intrinsically Safe

IA ATEX FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only

N1 ATEX Type n

K1 ATEX Flameproof, Intrinsically Safe, Type n, Dust (combination of E1, I1, N1, and ND)

ND ATEX Dust

E4 JIS Flameproof

E5 FM Explosion-proof

I5 FM Intrinsically Safe, Non-Incendive

IE FM FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only

K5 FM Explosion-proof, Intrinsically Safe, Non-Incendive (combination of E5 and I5)

E6 CSA Explosion-proof, Division 2

I6 CSA Intrinsically Safe

IF CSA FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only

K6 CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E6 and I6)

D3⁽¹³⁾ Measurement Canada Accuracy Approval

E7 SAA Flameproof, Dust Ignition-proof

I7 IECEx Intrinsically Safe

IG IECEx FISCO Intrinsically Safe

N7 IECEx Type n

K7 SAA Flameproof, Dust Ignition-proof, IECEx Intrinsically Safe, and Type n (combination of E7, I7, and N7)

KA ATEX and CSA Flameproof, Intrinsically Safe (combination of E1, I1, E6, and I6)

Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.

KB FM and CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E5, E6, I5, and I6)

Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.

KC FM and ATEX Explosion-proof, Intrinsically Safe, Non-Incendive (combination of E5, E1, I5, and I1)

Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.

KD FM, CSA, and ATEX Explosion-proof, Intrinsically Safe (combination of E5, I5, E6, I6, E1, and I1)

Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.

DW⁽¹⁴⁾ NSF Drinking Water Approval

Alternate Materials of Construction

L1 Inert sensor fill fluid *Note: Silicone fill fluid is standard.*

Digital Display⁽¹⁵⁾

M5 PlantWeb LCD Display

M7⁽¹⁶⁾ Remote mount LCD display and interface, no cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output

Note: Use Belden 3084A cable or equivalent. Contact an Emerson Process Management representative for additional information.

M8⁽¹⁶⁾ Remote mount LCD display and interface, 50 ft. (15 m) cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output

M9⁽¹⁶⁾ Remote mount LCD display and interface, 100 ft. (31 m) cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output

Special Procedures

P1	Hydrostatic testing with certificate
P2 ⁽¹⁷⁾	Cleaning for special services
P3 ⁽¹⁷⁾	Cleaning for less than 1 PPM chlorine/fluorine

Special Certifications

Q4	Calibration certificate
QP	Calibration certificate and tamper evident seal
Q8	Material traceability certification per EN 10204 3.1.B
QS ⁽¹⁸⁾	Prior-use certificate of FMEDA Data
QT ⁽¹⁹⁾	Safety certified to IEC 61508 with certificate of FMEDA data
Q16	Surface finish certification for sanitary remote seals

Terminal Blocks

T1 ⁽²⁰⁾	Transient terminal block
T2 ⁽²¹⁾	Terminal block with WAGO® spring clamp terminals
T3 ⁽²¹⁾	Transient terminal block with WAGO spring clamp terminals

Conduit Electrical Connector

GE ⁽²²⁾	M12, 4-pin, Male Connector (<i>euromast</i> ®)
GM ⁽²²⁾	A size Mini, 4-pin, Male Connector (<i>minifast</i> ®)

Typical Model Number: 3051S1TG 2A 2 E11 A 1A DA1 B4 M5

- (1) *Materials of Construction comply with metallurgical requirements highlighted within NACE MR0175/ISO 15156 for sour oil field production environments. Environmental limits apply to certain materials. Consult latest standard for details. Selected materials also conform to NACE MR0103 for sour refining environments.*
- (2) *Contact a Rosemount representative for performance specifications.*
- (3) *For spare SuperModule Platforms, select output code A.*
- (4) *Requires PlantWeb housing.*
- (5) *Material specified is cast as follows: CF-3M is the cast version of 316L SST. For housing, material is aluminum with polyurethane paint.*
- (6) *Available with output code A only. Not available with approvals. See Rosemount 753R Product Data Sheet, 00813-0100-4379, to specify Web-Based Monitoring Indicator. Does not integrate into plant host systems.*
- (7) *Available with output code A only. Available approvals are FM Intrinsically Safe, Non-Incendive (option code I5), ATEX Intrinsically Safe (option code I1), or IECEx Intrinsically Safe (option code I7). Contact an Emerson Process Management representative for additional information.*
- (8) *Requires PlantWeb housing and output code F.*
- (9) *Requires PlantWeb housing and output code A. Includes Hardware Adjustments as standard. Not available with option code QT.*
- (10) *Requires Rosemount Engineering Assistant to configure.*
- (11) *Not available with output code F or Housing code 01.*
- (12) *Valid when SuperModule Platform and housing have equivalent approvals.*
- (13) *Requires PlantWeb housing and Hardware Adjustments option code D1. Limited availability depending on transmitter type and range. Contact an Emerson Process Management representative for additional information.*
- (14) *Requires 316L SST wetted materials and Process Connection code E11 or G11.*
- (15) *Not available with Housing code 01 and 7J.*
- (16) *Not available with output code F, Housing code 01, option code DA1, or option code QT.*
- (17) *Not available with process connection option code A11.*
- (18) *Not available with Housing code 01.*
- (19) *Not available with output code F. Not available with housing code 01 or 7J.*
- (20) *Not available with Housing code 00, 01, 5A, or 7J.*
- (21) *Available with output code A and PlantWeb housing only.*
- (22) *Not available with Housing code 00, 01, 5A, or 7J. Available with Intrinsically Safe approvals only. For FM Intrinsically Safe, Non-Incendive approval (option code I5) or FM FISCO Intrinsically Safe approval (option code IE), install in accordance with Rosemount drawing 03151-1009 to maintain outdoor rating (NEMA 4X and IP66).*

Rosemount 3051S Series

Rosemount 3051S Series Liquid Level

Select either FF diaphragm seal type (see “Flush Flanged Seal” on page A-33) or for EF diaphragm seal type (see “Extended Flanged Seal” on page A-34) and then finish this selection by choosing transmitter options.

Model	Transmitter Type		
3051S	Scalable pressure transmitter		
Code	Performance Class		
1	Ultra: 0.065% span accuracy, 100:1 rangedown, limited 12-year warranty		
2	Classic: 0.065% span accuracy, 100:1 rangedown		
Code	Connection Type		
L	Level		
Code	Measurement Type		
D	Differential		
G	Gage		
A	Absolute		
Code	Pressure Range		
	Differential (LD)		
	Gage (LG)		
	Absolute (LA)		
1A	-25 to 25 inH ₂ O (-62,2 to 62,2 mbar)	-25 to 25 inH ₂ O (-62,2 to 62,2 mbar)	0 to 30 psia (2,1 bar)
2A	-250 to 250 inH ₂ O (-623 to 623 mbar)	-250 to 250 inH ₂ O (-623 to 623 mbar)	0 to 150 psia (10 bar)
3A	-1000 to 1000 inH ₂ O (-2,5 to 2,5 bar)	-393 to 1000 inH ₂ O (-0,98 to 2,5 bar)	0 to 800 psia (55 bar)
4A	-300 to 300 psi (-20,7 to 20,7 bar)	-14.2 to 300 psig (-0,98 to 21 bar)	0 to 4000 psia (276 bar)
5A	-2000 to 2000 psi (-137,9 to 137,9 bar)	-14.2 to 2000 psig (-0,98 to 137,9 bar)	N/A
Code	Output ⁽¹⁾		
A	4-20 mA with digital signal based on HART protocol		
F ⁽²⁾	FOUNDATION fieldbus protocol		
Code	Housing Style	Material ⁽³⁾	Conduit Entry
00	None (<i>SuperModule</i> Platform only, no housing included)		
01 ⁽⁴⁾	Assemble to Rosemount 753R Web-Based Monitoring Indicator		
1A	<i>PlantWeb</i> housing	Aluminum	1/2-14 NPT
1B	<i>PlantWeb</i> housing	Aluminum	M20 x 1.5 (CM20)
1C	<i>PlantWeb</i> housing	Aluminum	G ¹ / ₂
1J	<i>PlantWeb</i> housing	316L SST	1/2-14 NPT
1K	<i>PlantWeb</i> housing	316L SST	M20 x 1.5 (CM20)
1L	<i>PlantWeb</i> housing	316L SST	G ¹ / ₂
2A	Junction Box housing	Aluminum	1/2-14 NPT
2B	Junction Box housing	Aluminum	M20 x 1.5 (CM20)
2C	Junction Box housing	Aluminum	G ¹ / ₂
2J	Junction Box housing	316L SST	1/2-14 NPT
2E	Junction Box with output for remote interface	Aluminum	1/2-14 NPT
2F	Junction Box with output for remote interface	Aluminum	M20 x 1.5 (CM20)
2G	Junction Box with output for remote interface	Aluminum	G ¹ / ₂
2M	Junction Box with output for remote interface	316L SST	1/2-14 NPT
7J ⁽⁵⁾	Quick Connect (A size Mini, 4-pin male termination)	316L SST	
Code	Seal System Type		
1	Direct-mount diaphragm seal system		
Code	High Pressure Side Extension (between transmitter flange and seal)		
0	Direct-mount (No extension)		
Code	Low Pressure Side Connection (sensor module)		
1	One capillary connection remote diaphragm seal (see Rosemount 1199 ordering table for seal information)		
2	316L SST isolator / 316 SST transmitter flange		
3	<i>Hastelloy C-276</i> isolator / 316 SST transmitter flange		
Code	Capillary Length		
0	N/A		
Code	Diaphragm Seal Fill Fluid		
A	<i>Syltherm XLT</i>		
C	D. C. Silicone 704		
D	D. C. Silicone 200		
H	Inert (Halocarbon)		
G	Glycerine and Water		
N	<i>Neobee M-20</i>		
P	Propylene Glycol and Water		

Next, select either Flush Flanged (FF) diaphragm seal (see page A-33) or Extended Flanged (EF) diaphragm seal (see page A-34).

Seal Options (page A-33—A-34)

Flush Flanged Seal

Code	Process Connection Style	
FF	Flush Flanged, Ra 125-250 gasket surface	
Code	Diaphragm Seal Size (High Side)	
G	2-in./DN 50	
7	3-in.	
J	DN 80	
9	4-in./DN 100	
Code	Flange Rating (High Side)	
1	Class 150	
2	Class 300	
4	Class 600	
G	PN 40	
E	PN 10/16; available with 4 in. DN 100 only	
Code	Isolator Material	Flange Material (High Side)
CA	316L SST	CS
DA	316L SST	316 SST
CB	Hastelloy	CS
DB	Hastelloy	316 SST
CC	Tantalum - seam welded ⁽⁶⁾	CS
DC	Tantalum - seam welded ⁽⁶⁾	316 SST
Code	Lower Housing Material (High Side) ⁽⁷⁾	
0	None	
A	316 SST	
B	Hastelloy	
Code	Flushing Connection Quantity and Size (Lower Housing, High Side)	
0	None	
1	1 (1/4-in.)	
3	2 (1/4-in.)	
7	1 (1/2-in.)	
9	2 (1/2-in.)	
Code	Seal Options: Gaskets	
SJ	Teflon [®] (PTFE) gasket for lower housing	
SK	Gylon gasket for lower housing	
SN	Grafoil [™] gasket for lower housing	
Code	Other Options	
ST ⁽⁸⁾	Materials per NACE MR0175	

Continue with transmitter options on page A-34

- (1) For spare SuperModule Platforms, select output code A.
- (2) Requires PlantWeb housing.
- (3) Material specified is cast as follows: CF-3M is the cast version of 316L SST. For housing, material is aluminum with polyurethane paint.
- (4) Available with output code A only. Not available with approvals. See Rosemount 753R Product Data Sheet, 00813-0100-4379, to specify Web-Based Monitoring Indicator. Does not integrate into plant host systems.
- (5) Available with output code A only. Available approvals are FM Intrinsically Safe, Non-Incendive (option code I5), ATEX Intrinsically Safe (option code I1), or IECEx Intrinsically Safe (option code I7). Contact an Emerson Process Management representative for additional information.
- (6) Not recommended for use with spiral wound metallic gaskets (see 1199 product data sheet, document 00813-0100-4016 for additional options).
- (7) Standard gasket for lower housing consists of non-asbestos fiber.
- (8) Materials of Construction comply with metallurgical requirements highlighted within NACE MR0175/ISO 15156 for sour oil field production environments. Environmental limits apply to certain materials. Consult latest standard for details. Selected materials also conform to NACE MR0103 for sour refining environments.

Rosemount 3051S Series

Extended Flanged Seal

Code	Process Connection Style	
EF	Extended flanged, Ra 125-250 gasket surface	
Code	Diaphragm Seal Size (High Side)	
7	3-in./DN 80, 2.58-in. diaphragm	
9	4-in./DN 100, 3.5-in. diaphragm	
Code	Flange Rating (High Side)	
1	Class 150	
2	Class 300	
4	Class 600	
G	PN 40	
E	PN 10/16; available with 4 in. DN 100 only	
Code	Isolator Material and Extension Material	Flange Material (High Side)
CA	316L SST	CS
DA	316L SST	316 SST
CB	Hastelloy	CS
DB	Hastelloy	316 SST
Code	Extension Length (High Side, 1st Position)	
2	2-in./50 mm	
4	4-in./100 mm	
6	6-in./150 mm	
Code	Extension Length (High Side, 2nd Position)	
0	0-in./0 mm	

Continue with transmitter options below

Transmitter Options continued from page A-32

(— = Not Applicable • = Applicable)

Code	Options
PlantWeb Control Functionality	
A01 ⁽¹⁾	FOUNDATION fieldbus Advanced Control Function Block Suite
PlantWeb Diagnostic Functionality	
D01 ⁽¹⁾	FOUNDATION fieldbus Diagnostics Suite
DA1 ⁽²⁾	HART Diagnostics Suite
PlantWeb Enhanced Measurement Functionality	
H01 ⁽¹⁾⁽³⁾	Fully Compensated Mass Flow Block
Code	Options
Special Configuration (Software)	
C1 ⁽⁴⁾	Custom software configuration <i>Note: A Configuration Data Sheet must be completed, see 00806-0100-4801.</i>
C3	Gage pressure calibration on Rosemount 3051S_LA only
C4 ⁽⁴⁾	NAMUR alarm and saturation levels, high alarm
C5 ⁽⁴⁾	NAMUR alarm and saturation levels, low alarm
C6 ⁽⁴⁾	Custom alarm and saturation signal levels, high alarm <i>Note: Requires option code C1, custom software configuration. A Configuration Data Sheet must be completed, see 00806-0100-4801.</i>
C7 ⁽⁴⁾	Custom alarm and saturation signal levels, low alarm <i>Note: Requires option code C1, custom software configuration. A Configuration Data Sheet must be completed, see 00806-0100-4801.</i>
C8 ⁽⁴⁾	Low alarm (standard Rosemount alarm and saturation levels)

Special Configuration (hardware)		LD	LG	LA
D1	Hardware adjustments (zero, span, alarm, security) <i>Note: Not available with fieldbus protocol or Housing Style codes 00, 01, 2E, 2F, 2G, 2M, 5A, or 7J.</i>	•	•	•
D2	1/2-14 NPT process connections process adapters	•	—	—
D4	External ground screw assembly	•	•	•
D5	Delete transmitter drain/vent valves (install plugs)	•	—	—
D8	Ceramic drain/vent valves	•	—	—
D9	RC 1/2 process connections (process adapters)	•	—	—
Product Certifications⁽⁹⁾				
E1	ATEX Flameproof			
I1	ATEX Intrinsically Safe			
IA	ATEX FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only			
N1	ATEX Type n			
K1	ATEX Flameproof, Intrinsically Safe, Type n, Dust (combination of E1, I1, N1, and ND)			
ND	ATEX Dust			
E4	JIS Flameproof			
E5	FM Explosion-proof			
I5	FM Intrinsically Safe, Non-Incendive			
IE	FM FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only			
K5	FM Explosion-proof, Intrinsically Safe, Non-Incendive (combination of E5 and I5)			
E6	CSA Explosion-proof, Division 2			
I6	CSA Intrinsically Safe			
IF	CSA FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only			
K6	CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E6 and I6)			
D3 ⁽⁶⁾⁽⁷⁾	Measurement Canada Accuracy Approval			
E7	SAA Flameproof, Dust Ignition-proof			
I7	IECEX Intrinsically Safe			
IG	IECEX FISCO Intrinsically Safe			
N7	IECEX Type n			
K7	SAA Flameproof, Dust Ignition-proof, IECEX Intrinsically Safe, and Type n (combination of E7, I7, and N7)			
KA	ATEX and CSA Flameproof, Intrinsically Safe (combination of E1, I1, E6, and I6) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>			
KB	FM and CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E5, E6, I5, and I6) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>			
KC	FM and ATEX Explosion-proof, Intrinsically Safe, Non-Incendive (combination of E5, E1, I5, and I1) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>			
KD	FM, CSA, and ATEX Explosion-proof, Intrinsically Safe (combination of E5, I5, E6, I6, E1, and I1) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>			
Alternate Materials of Construction				
L1	Inert sensor fill fluid (differential and gage only) <i>Note: Silicone fill fluid is standard.</i>			
L2	Graphite-filled TFE o-ring			
L4	Austenitic 316 SST bolts			
L5	ASTM A 193, Grade B7M bolts			
L6	Monel bolts			
L7	ASTM A 453, Class A, Grade 660 bolts			
L8	ASTM A 193, Class 2, Grade B8M bolts			
Digital Display⁽⁸⁾				
M5	PlantWeb LCD Display			
M7 ⁽⁹⁾	Remote mount LCD display and interface, no cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output <i>Note: Use Belden 3084A cable or equivalent. Contact an Emerson Process Management representative for additional information.</i>			
M8 ⁽⁹⁾	Remote mount LCD display and interface, 50 ft. (15 m) cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output			
M9 ⁽⁹⁾	Remote mount LCD display and interface, 100 ft. (31 m) cable; PlantWeb housing, SST bracket, requires 4-20 mA / HART output			
Special Procedures				
P1	Hydrostatic testing with certificate			
P2	Cleaning for special services			
P3	Cleaning for less than 1PPM chlorine/fluorine			
Special Certifications				
Q4	Calibration certificate			
QP	Calibration certificate and tamper evident seal			
Q8	Material traceability certification per EN 10204 3.1.B			
QS ⁽¹⁰⁾	Prior-use certificate of FMEDA Data			
QT ⁽¹¹⁾	Safety certified to IEC 61508 with certificate of FMEDA data			

Rosemount 3051S Series

Terminal blocks

T1 ⁽¹²⁾	Transient terminal block
T2 ⁽¹³⁾	Terminal block with WAGO® spring clamp terminals
T3 ⁽¹³⁾	Transient terminal block with WAGO spring clamp terminals

Conduit Electrical Connector

GE ⁽¹⁴⁾	M12, 4-pin, Male Connector (<i>eurofast</i> ®)
GM ⁽¹⁴⁾	A size Mini, 4-pin, Male Connector (<i>minifast</i> ®)

Typical Model Number for FF seal:	3051S2LD	2A	A	1A	1	0	2	0	D	FF	7	1	DA	0	0
Typical Model Number for EF seal:	3051S2LD	2A	A	1A	1	0	2	0	D	EF	7	1	DA	2	0

- (1) Requires PlantWeb housing and output code F.
- (2) Requires PlantWeb housing and output code A. Includes Hardware Adjustments as standard. Not available with option code QT.
- (3) Requires Rosemount Engineering Assistant to configure.
- (4) Not available with output code F or Housing code 01.
- (5) Valid when SuperModule Platform and housing have equivalent approvals.
- (6) Requires PlantWeb Housing and Hardware Adjustments option code D1.
- (7) Limited availability depending on transmitter type and range. Contact a sales representative for additional information.
- (8) Not available with Housing Code 01 or 7J.
- (9) Not available with output code F, Housing code 01, option code DA1, or option code QT.
- (10) Not available with Housing Code 01.
- (11) Not available with output code F. Not available with housing code 01 or 7J.
- (12) Not available with Housing code 00, 01, 5A, or 7J.
- (13) Available with output code A and PlantWeb housing only.
- (14) Not available with Housing code 00, 01, 5A, or 7J. Available with Intrinsically Safe approvals only. For FM Intrinsically Safe, Non-Incendive approval (option code I5) or FM FISCO Intrinsically Safe approval (option code IE), install in accordance with Rosemount drawing 03151-1009 to maintain outdoor rating (NEMA 4X and IP66).

Rosemount 300S Series Housing “Kit”

Model			
300S	Housing “Kit” for Rosemount 3051S Scalable Pressure Transmitter		
Code	Housing Style	Material ⁽¹⁾	Conduit Entry
1A	<i>PlantWeb</i> housing	Aluminum	1/2–14 NPT
1B	<i>PlantWeb</i> housing	Aluminum	M20 x 1.5 (CM20)
1C	<i>PlantWeb</i> housing	Aluminum	G ^{1/2}
1J	<i>PlantWeb</i> housing	316L SST	1/2–14 NPT
1K	<i>PlantWeb</i> housing	316L SST	M20 x 1.5 (CM20)
1L	<i>Plantweb</i> housing	316L SST	G ^{1/2}
2A	Junction Box housing	Aluminum	1/2–14 NPT
2B	Junction Box housing	Aluminum	M20 x 1.5 (CM20)
2C	Junction Box housing	Aluminum	G ^{1/2}
2J	Junction Box housing	316L SST	1/2–14 NPT
2E	Junction Box housing with output for remote interface	Aluminum	1/2–14 NPT
2F	Junction Box housing with output for remote interface	Aluminum	M20 x 1.5 (CM20)
2G	Junction Box housing with output for remote interface	Aluminum	G ^{1/2}
2M	Junction Box housing with output for remote interface	316L SST	1/2–14 NPT
3A	Remote mount display and interface housing	Aluminum	1/2–14 NPT
3B	Remote mount display and interface housing	Aluminum	M20 x 1.5 (CM20)
3C	Remote mount display and interface housing	Aluminum	G ^{1/2}
3J	Remote mount display and interface housing	316L SST	1/2–14 NPT
7J ⁽²⁾	Quick Connect (A size Mini, 4-pin male termination)	316L SST	
Code	Output		
A	4–20 mA with digital signal based on HART protocol		
F ⁽³⁾	FOUNDATION fieldbus protocol		
Code	Options		
<i>PlantWeb</i> Control Functionality			
A01 ⁽⁴⁾	FOUNDATION fieldbus Advanced Control Function Block Suite		
<i>PlantWeb</i> Diagnostic Functionality			
D01 ⁽⁴⁾	FOUNDATION fieldbus Diagnostics Suite		
DA1 ⁽⁵⁾	HART Diagnostics Suite		
<i>PlantWeb</i> Enhanced Measurement Functionality			
H01 ⁽⁴⁾⁽⁶⁾	Fully Compensated Mass Flow Block		
Special Configuration (Hardware)			
D1 ⁽⁷⁾	Hardware adjustments (zero, span, alarm, security) <i>Note: Not available with Housing Style codes 2E, 2F, 2G, 2M, 3A, 3B, 3C, 3J, or 7J.</i>		
D4	External ground screw assembly		
Product Certifications			
E1	ATEX Flameproof		
I1	ATEX Intrinsically Safe		
IA	ATEX FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only		
N1	ATEX Type n		
K1	ATEX Flameproof, Intrinsically Safe, Type n, Dust (combination of E1, I1, N1, and ND)		
ND	ATEX Dust		
E5	FM Explosion-proof		
I5	FM Intrinsically Safe, Non-Incendive		
IE	FM FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only		
K5	FM Explosion-proof, Intrinsically Safe, Non-Incendive (combination of E5 and I5)		
E6	CSA Explosion-proof, Division 2		
I6	CSA Intrinsically Safe		
IF	CSA FISCO Intrinsically Safe; for FOUNDATION fieldbus protocol only		
K6	CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E6 and I6)		
E7	SAA Flameproof, Dust Ignition-proof		
I7	IECEx Intrinsically Safe		
IG	IECEx FISCO Intrinsically Safe		
N7	IECEx Type n		
K7	SAA Flameproof, Dust Ignition-proof, IECEx Intrinsically Safe, and Type n (combination of E7, I7, and N7)		

Rosemount 3051S Series

KA	ATEX and CSA Flameproof, Intrinsically Safe (combination of E1, I1, E6, and I6) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>
KB	FM and CSA Explosion-proof, Intrinsically Safe, Division 2 (combination of E5, E6, I5, and I6) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>
KC	FM and ATEX Explosion-proof, Intrinsically Safe, Non-Incendive (combination of E5, E1, I5, and I1) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>
KD	FM, CSA, and ATEX Explosion-proof, Intrinsically Safe (combination of E5, I5, E6, I6, E1, and I1) <i>Note: Only available on Housing Style codes 00, IA, IJ, 2A, 2J, 2E, or 2M.</i>

Digital Display⁽⁸⁾

M5	<i>PlantWeb</i> LCD Display
M7 ⁽⁹⁾	Remote mount LCD display and interface, no cable; <i>PlantWeb</i> housing, SST bracket, requires 4-20 mA / HART output <i>Note: Use Belden 3084A cable or equivalent. Contact an Emerson Process Management representative for additional information.</i>
M8 ⁽⁹⁾	Remote mount LCD display and interface, 50 ft. (15 m) cable; SST bracket, requires 4-20 mA / HART output
M9 ⁽⁹⁾	Remote mount LCD display and interface, 100 ft. (31 m) cable; SST bracket, requires 4-20 mA / HART output

Terminal Blocks

T1 ⁽¹⁰⁾	Transient terminal block
T2 ⁽¹¹⁾	Terminal block with WAGO [®] spring clamp terminals
T3 ⁽¹¹⁾	Transient terminal block with WAGO spring clamp terminals

Conduit Electrical Connector


GE ⁽¹²⁾	M12, 4-pin, Male Connector (<i>euromast</i> [®])
GM ⁽¹²⁾	A size Mini, 4-pin, Male Connector (<i>minifast</i> [®])

Typical Model Number: 300S 1A A E5

- (1) Material specified is cast as follows: CF-3M is the cast version of 316L SST. For housing, material is aluminum with polyurethane paint.
- (2) Available with output code A only. Not available with approvals. Contact an Emerson Process Management representative for additional information.
- (3) Requires *PlantWeb* housing.
- (4) Requires *PlantWeb* housing and output code F.
- (5) Requires *PlantWeb* housing and output code A. Includes Hardware Adjustments as standard.
- (6) Requires Rosemount Engineering Assistant to configure.
- (7) Not available with output code F.
- (8) Not available with Housing code 7J.
- (9) Not available with output code F, or option code DA1. Only available on Housing Style codes 3A, 3B, 3C, or 3J.
- (10) Not available with Housing code 3A, 3B, 3C, 3J, or 7J.
- (11) Available with output code A and *PlantWeb* housing only.
- (12) Not available with Housing code 00, 01, or 7J. Available with Intrinsically Safe approvals only. For FM Intrinsically Safe, Non-Incendive approval (option code I5) or FM FISCO Intrinsically Safe approval (option code IE), install in accordance with Rosemount drawing 03151-1009 to maintain outdoor rating (NEMA 4X and IP66).

EXPLODED VIEW DIAGRAM

The following drawing shows the name and location for commonly ordered spare parts.



Rosemount 3051S Series

SPARE PARTS

See Rosemount 3051S_C, 3051S_T & 3051S_L ordering tables in Appendix A (A-25, A-29, and A-32 respectively) for ordering spare sensor modules.

- Typical Model Number 3051S1CD2A2000A00

Electronics Board Assembly Hardware (PlantWeb® Housing)

LCD/Housing Interface Assemblies for Hart Output

Standard Interface	03151-9010-0001
Hardware Adjustment Kit	03151-9015-0001
Adjustment Interface	
Adjustment Module	
Adjustment Interface	03151-9017-0001
Adjustment Module	03151-9019-0001
Remote Meter Interface	03151-9023-0001

Fieldbus Output (Includes A01 and D01 PlantWeb Functionality)

FOUNDATION™ Fieldbus Upgrade Kit (Standard)	03151-9021-0021
FOUNDATION Fieldbus Output Electronics	
Standard Dual Compartment Terminal Block	
FOUNDATION Fieldbus Upgrade Kit (with Transient Protection)	03151-9021-0022
FOUNDATION Fieldbus Output Electronics	
Transient Dual Compartment Terminal Block	
FOUNDATION Fieldbus Upgrade Kit (FISCO)	03151-9021-0023
FOUNDATION Fieldbus Output Electronics	
FISCO Dual Compartment Terminal Block	
FOUNDATION Fieldbus Output Electronics	03151-9020-0001

HART Advanced Diagnostics Electronics

HART Advanced Diagnostics Upgrade Kit	03151-9070-0001
---------------------------------------	-----------------

Miscellaneous

PlantWeb housing header cable o-ring (package of 12)	03151-9011-0001
--	-----------------

Electrical Housing, Terminal Blocks

See Rosemount 300S Series Housing "Kit" in Appendix A, page A-37 for ordering spare housings.

- Typical Model Number 300S1AAE5

PlantWeb Housing Terminal Block, HART (4-20 mA)

Standard Dual Compartment Terminal Block Assembly	03151-9005-0001
Transient Dual Compartment Terminal Block Assembly (Option T1)	03151-9005-0002

PlantWeb Housing Terminal Block, Fieldbus

Standard Dual Compartment Terminal Block Assembly	03151-9005-0021
Transient Dual Compartment Terminal Block Assembly (Option T1)	03151-9005-0022
FISCO Dual Compartment Terminal Block Assembly	03151-9005-0023

Junction Box Terminal Block, HART (4-20 mA)

Standard Junction Box Terminal Block Assembly	03151-9000-1001
Transient Junction Box Terminal Block Assembly (Option T1)	03151-9000-1002

Junction Box Terminal Block, HART (4-20 mA) with Adjustment

Standard Junction Box Terminal Block Assembly, Switch	03151-9000-2001
Transient Junction Box Terminal Block Assembly, Switch (Option T1)	03151-9000-2002
Alarm/Security Jumper with O-ring	03151-9001-0001

Remote Meter Terminal Blocks

PlantWeb Housing 7-Position Remote Communications Terminal Block Assembly	03151-9006-0101
Junction Box Remote Communications Standard Terminal Block Assembly	03151-9000-1010

Junction Box Remote Communications Transient Terminal Block Assembly	03151-9000-1011
Covers	
Aluminum Electronics Cover; Cover and O-ring	03151-9030-0001
316L SST Electronics Cover; Cover and O-ring	03151-9030-0002
Housing Miscellaneous	
External Ground Screw Assembly (Option D4): Screw, clamp, washer	03151-9060-0001
Housing V-Seal for both PlantWeb and Junction Box housings	03151-9061-0001
Flanges	Part Number
Differential Coplanar Flange	
Nickel-plated Carbon Steel	03151-9200-0025
316 SST	03151-9200-0022
Hastelloy C	03151-9200-0023
Monel	03151-9200-0024
Gage/Absolute Coplanar Flange	
Nickel-plated Carbon Steel	03151-9200-1025
316 SST	03151-9200-1022
Hastelloy C	03151-9200-1023
Monel	03151-9200-1024
Coplanar Flange Alignment Screw (package of 12)	03151-9202-0001
Traditional Flange	
316 SST	03151-9203-0002
Hastelloy C	03151-9203-0003
Monel	03151-9203-0004
Level Flange, Vertical Mount	
2 in., Class 150, SST	03151-9205-0221
2 in., Class 300, SST	03151-9205-0222
3 in., Class 150, SST	03151-9205-0231
3 in., Class 300, SST	03151-9205-0232
DIN, DN 50, PN 40	03151-9205-1002
DIN, DN 80, PN 40	03151-9205-1012
Flange Adapter Kits (Each kit contains adapters, bolts, and o-ring for one DP transmitter or two GP/AP transmitters.)	
Differential Flange Adapter Kits	
CS Bolts, Glass Filled Teflon O-Rings	
SST Adapters	03031-1300-0002
Hastelloy Adapters	03031-1300-0003
Monel Adapters	03031-1300-0004
Ni Plated CS Adapters	03031-1300-0005
SST Bolts, Glass Filled Teflon O-Rings	
SST Adapters	03031-1300-0012
Hastelloy Adapters	03031-1300-0013
Monel Adapters	03031-1300-0014
Ni Plated CS Adapters	03031-1300-0015
CS Bolts, Graphite TFE O-Rings	
SST Adapters	03031-1300-0102
Hastelloy Adapters	03031-1300-0103
Monel Adapters	03031-1300-0104
Ni Plated CS Adapters	03031-1300-0105

SST Bolts, Graphite TFE O-Rings	
SST Adapters	03031-1300-0112
Hastelloy Adapters	03031-1300-0113
Monel Adapters	03031-1300-0114
Ni Plated CS Adapters	03031-1300-0115
Flange Adapter Union	
	Part Number
Nickel-plated Carbon Steel	03151-9259-0005
316 SST	03151-9259-0002
Hastelloy C	03151-9259-0003
Monel	03151-9259-0004
Drain/Vent Valve Kits	
(each kit contains parts for one transmitter)	
	Part Number
Differential Drain/Vent Kits	
316 SST Valve Stem and Seat Kit	03151-9268-0022
Hastelloy C Valve Stem and Seat Kit	03151-9268-0023
Monel Valve Stem and Seat Kit	03151-9268-0024
316 SST Ceramic Ball Drain/Vent Kit	03151-9258-0122
Hastelloy C Ceramic Ball Drain/Vent Kit	03151-9268-0123
Monel Ceramic Ball Drain/Vent Kit	03151-9268-0124
Gage/Absolute Drain/Vent Kits	
316 SST Valve Stem and Seat Kit	03151-9268-0012
Hastelloy C Valve Stem and Seat Kit	03151-9268-0013
Monel Valve Stem and Seat Kit	03151-9268-0014
316 SST Ceramic Ball Drain/Vent Kit	03151-9268-0112
Hastelloy C Ceramic Ball Drain/Vent Kit	03151-9268-0113
Monel Ceramic Ball Drain/Vent Kit	03151-9268-0114
O-Ring Packages (package of 12)	
Electronic Housing, Cover (Standard and Meter)	03151-9040-0001
Electronics Housing, Module	03151-9041-0001
Process Flange, Glass-filled Teflon®	03151-9042-0001
Process Flange, Graphite-filled Teflon	03151-9042-0002
Flange Adapter, Glass-filled Teflon	03151-9043-0001
Flange Adapter, Graphite-filled Teflon	03151-9043-0002
Gland and Collar Kits	
Gland and Collar Kits	03151-9250-0001
Mounting Brackets	
Coplanar Flange Bracket Kit	
B4 Bracket, SST, 2-in. pipe mount, SST bolts	03151-9270-0001
In-line Bracket Kit	
B4 Bracket, SST, 2-in. pipe mount, SST bolts	03151-9270-0002
Traditional Flange Bracket Kits	
B1 Bracket, 2-in. pipe mount, CS bolts	03151-9272-0001
B2 Bracket, panel mount, CS bolts	03151-9272-0002
B3 Flat Bracket for 2-in. pipe mount, CS bolts	03151-9272-0003
B7 (B1 style bracket with SST bolts)	03151-9272-0007
B8 (B2 style bracket with SST bolts)	03151-9272-0008
B9 (B3 style bracket with SST bolts)	03151-9272-0009
BA (SST B1 bracket with SST bolts)	03151-9272-0011
BC (SST B3 bracket with SST bolts)	03151-9272-0013

Bolt Kits	
COPLANAR FLANGE	
Flange Bolt Kit {44 mm (1.75 in.)}	
Carbon Steel (set of 4)	03151-9280-0001
316 SST (set of 4)	03151-9280-0002
ANSI/ASTM-A-193-B7M (set of 4)	03151-9280-0003
Monel (set of 4)	03151-9280-0004
Flange/Adapter Bolt Kit {73 mm (2.88 in.)}	
Carbon Steel (set of 4)	03151-9281-0001
316 SST (set of 4)	03151-9281-0002
ANSI/ASTM-A-193-B7M (set of 4)	03151-9281-0003
Monel (set of 4)	03151-9281-0004
Manifold/Flange Kit {57 mm (2.25 in.)}	
Carbon Steel (set of 4)	03151-9282-0001
316 SST (set of 4)	03151-9282-0002
ANSI/ASTM-A-193-B7M (set of 4)	03151-9282-0003
Monel (set of 4)	03151-9282-0004
TRADITIONAL FLANGE	
Differential Flange and Adapter Bolt Kit	
Carbon Steel (set of 8)	03151-9283-0001
316 SST (set of 8)	03151-9283-0002
ANSI/ASTM-A-193-B7M (set of 8)	03151-9283-0003
Monel (set of 8)	03151-9283-0004
Gage/Absolute Flange and Adapter Bolt Kit	
Carbon Steel (set of 6)	03151-9283-1001
316 SST (set of 6)	03151-9283-1002
ANSI/ASTM-A-193-B7M (set of 6)	03151-9283-1003
Monel (set of 6)	03151-9283-1004
Manifold/Traditional Flange Bolts	
Carbon Steel	Use bolts supplied with manifold
316 SST	Use bolts supplied with manifold
LEVEL FLANGE, VERTICAL MOUNT	
Flange Bolt Kit (Each kit contains bolts for one transmitter)	
Carbon Steel (set of 4)	03151-9285-0001
316 SST (set of 4)	03151-9285-0002
Meters	Part Number
Indicating Meter for Plantweb Aluminum Housing	
Meter Kit: LCD assembly, 4-pin interconnection header and aluminum meter cover assembly	03151-9193-0001
Meter Only: LCD assembly, 4-pin interconnection header	03151-9193-0002
Cover Assembly Kit: aluminum meter cover assembly	03151-9193-0003
Indicating Meter for Plantweb 316L SST Housing	
Meter Kit: LCD assembly, 4-pin interconnection header, 316L SST meter cover assembly	03151-9193-0004
Meter Only: LCD assembly, 4-pin interconnection header	03151-9193-0002
Cover Assembly Kit: 316L SST meter cover assembly	03151-9193-0005

Rosemount 3051S Series

Reference Manual
00809-0100-4801, Rev CB
January 2007

Appendix B Product Certifications

Approved Manufacturing Locations	page B-1
European Directive Information	page B-1
Ordinary Location Certification for FM	page B-1
Hazardous Locations Certifications	page B-1
Installation Drawings	page B-6
European ATEX Directive Information	page B-39

This section contains hazardous location certifications for 3051S HART protocol.

Approved Manufacturing Locations

Rosemount Inc. — Chanhassen, Minnesota USA
Emerson Process Management GmbH & Co. — Wessling, Germany
Emerson Process Management Asia Pacific Private Limited — Singapore
Beijing Rosemount Far East Instrument Co., LTD — Beijing, China

European Directive Information

The EC declaration of conformity for all applicable European directives for this product can be found at www.rosemount.com. A hard copy may be obtained by contacting an Emerson Process Management representative.

ATEX Directive (94/9/EC)

Emerson Process Management complies with the ATEX Directive.

European Pressure Equipment Directive (PED) (97/23/EC)

Models 3051S_CA4; 3051S_CD2, 3, 4, 5; (also with P9 option) Pressure Transmitters — QS Certificate of Assessment -

EC No. PED-H-20, Module H Conformity Assessment

All other Model 3051S Pressure Transmitters
— Sound Engineering Practice

Transmitter Attachments: Diaphragm Seal - Process Flange - Manifold — Sound Engineering Practice

Primary Elements, Flowmeter

— See appropriate Primary Element QIG

Electro Magnetic Compatibility (EMC) (89/336/EEC)

All Models: EN 50081-1: 1992; EN 50082-2:1995;
EN 61326-1:1997 + A1, A2, and A3 – Industrial

Ordinary Location Certification for FM

As standard, the transmitter has been examined and tested to determine that the design meets basic electrical, mechanical, and fire protection requirements by FM, a nationally recognized testing laboratory (NRTL) as accredited by the Federal Occupational Safety and Health Administration (OSHA).

Hazardous Locations Certifications

North American Certifications

FM Approvals

E5 Explosion-proof for Class I, Division 1, Groups B, C, and D; dust-ignition proof for Class II and Class III, Division 1, Groups E, F, and G; hazardous locations; enclosure Type 4X, conduit seal not required when installed according to Rosemount drawing 03151-1003.

I5/IE Intrinsically Safe for use in Class I, Division 1, Groups A, B, C, and D; Class II, Division 1, Groups E, F, and G; Class III, Division 1; Class I, Zone 0 AEx ia IIC when connected in accordance with Rosemount drawing 03151-1006; Non-incendive for Class I, Division 2, Groups A, B, C, and D Enclosure Type 4X

For entity parameters see control drawing 03151-1006.

Canadian Standards Association (CSA)

- E6** Explosion-proof for Class I, Division 1, Groups B, C, and D; Dust-Ignition-Proof for Class II and Class III, Division 1, Groups E, F, and G; suitable for Class I, Division 2, Groups A, B, C, and D, when installed per Rosemount drawing 03151-1013, CSA Enclosure Type 4X; conduit seal not required.
- I6/IF** Intrinsically Safe for Class I, Division 1, Groups A, B, C, and D when connected in accordance with Rosemount drawings 03151-1016;
For entity parameters see control drawing 03151-1016.

European Certifications

I1/IA ATEX Intrinsic Safety


Certificate No.: BAS01ATEX1303X  II 1G
 EEx ia IIC T5 (T_a = -60 °C to 40 °C) -HART/Remote Display/Quick Connect/
 HART Diagnostics
 EEx ia IIC T4 (T_a = -60 °C to 70 °C) -HART/Remote Display/Quick Connect/
 HART Diagnostics
 EEx ia IIC T4 (T_a = -60 °C to 70 °C) -FOUNDATION fieldbus
 EEx ia IIC T4 (T_a = -60 °C to 40 °C) -FISCO
CE 1180


TABLE 1. Input Parameters

Loop / Power	Groups
U _i = 30 V	HART / FOUNDATION fieldbus/ Remote Display / Quick Connect / HART Diagnostics
U _i = 17.5 V	FISCO
I _i = 300 mA	HART / FOUNDATION fieldbus/ Remote Display / Quick Connect / HART Diagnostics
I _i = 380 mA	FISCO
P _i = 1.0 W	HART / Remote Display / Quick Connect / HART Diagnostics
P _i = 1.3 W	FOUNDATION fieldbus
P _i = 5.32 W	FISCO
C _i = 30 nF	<i>SuperModule</i> [™] Platform / Quick Connect
C _i = 11.4 nF	HART / HART Diagnostics
C _i = 0	FOUNDATION fieldbus / Remote Display / FISCO
L _i = 0	HART / FOUNDATION fieldbus/ FISCO / Quick Connect / HART Diagnostics
L _i = 60 μH	Remote Display

Special conditions for safe use (x)

- The apparatus, excluding the Types 3051 S-T and 3051 S-C (In-line and *Coplanar SuperModule* Platforms respectively), is not capable of withstanding the 500V test as defined in Clause 6.4.12 of EN 50020. This must be considered during installation.
- The terminal pins of the Types 3051 S-T and 3051 S-C must be protected to IP20 minimum.


N1 ATEX Type n

Certificate No.: BAS01ATEX3304X  II 3 G
 EEx nL IIC T5 (T_a = -40 °C TO 70 °C)
 U_i = 45 Vdc max
 IP66
CE

Special conditions for safe use (x)


The apparatus is not capable of withstanding the 500V insulation test required by Clause 9.1 of EN 50021: 1999. This must be taken into account when installing the apparatus.

ND ATEX Dust

Certificate No.: BAS01ATEX1374X  II 1 D
 T105°C (-20 °C ≤ T_{amb} ≤ 85 °C)
 V_{max} = 42.4 volts max
 A = 24 mA
 IP66
CE 1180

Special conditions for safe use (x)

1. The user must ensure that the maximum rated voltage and current (42.4 volts, 22 milliampere, DC) are not exceeded. All connections to other apparatus or associated apparatus shall have control over this voltage and current equivalent to a category “ib” circuit according to EN 50020.
2. Cable entries must be used which maintain the ingress protection of the enclosure to at least IP66.
3. Unused cable entries must be filled with suitable blanking plugs which maintain the ingress protection of the enclosure to at least IP66.
4. Cable entries and blanking plugs must be suitable for the ambient range of the apparatus and capable of withstanding a 7J impact test.
5. The 3051S must be securely screwed in place to maintain the ingress protection of the enclosure. (The 3051S SuperModule must be properly assembled to the 3051S housing to maintain ingress protection.)

E1 ATEX Flameproof
Certificate No.: KEMA00ATEX2143X  II 1/2 G
EEx d IIC T6 (-50 °C ≤ T_{amb} ≤ 65 °C)
EEx d IIC T5 (-50 °C ≤ T_{amb} ≤ 80 °C)
V_{max} = 42.4V
CE 1180

Special conditions for safe use (x)

This device contains a thin wall diaphragm. Installation, maintenance and use shall take into account the environmental conditions to which the diaphragm will be subjected. The manufacturer's instructions for installation and maintenance shall be followed in detail to assure safety during its expected lifetime. The Model 3051S pressure transmitter must include a 300S housing integrally mounted to a 3051S Sensor module as per Rosemount drawing 03151-1023.

Japanese Certifications

E4 JIS Flameproof
Ex d IIC T6

Certificate	Description
TC15682	Coplanar with Junction Box Housing
TC15683	Coplanar with <i>PlantWeb</i> Housing
TC15684	Coplanar with <i>PlantWeb</i> Housing and LCD Display
TC15685	In-Line SST with Junction Box Housing
TC15686	In-Line <i>Hastelloy</i> with Junction Box Housing
TC15687	In-Line SST with <i>PlantWeb</i> Housing
TC15688	In-Line <i>Hastelloy</i> with <i>Plantweb</i> Housing
TC15689	In-Line SST with <i>Plantweb</i> Housing and LCD Display
TC15690	In-Line <i>Hastelloy</i> with <i>PlantWeb</i> Housing and LCD Display
TC17102	Remote Display

Australian Certifications

E7 SAA Explosion-proof and Dust Ignition-proof
Certification No.: AUS Ex 3798X
Ex d IIC T6 ($T_a = 60^\circ\text{C}$) IP66
DIP A21 TA T6 ($T_a = 60^\circ\text{C}$) IP66

Special conditions for safe use (x)

1. It is a condition of manufacture that each transmitter module shall be pressure tested in accordance with clause 4.3 of AS 2380.2 at minimum pressure of 1450 kPa. As the model 300S housing passed tests at 4 times the reference pressures (400 kPa for single and 3800 kPa for dual compartment housing) and are not of welded construction, they may be exempted from the routing pressure test of clause 4.3 of AS 2380.2.
2. It is a condition of manufacture that each transmitter module and housing combination shall be subjected to a routine high voltage test in accordance with clause 6.2 of AS 2380.1, with the following variation. The test voltage applied to each single or dual compartment housing shall not be less than 500 V, 47 to 62 Hz, for a period of not less than one minute, with a breakdown current of less than 5 mA.
3. It is a condition of safe use that each housing shall be connected to external circuits via suitable conduit or Standards Australia certified cable glands. Where only one entry is used for connection to external circuits, the unused entry shall be closed by means of the blanking plug supplied by the equipment manufacturer or by a suitable Standards Australia certified blanking plug.
4. It is a condition of safe use that a dielectric strength test shall be applied whenever the terminal block is changed or replaced in either the dual compartment or single compartment housings. The breakdown current shall be less than 5 mA, when 500 V, 47 to 62 Hz, is applied for one minute. **Note:** if tested with an optional T1 transient protector terminal block fitted, the protection will operate and hence there will be no current indicated.
5. It is a condition of safe use that each transmitter module shall be used with a Model 300S housing, in order to comply with flameproof requirements.
6. It is a condition of safe use that each model 300S housing fitted with a transmitter module shall be marked with the same certification marking code information. Should the housing be replaced after initial supply to another model 300S housing, the replacement housing shall have the same certification marking code information as the housing it replaces.

IECEX Certifications

I7/IG IECEX Intrinsic Safety

Certificate No.: IECEXBAS04.0017X
 Ex ia IIC T5 ($T_a = -60\text{ }^\circ\text{C}$ to $40\text{ }^\circ\text{C}$) -HART/Remote Display/Quick Connect/
 HART Diagnostics
 Ex ia IIC T4 ($T_a = -60\text{ }^\circ\text{C}$ to $70\text{ }^\circ\text{C}$) -HART/Remote Display/Quick Connect/
 HART Diagnostics
 Ex ia IIC T4 ($T_a = -60\text{ }^\circ\text{C}$ to $70\text{ }^\circ\text{C}$) -FOUNDATION fieldbus
 Ex ia IIC T4 ($T_a = -60\text{ }^\circ\text{C}$ to $40\text{ }^\circ\text{C}$) -FISCO
 IP66

TABLE 2. Input Parameters

Loop / Power	Groups
$U_i = 30\text{ V}$	HART / FOUNDATION fieldbus/ Remote Display / Quick Connect / HART Diagnostics
$U_i = 17.5\text{ V}$	FISCO
$I_i = 300\text{ mA}$	HART / FOUNDATION fieldbus/ Remote Display / Quick Connect / HART Diagnostics
$I_i = 380\text{ mA}$	FISCO
$P_i = 1.0\text{ W}$	HART / Remote Display / Quick Connect / HART Diagnostics
$P_i = 1.3\text{ W}$	FOUNDATION fieldbus
$P_i = 5.32\text{ W}$	FISCO
$C_i = 30\text{ nF}$	SuperModule™ Platform / Quick Connect
$C_i = 11.4\text{ nF}$	HART / HART Diagnostics
$C_i = 0$	FOUNDATION fieldbus / Remote Display / FISCO / Quick Connect / HART Diagnostics
$L_i = 0$	HART / FOUNDATION fieldbus/ FISCO / Quick Connect / HART Diagnostics
$L_i = 60\text{ }\mu\text{ H}$	Remote Display

Special conditions for safe use (x)

- 1.The Models 3051S HART 4-20mA, 3051S fieldbus, 3051S Profibus and 3051S FISCO are not capable of withstanding the 500V test as defined in clause 6.4.12 of IEC 60079-11. This must be taken into account during installation.
- 2.The terminal pins of the Types 3051S-T and 3051S-C must be protected to IP20 minimum.

N7 IECEX Type n

Certificate No.: IECEXBAS04.0018X
 Ex nC IIC T5 ($T_a = -40\text{ }^\circ\text{C}$ to $70\text{ }^\circ\text{C}$)
 $U_i = 45\text{ Vdc MAX}$
 IP66

Special conditions for safe use (x)

The apparatus is not capable of withstanding the 500 V insulation test required by Clause 8 of IEC 79-15: 1987.

Combinations of Certifications

Stainless steel certification tag is provided when optional approval is specified. Once a device labeled with multiple approval types is installed, it should not be reinstalled using any other approval types. Permanently mark the approval label to distinguish it from unused approval types.

- K1** Combination of E1, I1, N1, and ND
- K5** Combination of E5 and I5
- K6** Combination of E6 and I6
- K7** Combination of E7, I7, and N7
- KA** Combination of E1, I1, E6, and I6
- KB** Combination of E5, I5, I6 and E6
- KC** Combination of E5, E1, I5 and I1
- KD** Combination of E5, I5, E6, I6, E1, and I1

Rosemount 3051S Series

INSTALLATION DRAWINGS

Factory Mutual (FM)

REVISIONS					
ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
	AA	NEW RELEASE	RTC1009618	P.C.S.	9/11/00
	AB	ADD 3051S_L AND TRADITIONAL HOUSING	RTC1015145	B.L.H.	4/7/03

NOTES:

1. WIRING METHOD SUITABLE FOR CLASS I, DIV 1 or CLASS I, ZONE 1 WITH ANY LENGTH.
2. TRANSMITTER MUST NOT BE CONNECTED TO EQUIPMENT GENERATING MORE THAN 250 VAC.
3. ALL CONDUIT THREADS TO BE ASSEMBLED WITH FIVE FULL THREADS MINIMUM.
4. COMPONENTS REQUIRED TO BE APPROVED MUST BE APPROVED FOR GAS GROUP APPROPRIATE TO AREA CLASSIFICATION.
5. 3051SC, 3051ST OR 3051SL SENSOR MODULE MUST BE INSTALLED WITH FM FLAMEPROOF / EXPLOSIONPROOF APPROVED 300S1, 300S2 OR 300S4 HOUSING ATTACHED TO MEET FLAMEPROOF / EXPLOSIONPROOF INSTALLATION REQUIREMENTS.
6. INSTALLATION TO BE IN ACCORDANCE WITH THE LATEST EDITION OF NATIONAL ELECTRICAL CODE (NFPA 70).
7. 300S1, 300S2 OR 300S4 HOUSING MUST BE INSTALLED WITH FM FLAMEPROOF / EXPLOSIONPROOF APPROVED 3051SC, 3051ST OR 3051SL SENSOR MODULE ATTACHED TO MEET FLAMEPROOF / EXPLOSIONPROOF INSTALLATION REQUIREMENTS.
8. UNUSED CONDUIT ENTRY MUST BE CLOSED WITH SUITABLE BLANKING ELEMENT.

CAD Maintained, (Pro/E)


UNLESS OTHERWISE SPECIFIED DIMENSIONS IN INCHES [mm]. REMOVE ALL BURRS AND SHARP EDGES. MACHINE SURFACE FINISH 125 -TOLERANCES- .X ± .1 [2,5] .XX ± .02 [0,5] .XXX ± .010 [0,25] FRACTIONS ANGLES ± 1/32 ± 2	CONTRACT NO.		ROSEMOUNT® 8200 Market Boulevard • Chanhassen, MN 55317 USA		
	DR. <i>Myles Lee Miller</i>	8/28/00	TITLE MODEL 3051 / 300 EXPLOSIONPROOF / FLAMEPROOF INSTALLATION DRAWING, FM		
	CHK'D	.			
	APP'D <i>Paul C. Sundet</i>	9/11/00	SIZE A	FSCM NO.	DRAWING NO. 03151-1003
APP'D GOVT.	SCALE : 4	WT.	SHEET OF 3		

REVISIONS					
ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
	AB				

COMPONENT IDENTIFICATION


300S1____, PLANTWEB
 300S4____, TRADITIONAL
 (DUAL COMPARTMENT HOUSING)

300S2____
 JUNCTION BOX HOUSING
 (SINGLE COMPARTMENT)



3051S_C____
 3051S_L____
 SCALABLE COPLANAR
 PRESSURE TRANSMITTER


3051S_T____
 SCALABLE IN-LINE
 PRESSURE TRANSMITTER



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA			CAD Maintained, (Pro/E)		
DR. <i>Myles Lee Miller</i>	8/28/00	SIZE A	FSCM NO	DWG NO.	03151-1003
ISSUED		SCALE 1:2	WT.	SHEET 2	OF 3

REVISIONS					
ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
	AB				

HOUSING TO MODULE ASSEMBLY



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD Maintained, (Pro/E)			
DR. <i>Myles Lee Miller</i>	8/28/00	SIZE A	FSCM NO.	DWG NO.	03151-1003
ISSUED		SCALE	1 : 4	WT.	SHEET 3 OF 3

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				

ENTITY CONCEPT APPROVALS

THE ENTITY CONCEPT ALLOWS INTERCONNECTION OF INTRINSICALLY SAFE APPARATUS TO ASSOCIATED APPARATUS NOT SPECIFICALLY EXAMINED IN COMBINATION AS A SYSTEM. THE APPROVED VALUES OF MAX. OPEN CIRCUIT VOLTAGE (V_{oc} , U_o OR V_t) AND MAX. SHORT CIRCUIT CURRENT (I_{sc} , I_o , OR I_t) AND MAX. POWER $P_o(V_{oc} \times I_{sc}/4)$ OR $(V_t \times I_t/4)$, FOR THE ASSOCIATED APPARATUS MUST BE LESS THAN OR EQUAL TO THE MAXIMUM SAFE INPUT VOLTAGE (V_{max} , OR U_i), MAXIMUM SAFE INPUT CURRENT (I_{max} OR I_i), AND MAXIMUM SAFE INPUT POWER (P_{max} OR P_i) OF THE INTRINSICALLY SAFE APPARATUS. IN ADDITION, THE APPROVED MAX. ALLOWABLE CONNECTED CAPACITANCE (C_a) OF THE ASSOCIATED APPARATUS MUST BE GREATER THAN THE SUM OF THE INTERCONNECTING CABLE CAPACITANCE AND THE UNPROTECTED INTERNAL CAPACITANCE (C_i) OF THE INTRINSICALLY SAFE APPARATUS, AND THE APPROVED MAX. ALLOWABLE CONNECTED INDUCTANCE (L_a) OF THE ASSOCIATED APPARATUS MUST BE GREATER THAN THE SUM OF THE INTERCONNECTING CABLE INDUCTANCE AND THE UNPROTECTED INTERNAL INDUCTANCE (L_i) OF THE INTRINSICALLY SAFE APPARATUS.

NOTE: ENTITY PARAMETERS LISTED APPLY ONLY TO ASSOCIATED APPARATUS WITH LINEAR OUTPUT.

FOR OUTPUT CODE 'A' MODEL 3051S SUPERMODULE CLASS I, DIV. 1, GROUPS A, B, C AND D

U_i or $V_{MAX} = 30V$	U_o, V_T or V_{OC} IS LESS THAN OR EQUAL TO 30V
I_i or $I_{MAX} = 300mA$	I_o, I_T or I_{SC} IS LESS THAN OR EQUAL TO 300mA
P_i or $P_{MAX} = 1.0$ WATT	$(\frac{V_T \times I_T}{4})$ or $(\frac{V_{oc} \times I_{sc}}{4})$ IS LESS THAN OR EQUAL TO 1.0 WATT
$C_i = 38nF$	C_A IS GREATER THAN 38nF
$L_i = \emptyset$	L_A IS GREATER THAN \emptyset H
T4 ($T_a = -50^\circ C$ to $+70^\circ C$)	T5 ($T_a = -50^\circ C$ to $+40^\circ C$)

FOR OUTPUT CODE 'A' MODEL 300S JUNCTION BOX, 300S PLANTWEB HOUSING, OR 3051S QUICK CONNECT CLASS I, DIV. 1, GROUPS A, B, C AND D

U_i or $V_{MAX} = 30V$	U_o, V_T or V_{OC} IS LESS THAN OR EQUAL TO 30V
I_i or $I_{MAX} = 300mA$	I_o, I_T or I_{SC} IS LESS THAN OR EQUAL TO 300mA
P_i or $P_{MAX} = 1.0$ WATT	$(\frac{V_T \times I_T}{4})$ or $(\frac{V_{oc} \times I_{os}}{4})$ IS LESS THAN OR EQUAL TO 1.0 WATT
$C_i = 11.4nF$	C_A IS GREATER THAN 11.4nF
$L_i = 2.4 \mu H$	L_A IS GREATER THAN 2.4 μH
T4 ($T_a = -50^\circ C$ to $+70^\circ C$)	
T5 ($T_a = -50^\circ C$ to $+40^\circ C$)	

FOR OUTPUT CODE 'A' WITH HART DIAGNOSTICS SUITE AND MODEL 300S PLANTWEB HOUSING CLASS I, DIV. 1, GROUPS A, B, C AND D

U_i or $V_{MAX} = 30V$	U_o, V_T or V_{OC} IS LESS THAN OR EQUAL TO 30V
I_i or $I_{MAX} = 240mA$	I_o, I_T or I_{SC} IS LESS THAN OR EQUAL TO 240mA
P_i or $P_{MAX} = 1.0$ WATT	$(\frac{V_T \times I_T}{4})$ or $(\frac{V_{oc} \times I_{os}}{4})$ IS LESS THAN OR EQUAL TO 1.0 WATT
$C_i = 11.4nF$	C_A IS GREATER THAN 11.4nF
$L_i = \emptyset$	L_A IS GREATER THAN \emptyset
T4 ($T_a = -50^\circ C$ to $+70^\circ C$)	
T5 ($T_a = -50^\circ C$ to $+40^\circ C$)	

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA	CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO. 03151-1006
ISSUED	SCALE N/A	WT. _____	SHEET 2 OF 11

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				


FOR OUTPUT CODE 'B' (SAFETY CERTIFIED) MODEL 300S CLASS 1, DIV. 1, GROUPS A, B, C AND D

U_1 or $V_{MAX} = 30V$	U_o, V_T or V_{OC} IS LESS THAN OR EQUAL TO 30V
I_1 or $I_{MAX} = 240mA$	I_o, I_T or I_{SC} IS LESS THAN OR EQUAL TO 240mA
P_1 or $P_{MAX} = 1.0$ WATT	$(\frac{V_T \times I_T}{4})$ or $(\frac{V_{oc} \times I_{os}}{4})$ IS LESS THAN OR EQUAL TO 1.0 WATT
$C_1 = 11.4nF$	C_A IS GREATER THAN 11.4nF
$L_1 = 570\mu H$	L_A IS GREATER THAN 570 μH
T4 ($T_a = -50^\circ C$ to $+70^\circ C$)	
T5 ($T_a = -50^\circ C$ to $+40^\circ C$)	

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO.	03151-1006
ISSUED	SCALE N/A	WT.	SHEET 3 OF	11


REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				

CIRCUIT DIAGRAM 1
ONE BARRIER OR CONVERTER:
SINGLE OR DUAL CHANNEL



OUTPUT CODE A & B
MODELS INCLUDED
3051S WITH 300S
JUNCTION BOX or
PLANTWEB HOUSING




CIRCUIT DIAGRAM 2
SUPPLY AND RETURN BARRIERS
(ONLY FOR USE WITH BARRIERS APPROVED IN THIS CONFIGURATION)



OUTPUT CODE A & B
MODELS INCLUDED
3051S WITH 300S
JUNCTION BOX or
PLANTWEB HOUSING

Rosemount Inc. 8200 Market Boulevard Chanhasen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO.	03151-1006
ISSUED	SCALE N/A	WT.	SHEET	4 OF 11

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO. 03151-1006	
ISSUED	SCALE N/A	WT.	SHEET 5 OF 11	


Rosemount 3051S Series

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				

OUTPUT CODE A WITH M8 or M9 OPTION
CLASS I, DIV. 1, GROUPS A, B, C AND D

U_1 or V_{MAX} = 30V
I_1 or I_{MAX} = 300mA
P_1 or P_{MAX} = 1.0 WATT
C_1 = 0
L_1 = 58.2 μ H
T4 (T_a = -50°C to +70°C)
T5 (T_a = -50°C to +40°C)

MAXIMUM CABLE PARAMETERS
CAPACITANCE - 50 pf / Ft
INDUCTANCE - 0.251 μ H / Ft
LENGTH - 100 Ft
RECOMMENDED CABLE - BELDEN 3084A DEVICE NET OR BELDEN 123084A ARMORED DEVICE NET



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)	
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO. 03151-1006
ISSUED	SCALE N/A	WT.	SHEET 6 OF 11


REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				

FOR OUTPUT CODE F or W (MODEL 300S)

CLASS I, DIV. 1, GROUPS A, B, C AND D

U_1 OR $V_{MAX} = 30V$	$U_o, V_T, \text{ OR } V_{OC}$ IS LESS THAN OR EQUAL TO 30V
I_1 OR $I_{MAX} = 300mA$	$I_o, I_T, \text{ OR } I_{SC}$ IS LESS THAN OR EQUAL TO 300mA
P_1 OR $P_{MAX} = 1.3 \text{ WATT}$	$P_1 (\frac{V_T \times I_T}{4})$ OR $(\frac{V_{oc} \times I_{sc}}{4})$ IS LESS THAN OR EQUAL TO 1.3 WATT
$C_1 = 0\mu f$	C_A IS GREATER THAN $0\mu f$
$L_1 = 0\mu H$	L_A IS GREATER THAN $0\mu H$
T4 ($T_a = -50^\circ C$ TO $+60^\circ C$)	

CIRCUIT DIAGRAM 1
 ONE BARRIER OR CONVERTER:
 SINGLE OR DUAL CHANNEL



OUTPUT CODE F or W
 MODELS INCLUDED
 3051S WITH 300S
 PLANTWEB HOUSING

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO.	DWG NO. 03151-1006	
ISSUED	SCALE N/A	WT.	SHEET 7 OF 11	

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				

FISCO CONCEPT

THE FISCO CONCEPT ALLOWS INTERCONNECTION OF INTRINSICALLY SAFE APPARATUS TO ASSOCIATED APPARATUS NOT SPECIALLY EXAMINED IN SUCH COMBINATION. THE CRITERIA FOR INTERCONNECTION IS THAT THE VOLTAGE (U_1 OR V_{max}), THE CURRENT (I_1 OR I_{max}), AND THE POWER (P_1 OR P_{max}) WHICH AN INTRINSICALLY SAFE APPARATUS CAN RECEIVE AND REMAIN INTRINSICALLY SAFE CONSIDERING FAULTS, MUST BE EQUAL OR GREATER THAN VOLTAGE (U_0 , V_{oc} , OR V_t), THE CURRENT (I_0 , I_{sc} , OR I_t) AND THE POWER (P_0 OR P_{max}) LEVELS WHICH CAN BE DELIVERED BY THE ASSOCIATED APPARATUS, CONSIDERING FAULTS AND APPLICABLE FACTORS. IN ADDITION, THE MAXIMUM UNPROTECTED CAPACITANCE (C_1) AND THE INDUCTANCE (L_1) OF EACH APPARATUS (OTHER THAN THE TERMINATION) CONNECTED TO THE FIELD BUS MUST BE LESS THAN OR EQUAL TO 5 nF AND 10 μ H RESPECTIVELY.

IN EACH SEGMENT ONLY ONE ACTIVE DEVICE, NORMALLY THE ASSOCIATED APPARATUS, IS ALLOWED TO PROVIDE THE NECESSARY ENERGY FOR THE FIELD BUS SYSTEM. THE VOLTAGE U_0 (OR V_{oc} OR V_t) OF THE ASSOCIATED APPARATUS IS LIMITED TO A RANGE OF 14V TO 24Vd.c. ALL OTHER EQUIPMENT CONNECTED TO THE BUS CABLE HAS TO BE PASSIVE, MEANING THAT THEY ARE NOT ALLOWED TO PROVIDE ENERGY TO THE SYSTEM, EXCEPT A LEAKAGE CURRENT OF 50 μ A FOR EACH CONNECTED DEVICE. SEPARATELY POWERED EQUIPMENT NEEDS GALVANIC ISOLATION TO ASSURE THAT THE INTRINSICALLY SAFE FIELD BUS CIRCUIT REMAINS PASSIVE.

THE CABLE USED TO INTERCONNECT DEVICES NEEDS TO HAVE THE PARAMETERS IN THE FOLLOWING RANGE:

Loop Resistance R':	15.....150 Ohm/km
Inductance per unit length L':	0.4.....1 mH/km
Capacitance per unit length C':	80.....200 nF
C' = C' line/line + 0.5C' line/screen, if both lines are floating, or	
C' = C' line/line + C' line/screen, if the screen is connected to one line	
Length of trunk cable:	less than or equal to 1000m
Length of spur cable:	less than or equal to 30m
Length of spur splice:	less than or equal to 1m


AT EACH END OF THE TRUNK CABLE AN APPROVED INFALLIBLE LINE TERMINATION WITH THE FOLLOWING PARAMETERS IS SUITABLE:

$$R = 90.....100\Omega \quad C = 0.....2.2\mu F$$

ONE OF THE ALLOWED TERMINATIONS MIGHT ALREADY BE INTEGRATED IN THE ASSOCIATED APPARATUS. THE NUMBER OF PASSIVE APPARATUS CONNECTED TO THE BUS SEGMENT IS NOT LIMITED DUE TO I. S. REASONS. IF THE ABOVE RULES ARE RESPECTED, UP TO A TOTAL LENGTH OF 1000 m (SUM OF TRUNK AND ALL SPUR CABLES) OF CABLE IS PERMITTED. THE INDUCTANCE AND THE CAPACITANCE OF THE CABLE WILL NOT IMPAIR THE INTRINSIC SAFETY OF THE INSTALLATION.


Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO.	03151-1006
ISSUED	SCALE N/A	WT. _____	SHEET	8 OF 11

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO.	03151-1006
ISSUED	SCALE N/A	WT.	SHEET 9 OF	11

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				



IN NORMAL OPERATION
DEVICES CONTROL THROUGH-CURRENT

PARAMETERS (NON-INCENDIVE FIELD WIRING)	DEVICE	ROSEMOUNT 3051S/300S					
		3051S 4-20mA / HART	MODEL 300S REMOTE METER	3051S QUICK CONNECT OR 300S OUTPUT CODE 'A'	MODEL 300S HART DIAGNOSTICS OUTPUT CODE 'A'	300S OUTPUT CODE 'B' (SAFETY CERTIFIED)	FIELDBUS (F or W)
Vmax		42.4v	42.4v	42.4v	42.4v	42.4v	35v
Maximum normal operating current		22mA	22mA	22mA	22mA	22mA	27mA
C1		38nF	0nF	11.4nF	11.4nF	11.4nF	0uF
L1		0uH	58.2uH	2.4uH	0uH	570uH	0uH

$Imax_N \geq Iq_N + Isignal_N$

ROSEMOUNT 3051 TRANSMITTERS ARE CURRENT CONTROLLERS ON INDIVIDUAL PARALLEL BRANCHES WITH RESPECT TO THE POWER SUPPLY. IN NONINCENDIVE INSTALLATIONS THE $Imax$ FOR EACH TRANSMITTER IS NOT RELATED TO THE MAXIMUM CURRENT OF THE POWER SUPPLY (Isc) IN THE SAME MANNER AS FOR TRANSMITTER INSTALLED PER I.S. REQUIREMENTS, BECAUSE NONINCENDIVE REQUIREMENTS INCLUDE ONLY NORMAL OPERATING CONDITIONS.

$Imax$ for an individual device = $Iq + Isignal$

Iq = Quiescent current through device
(Maximum quiescent current for the device)

$Isignal$ = Signaling current through device
(Protocol may limit signaling to one device at a time)

Operating $Imax = Iq_1 + Iq_2 + \dots + Iq_N + I_{signal\ max}$
 $I_{signal\ max} = \text{Max. of } (Isignal_1, Isignal_2, \dots, Isignal_N)$

TEMP CODE: T5 ($Ta = -50^\circ\text{C TO } +40^\circ\text{C}$)

REFERENCE: APPENDIX A7 (FM3611 1999)

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO.	DWG NO. 03151-1006	
ISSUED	SCALE N/A	WT.	SHEET 10 OF 11	

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AM				

NOTES:

1. NO REVISION TO THIS DRAWING WITHOUT PRIOR FACTORY MUTUAL APPROVAL.
2. ASSOCIATED APPARATUS MANUFACTURER'S INSTALLATION DRAWING MUST BE FOLLOWED WHEN INSTALLING THIS EQUIPMENT.
3. DUST-TIGHT CONDUIT SEAL MUST BE USED WHEN INSTALLED IN CLASS II AND CLASS III ENVIRONMENTS.
4. CONTROL EQUIPMENT CONNECTED TO BARRIER MUST NOT USE OR GENERATE MORE THAN 250 Vrms or Vdc.
5. RESISTANCE BETWEEN INTRINSICALLY SAFE GROUND AND EARTH GROUND MUST BE LESS THAN 1 OHM.
6. INSTALLATION SHOULD BE IN ACCORDANCE WITH ANSI/ISA-RP12.6 "INSTALLATION OF INTRINSICALLY SAFE SYSTEMS FOR HAZARDOUS (CLASSIFIED) LOCATIONS" AND THE NATIONAL ELECTRICAL CODE (ANSI/NFPA 70).
7. THE ASSOCIATED APPARATUS MUST BE FACTORY MUTUAL APPROVED.
8. WARNING - SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC AND NON-INCENDIVE SAFETY.
9. ASSOCIATED APPARATUS MUST MEET THE FOLLOWING PARAMETERS:
 U_o or V_{oc} or V_t LESS THAN or EQUAL TO U_1 (V_{max})
 I_o or I_{sc} or I_t LESS THAN or EQUAL TO I_1 (I_{max})
 P_o or P_{max} LESS THAN or EQUAL TO P_1 (P_{max})
 C_a IS GREATER THAN or EQUAL THE SUM OF ALL C_1 's PLUS C_{cable}
 L_a IS GREATER THAN or EQUAL THE SUM OF ALL L_1 's PLUS L_{cable}
10. WARNING - TO PREVENT IGNITION OF FLAMMABLE OR COMBUSTIBLE ATMOSPHERES, DISCONNECT POWER BEFORE SERVICING.

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR.	Myles Lee Miller	SIZE A	FSCM NO	DWG NO. 03151-1006
ISSUED		SCALE N/A	WT. _____	SHEET 11 OF 11

Rosemount 3051S Series

CONFIDENTIAL AND PROPRIETARY INFORMATION IS CONTAINED HEREIN AND MUST BE HANDLED ACCORDINGLY.	REVISIONS				
	REV	DESCRIPTION	ECO NO.	APP'D	DATE
	AA	NEW RELEASE	RTC1022362	B.L.H.	9/1/06

NOTES:

1. USE TURCK CORDSETS AS SPECIFIED IN THIS DRAWING WITH GE / GM OPTION TO ENSURE OUTDOOR RATING (NEMA 4X or IP66).
2. LOK-FAST GUARD IS REQUIRED FOR CLASS 1 DIVISION 2 INSTALLATIONS.
3. (X)XXV 49-4.5IN/14.5 IS INSTALLED INTO 1/2-14 NPT CONDUIT ENTRY THREADS. (X)XXV 49-4.5IN/M20 IS INSTALLED INTO CM20 CONDUIT ENTRY THREADS.
4. eurofast[®] AND minifast[®] ARE REGISTERED TRADEMARKS OF TURCK INC.

UNLESS OTHERWISE SPECIFIED
 DIMENSIONS IN INCHES [mm].
 REMOVE ALL BURRS AND
 SHARP EDGES. MACHINE
 SURFACE FINISH 125

-TOLERANCES-
 .X ± .1 [2,5]
 .XX ± .02 [0,5]
 .XXX ± .010 [0,25]

FRACTIONS ANGLES
 ± 1/32 ± 2°

DO NOT SCALE PRINT




ROSEMOUNT[®]
 8200 Market Boulevard Chanhassen, MN 55317 USA


TITLE					
GE / GM OPTION NEMA 4X INSTALLATION, FM					
DR.	Myles Lee Miller	8/29/06	SIZE	DRAWING NO.	REV
APP'D	Bryce Hagbom	8/30/06	A	03151-1009	AA
CAD MAINTAINED, (PRO/E)				SHEET 1 OF 3	

Form Rev AA

GM OPTION WITH 4 - 20 mA / HART OUTPUT
 A-SIZE MINI (minifast[®]), 4-PIN CONNECTION





GE OPTION WITH 4 - 20 mA / HART OUTPUT
 M12 (eurofast[®]), 4-PIN CONNECTION



Form Rev. AA

		ROSEMOUNT[®] 8200 Market Boulevard Chanhassen, MN 55317 USA	
SIZE A	DRAWING NO. 03151-1009	REV AA	
CAD Maintained, (Pro/E)		SHEET 2	OF 3






EMERSON Process Management		ROSEMOUNT® 8200 Market Boulevard Chanhassen, MN 55317 USA	
SIZE A	DRAWING NO. 03151-1009	REV AA	
CAD Maintained, (Pro/E)		SHEET 3 OF 3	

Form Rev AA



Canadian Standards Association (CSA)

CONFIDENTIAL AND PROPRIETARY INFORMATION IS CONTAINED HEREIN AND MUST BE HANDLED ACCORDINGLY.	REVISIONS					
	ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
		AC	ADD 3051S_L AND TRADITIONAL HOUSING	RTC1015145	P.C.S.	4/7/03
	AD	ADD NOTE 9	RTC1018745	B.L.H.	12/6/04	

NOTES:

1.  WIRING METHOD SUITABLE FOR CLASS I, DIV I WITH ANY LENGTH.
2.  TRANSMITTER MUST NOT BE CONNECTED TO EQUIPMENT GENERATING MORE THAN 250 VAC.
3. ALL CONDUIT THREADS TO BE ASSEMBLED WITH FIVE FULL TAPERED THREADS MINIMUM.
4. COMPONENTS REQUIRED TO BE APPROVED MUST BE APPROVED FOR GAS GROUP APPROPRIATE TO AREA CLASSIFICATION.
5. 3051SC, 3051ST OR 3051SL SENSOR MODULE MUST BE INSTALLED WITH CSA FLAMEPROOF / EXPLOSIONPROOF APPROVED 300S1, 300S2 OR 300S4 HOUSING ATTACHED TO MEET FLAMEPROOF / EXPLOSIONPROOF INSTALLATION REQUIREMENTS. MINIMUM OF 7 FULL THREADS ENGAGED AND LOCKED IN PLACE. SEE PAGE 3.
6. INSTALLATION TO BE IN ACCORDANCE WITH THE LATEST EDITION OF CANADIAN ELECTRICAL CODE.
7. 300S1, 300S2 OR 300S4 HOUSING MUST BE INSTALLED WITH CSA FLAMEPROOF / EXPLOSIONPROOF APPROVED 3051SC, 3051ST OR 3051SL SENSOR MODULE ATTACHED TO MEET FLAMEPROOF / EXPLOSIONPROOF INSTALLATION REQUIREMENTS. MINIMUM OF 7 FULL THREADS ENGAGED AND LOCKED IN PLACE. SEE PAGE 3.
8.  UNUSED CONDUIT ENTRY MUST BE CLOSED WITH SUITABLE BLANKING ELEMENT.
9. TEMPERATURE CODE T5, Tambient = -50°C to 85°C.

CAD Maintained, (Pro/E)


UNLESS OTHERWISE SPECIFIED DIMENSIONS IN INCHES [mm]. REMOVE ALL BURRS AND SHARP EDGES. MACHINE SURFACE FINISH 125 -TOLERANCES- .X ± .1 [2,5] .XX ± .02 [0,5] .XXX ± .010 [0,25] FRACTIONS ANGLES ± 1/32 ± 2° DO NOT SCALE PRINT	CONTRACT NO.		  8200 Market Boulevard • Chanhassen, MN 55317 USA		
	DR. <i>Myles Lee Miller</i>	8/28/00			
	CHK'D				EXPLOSIONPROOF / FLAMEPROOF
	APP'D Paul C. Sundet	10/19/00			INSTALLATION DRAWING, CSA
APP'D GOVT.		SIZE A	FSCM NO.	DRAWING NO.	03151-1013
		SCALE 1:4	WT.	SHEET 1	OF 3

REVISIONS					
ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
	AD				

COMPONENT IDENTIFICATION


300S1____, PLANTWEB
300S4____, TRADITIONAL
(DUAL COMPARTMENT HOUSING)

300S2____
JUNCTION BOX HOUSING
(SINGLE COMPARTMENT)



3051S_C____
3051S_L____
SCALABLE COPLANAR
PRESSURE TRANSMITTER


3051S_T____
SCALABLE IN-LINE
PRESSURE TRANSMITTER



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA			CAD Maintained, (Pro/E)		
DR.	<i>Myles Lee Miller</i>	8/28/00	SIZE A	FSCM NO	DWG NO. 03151-1013
ISSUED			SCALE 1:2	WT.	SHEET 2 OF 3

REVISIONS					
ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
	AD				

HOUSING TO MODULE ASSEMBLY



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA			CAD Maintained, (Pro/E)		
DR.	<i>Myles Lee Miller</i>	8/28/00	SIZE A	FSCM NO.	DWG NO. 03151-1013
ISSUED			SCALE 1:4	WT.	SHEET 3 OF 3

Rosemount 3051S Series

CONFIDENTIAL AND PROPRIETARY INFORMATION IS CONTAINED HEREIN AND MUST BE HANDLED ACCORDINGLY	REVISIONS				
	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
	AF	CORRECTED C ₁ for SM	RTC1016190	S.R.T.	10/20/03
	AG	ADD OUTPUT CODE B (SIS)	RTC1017150	B.L.H.	3/17/04
	AH	CHG 'IE' to 'IF' ON PG 9	RTC1019914	B.L.H.	7/21/05
	AJ	ADD QUICK CONNECT	RTC1020189	T.S.	8/31/05
AK	ADD DIAGNOSTICS FEATURE BOARD	RTC1020856	J.D.V.	3/23/06	

APPROVALS FOR


OUTPUT CODES A,B,F,W I.S. ENTITY PARAMETERS SHEETS 2-3
 OUTPUT CODES A,B (4-20 mA HART) I.S. SEE SHEETS 4-7
 REMOTE METER (4-20 mA HART) I.S. SEE SHEET 6
 OUTPUT CODE F/W (FIELDBUS) I.S. SEE SHEET 8
 FISCO SEE SHEETS 9-10

TO ASSURE AN INTRINSICALLY SAFE SYSTEM, THE TRANSMITTER AND BARRIER MUST BE WIRED IN ACCORDANCE WITH THE BARRIER MANUFACTURER'S FIELD WIRING INSTRUCTIONS AND THE APPLICABLE CIRCUIT DIAGRAM.

WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION I.

AVERTISSEMENT - RISQUE D'EXPLOSION - LA SUBSTITUTION DE COMPOSANTS PEUT RENDRE CE MATERIEL INACCEPTABLE POUR LES EMPLACEMENTS DE CLASSE I, DIVISION I.

CAD MAINTAINED (MicroStation)

UNLESS OTHERWISE SPECIFIED DIMENSIONS IN INCHES (mm). REMOVE ALL BURRS AND SHARP EDGES. MACHINE SURFACE FINISH 125	CONTRACT NO.		 ROSEMOUNT® 8200 Market Boulevard • Chanhassen, MN 55317 USA		
	DR. Myles Lee Miller	3/7/01	TITLE INDEX OF I.S. CSA FOR 3051S		
	CHK'D				
	APP'D. Paul C. Sundet	8/6/01	SIZE A	FSCM NO	DWG NO. 03151-1016
	FRACTIONS ± 1/32	ANGLES ± 2°	SCALE	N/A	WT. _____
DO NOT SCALE PRINT	APP'D. GOVT.				

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

ENTITY CONCEPT APPROVALS

THE ENTITY CONCEPT ALLOWS INTERCONNECTION OF INTRINSICALLY SAFE APPARATUS TO ASSOCIATED APPARATUS NOT SPECIFICALLY EXAMINED IN COMBINATION AS A SYSTEM. THE APPROVED VALUES OF MAX. OPEN CIRCUIT VOLTAGE (V_{OC}) AND MAX. SHORT CIRCUIT CURRENT (I_{SC}) AND MAX. POWER ($V_{OC} \times I_{SC}/4$), FOR THE ASSOCIATED APPARATUS MUST BE LESS THAN OR EQUAL TO THE MAXIMUM SAFE INPUT VOLTAGE (V_{MAX}), MAXIMUM SAFE INPUT CURRENT (I_{MAX}), AND MAXIMUM SAFE INPUT POWER (P_{MAX}) OF THE INTRINSICALLY SAFE APPARATUS. IN ADDITION, THE APPROVED MAX. ALLOWABLE CONNECTED CAPACITANCE (C_A) OF THE ASSOCIATED APPARATUS MUST BE GREATER THAN THE SUM OF THE INTERCONNECTING CABLE CAPACITANCE AND THE UNPROTECTED INTERNAL CAPACITANCE (C_1) OF THE INTRINSICALLY SAFE APPARATUS, AND THE APPROVED MAX. ALLOWABLE CONNECTED INDUCTANCE (L_A) OF THE ASSOCIATED APPARATUS MUST BE GREATER THAN THE SUM OF THE INTERCONNECTING CABLE INDUCTANCE AND THE UNPROTECTED INTERNAL INDUCTANCE (L_1) OF THE INTRINSICALLY SAFE APPARATUS.

FOR OUTPUT CODE A MODEL 3051S
 CLASS I, DIV. 1, GROUPS A, B, C AND D

$V_{MAX} = 30V$	V_{OC} IS LESS THAN OR EQUAL TO 30V
$I_{MAX} = 300mA$	I_{SC} IS LESS THAN OR EQUAL TO 300mA
$C_1 = 38nF$	C_A IS GREATER THAN $38nF + C_{cable}$
$L_1 = 0$	L_A IS GREATER THAN $0H + L_{cable}$

FOR OUTPUT CODE A WITH MODEL 300S JUNCTION BOX, 300S PLANTWEB HOUSING, OR 3051S QUICK CONNECT CLASS I, DIV. 1, GROUPS A, B, C AND D

$V_{MAX} = 30V$	V_{OC} IS LESS THAN OR EQUAL TO 30V
$I_{MAX} = 300mA$	I_{SC} IS LESS THAN OR EQUAL TO 300mA
$C_1 = 11.4nF$	C_A IS GREATER THAN $11.4nF + C_{cable}$
$L_1 = 2.4\mu H$	L_A IS GREATER THAN $2.4\mu H + L_{cable}$

FOR OUTPUT CODE A WITH REMOTE METER CONFIGURATION (OPTION CODES M8 or M9)
 CLASS I, DIV. 1, GROUPS A, B, C AND D

$V_{MAX} = 30V$	V_{OC} IS LESS THAN OR EQUAL TO 30V
$I_{MAX} = 300mA$	I_{SC} IS LESS THAN OR EQUAL TO 300mA
$C_1 = 0nF$	C_A IS GREATER THAN C_{cable}
$L_1 = 58.2\mu H$	L_A IS GREATER THAN $58.2\mu H + L_{cable}$

FOR OUTPUT CODE A WITH HART DIAGNOSTICS SUITE AND MODEL 300S PLANTWEB HOUSING
 CLASS I, DIV. 1, GROUPS A, B, C AND D

$V_{MAX} = 30V$	V_{OC} IS LESS THAN OR EQUAL TO 30V
$I_{MAX} = 300mA$	I_{SC} IS LESS THAN OR EQUAL TO 300mA
$C_1 = 11.4nF$	C_A IS GREATER THAN $11.4nF + C_{cable}$
$L_1 = 0$	L_A IS GREATER THAN $0H + L_{cable}$

NOTE: ENTITY PARAMETERS LISTED APPLY ONLY TO ASSOCIATED APPARATUS WITH LINEAR OUTPUT.

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR.	Myles Lee Miller	SIZE A	FSCM NO.	DWG NO. 03151-1016
ISSUED		SCALE N/A	WT.	SHEET 2 OF 10

Rosemount 3051S Series

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

FOR OUTPUT CODE B (SAFETY CERTIFIED SIS) WITH MODEL 300S PLANTWEB HOUSING
CLASS I, DIV. 1, GROUPS A, B, C AND D

$V_{MAX} = 30V$	V_{OC} IS LESS THAN OR EQUAL TO 30V
$I_{MAX} = 300mA$	I_{SC} IS LESS THAN OR EQUAL TO 300mA
$C_1 = 11.4nF$	C_A IS GREATER THAN 11.4nF + C_{cable}
$L_1 = 570\mu H$	L_A IS GREATER THAN 570 μH + L_{cable}

FOR OUTPUT CODE F or W WITH MODEL 300S PLANTWEB HOUSING
CLASS I, DIV. 1, GROUPS A, B, C AND D

$V_{MAX} = 30V$	V_{OC} IS LESS THAN OR EQUAL TO 30V
$I_{MAX} = 300mA$	I_{SC} IS LESS THAN OR EQUAL TO 300mA
$C_1 = 0\mu f$	C_A IS GREATER THAN 0 μf + C_{cable}
$L_1 = 0\mu H$	L_A IS GREATER THAN 0 μH + L_{cable}


NOTE: ENTITY PARAMETERS LISTED APPLY ONLY TO ASSOCIATED
APPARATUS WITH LINEAR OUTPUT.

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO.	03151-1016
ISSUED	SCALE N/A	WT. _____	SHEET 3 OF 10	

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

CSA INTRINSIC SAFETY APPROVALS
 CIRCUIT CONNECTION WITH BARRIER OR CONVERTER

Ex ia
 INTRINSICALLY SAFE/SECURITE INTRINSEQUE
 4-20 mA, ("A" or "B" OUTPUT CODE)



** FOR FIELDBUS OPTIONS("F" or "W" OUTPUT CODE),
 SEE PAGE 6 FOR PARAMETERS AND CIRCUIT CONNECTION TO BARRIER.

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)	
DR. Myles Lee Miller 3/7/001	SIZE A	FSCM NO	DWG NO. 03151-1016
ISSUED	SCALE N/A	WT. _____	SHEET 4 OF 10


Rosemount 3051S Series

Reference Manual
00809-0100-4801, Rev CB
January 2007

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

CSA INTRINSIC SAFETY APPROVALS
CIRCUIT CONNECTION WITH BARRIER OR CONVERTER

Ex ia
INTRINSICALLY SAFE/SECURITE INTRINSEQUE
4-20 mA, ("A" OUTPUT CODE)




Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller 8/17/05	SIZE A	FSCM NO	DWG NO.	Ø3151-1Ø16
ISSUED	SCALE N/A	WT.	SHEET 5 OF 10	

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

CSA INTRINSIC SAFETY APPROVALS
 CIRCUIT CONNECTION WITH BARRIER OR CONVERTER

Ex ia
 INTRINSICALLY SAFE/SECURITE INTRINSEQUE
 4-20 mA, ("A" OUTPUT CODE)



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR.	Myles Lee Miller	SIZE A	FSCM NO	DWG NO. 03151-1016
ISSUED		SCALE N/A	WT.	SHEET 6 OF 10

Rosemount 3051S Series

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

4-20 mA, ("A" or "B" OUTPUT CODE)

DEVICE	PARAMETERS	APPROVED FOR CLASS I, DIV.I
CSA APPROVED SAFETY BARRIER	30 V OR LESS * 330 OHMS OR MORE * 28 V OR LESS 300 OHMS OR MORE 25 V OR LESS 200 OHMS OR MORE * 22 V OR LESS 180 OHMS OR MORE	GROUPS A, B, C, D
FOXBORO CONVERTER 2A1-I2V-CGB, 2A1-I3V-CGB, 2AS-I3I-CGB, 3A2-I2D-CGB, 3A2-I3D-CGB, 3AD-I3I-CGB, 3A4-I2D-CGB, 2AS-I2I-CGB, 3F4-I2DA		GROUPS B, C, D
CSA APPROVED SAFETY BARRIER	30 V OR LESS 150 OHMS OR MORE	GROUPS C, D

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO. 03151-1016	
ISSUED	SCALE N/A	WT. _____	SHEET 7 OF 10	


REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

FIELDBUS, ("F" or "W" OUTPUT CODE)

DEVICE	PARAMETERS	APPROVED FOR CLASS I, DIV. I
CSA APPROVED SAFETY BARRIER	30 V OR LESS 300 OHMS OR MORE	GROUPS A, B, C, D
	28 V OR LESS 235 OHMS OR MORE	
	25 V OR LESS 160 OHMS OR MORE	
	22 V OR LESS 100 OHMS OR MORE	

CSA INTRINSIC SAFETY APPROVALS CIRCUIT CONNECTION WITH BARRIER OR CONVERTER

Ex ia
 INTRINSICALLY SAFE/SECURITE INTRINSEQUE
 FIELDBUS, ("F" or "W" OUTPUT CODE)



WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS
 MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION I.

AVERTISSEMENT - RISQUE D'EXPLOSION - LA SUBSTITUTION DE COMPOSANTS
 PEUT RENDRE CE MATERIEL INACCEPTABLE POUR LES EMPLACEMENTS
 DE CLASSE I, DIVISION I.

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)	
DR. Myles Lee Miller	SIZE A	FSCM NO.	DWG NO. 03151-1016
ISSUED	SCALE N/A	WT.	SHEET 8 OF 10

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

FISCO CONCEPT

THE FISCO CONCEPT ALLOWS INTERCONNECTION OF INTRINSICALLY SAFE APPARATUS TO ASSOCIATED APPARATUS NOT SPECIALLY EXAMINED IN SUCH COMBINATION. THE CRITERIA FOR INTERCONNECTION IS THAT THE VOLTAGE (V_{max}), THE CURRENT (I_{max}), AND THE POWER (P_{max}) WHICH AN INTRINSICALLY SAFE APPARATUS CAN RECEIVE AND REMAIN INTRINSICALLY SAFE CONSIDERING FAULTS, MUST BE EQUAL OR GREATER THAN VOLTAGE (V_{oc}), AND CURRENT (I_{sc}) WHICH CAN BE DELIVERED BY THE ASSOCIATED APPARATUS, CONSIDERING FAULTS AND APPLICABLE FACTORS. IN ADDITION, THE MAXIMUM UNPROTECTED CAPACITANCE (C_1) AND THE INDUCTANCE (L_1) OF EACH APPARATUS (OTHER THAN THE TERMINATION) CONNECTED TO THE FIELDBUS MUST BE LESS THAN OR EQUAL TO 5 nF AND 10 μ H RESPECTIVELY.

IN EACH SEGMENT ONLY ONE ACTIVE DEVICE, NORMALLY THE ASSOCIATED APPARATUS, IS ALLOWED TO PROVIDE THE NECESSARY ENERGY FOR THE FIELDBUS SYSTEM. THE VOLTAGE (V_{oc}) OF THE ASSOCIATED APPARATUS IS LIMITED TO A RANGE OF 14V TO 24Vd.c. ALL OTHER EQUIPMENT CONNECTED TO THE BUS CABLE HAS TO BE PASSIVE, MEANING THAT THEY ARE NOT ALLOWED TO PROVIDE ENERGY TO THE SYSTEM, EXCEPT A LEAKAGE CURRENT OF 50 μ A FOR EACH CONNECTED DEVICE. SEPARATELY POWERED EQUIPMENT NEEDS GALVANIC ISOLATION TO ASSURE THAT THE INTRINSICALLY SAFE FIELDBUS CIRCUIT REMAINS PASSIVE.

THE CABLE USED TO INTERCONNECT DEVICES NEEDS TO HAVE THE PARAMETERS IN THE FOLLOWING RANGE:

Loop Resistance R':	15.....150 Ohm/km
Inductance per unit length L':	0.4.....1 mH/km
Capacitance per unit length C':	80.....200 nF
C' = C' line/line + 0.5C' line/screen, if both lines are floating, or	
C' = C' line/line + C' line/screen, if the screen is connected to one line	
Length of trunk cable:	less than or equal to 1000m
Length of spur cable:	less than or equal to 30m
Length of spur splice:	less than or equal to 1m

AT EACH END OF THE TRUNK CABLE AN APPROVED INFALLIBLE LINE TERMINATION WITH THE FOLLOWING PARAMETERS IS SUITABLE:

$$R = 90.....100\Omega \quad C = 0.....2.2\mu F$$


ONE OF THE ALLOWED TERMINATIONS MIGHT ALREADY BE INTEGRATED IN THE ASSOCIATED APPARATUS. THE NUMBER OF PASSIVE APPARATUS CONNECTED TO THE BUS SEGMENT IS NOT LIMITED DUE TO I. S. REASONS. IF THE ABOVE RULES ARE RESPECTED, UP TO A TOTAL LENGTH OF 1000 m (SUM OF TRUNK AND ALL SPUR CABLES) OF CABLE IS PERMITTED. THE INDUCTANCE AND THE CAPACITANCE OF THE CABLE WILL NOT IMPAIR THE INTRINSIC SAFETY OF THE INSTALLATION.

Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR. Myles Lee Miller	SIZE A	FSCM NO	DWG NO.	03151-1016
ISSUED	SCALE N/A	WT. _____	SHEET	9 OF 10

REVISIONS				
REV	DESCRIPTION	CHG. NO.	APP'D	DATE
AK				

NOTES:

1. APPROVED ASSOCIATED APPARATUS MUST BE INSTALLED IN ACCORDANCE WITH MANUFACTURER'S INSTRUCTIONS.
2. CSA APPROVED ASSOCIATED APPARATUS MUST MEET THE FOLLOWING PARAMETERS:
 V_{oc} LESS THAN OR EQUAL TO (V_{max}) AND I_{sc} LESS THAN OR EQUAL TO (I_{max}) .
3. THE MAXIMUM NON-HAZARDOUS AREA VOLTAGE MUST NOT EXCEED 250V.
4. THE INSTALLATION MUST BE IN ACCORDANCE WITH CANADIAN ELECTRICAL
5. CAUTION: USE ONLY SUPPLY WIRES SUITABLE FOR 5°C ABOVE SURROUNDING TEMPERATURE.
6. WARNING: SUBSTITUTION OF COMPONENTS MAY IMPAIR INTRINSIC SAFETY.



Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD MAINTAINED (MicroStation)		
DR.	Myles Lee Miller	SIZE A	FSCM NO.	DWG NO. 03151-1016
ISSUED		SCALE N/A	WT.	SHEET 10 OF 10

Rosemount 3051S Series

KEMA

CONFIDENTIAL AND PROPRIETARY INFORMATION IS CONTAINED HEREIN AND MUST BE HANDLED ACCORDINGLY.	REVISIONS					
	ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
		AA	NEW RELEASE	RTC1009618	P.C.S.	9/11/00
	AB	ADD 3051SL AND TRADITIONAL HOUSING	RTC1015145	B.L.H.	4/7/03	

NOTES:

1. WIRING METHOD SUITABLE FOR CATEGORY 2, (ZONE 1) WITH ANY LENGTH.
2. TRANSMITTER MUST NOT BE CONNECTED TO EQUIPMENT GENERATING MORE THAN 250 VAC.
3. ALL CONDUIT THREADS TO BE ASSEMBLED WITH FIVE FULL THREADS MINIMUM.
4. COMPONENTS REQUIRED TO BE APPROVED MUST BE APPROVED FOR GAS GROUP APPROPRIATE TO AREA CLASSIFICATION.
5. 3051SC, 3051ST OR 3051SL SENSOR MODULE MUST BE INSTALLED WITH CENELEC FLAMEPROOF APPROVED 300S1, 300S2 OR 300S4 HOUSING ATTACHED TO MEET FLAMEPROOF INSTALLATION REQUIREMENTS.
6. INSTALLATION TO BE IN ACCORDANCE WITH APPLICABLE LOCAL REQUIREMENTS.
7. 300S1, 300S2 OR 300S4 HOUSING MUST BE INSTALLED WITH CENELEC FLAMEPROOF APPROVED 3051SC, 3051ST OR 3051SL SENSOR MODULE ATTACHED TO MEET FLAMEPROOF INSTALLATION REQUIREMENTS.
8. UNUSED CONDUIT ENTRY MUST BE CLOSED WITH A CENELEC FLAMEPROOF APPROVED BLANKING ELEMENT.

CAD Maintained. (Pro/E)


UNLESS OTHERWISE SPECIFIED DIMENSIONS IN INCHES [mm]. REMOVE ALL BURRS AND SHARP EDGES. MACHINE SURFACE FINISH 125 -TOLERANCES- .X ± .1 [2,5] .XX ± .02 [0,5] .XXX ± .010 [0,25] FRACTIONS ± 1/32 ANGLES ± 2° DO NOT SCALE PRINT	CONTRACT NO.		ROSEMOUNT® 8200 Market Boulevard • Chanhassen, MN 55317 USA		
	DR.	Myles Lee Miller	8/28/00	TITLE MODEL 3051 / 300 FLAMEPROOF INSTALLATION DRAWING, KEMA	
	CHK'D	.	.		
	APP'D	Paul C. Sundet	9/11/00		
	APP'D GOVT.			SIZE A	FSCM NO.
			DRAWING NO. 03151-1023		
			SCALE 1:4	WT.	
			SHEET 1 OF 3		

REVISIONS					
ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
	AB				

COMPONENT IDENTIFICATION


300S1_----, PLANTWEB
 300S4_----, TRADITIONAL
 (DUAL COMPARTMENT HOUSING)

300S2_----
 JUNCTION BOX HOUSING
 (SINGLE COMPARTMENT)



3051S_C_----
 3051S_L_----
 SCALABLE COPLANAR
 PRESSURE TRANSMITTER

3051S_T_----
 SCALABLE IN-LINE
 PRESSURE TRANSMITTER




Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA		CAD Maintained, (Pro/E)		
DR. <i>Myles Lee Miller</i>	8/28/00	SIZE A	FSCM NO.	DWG NO. 03151-1023
ISSUED		SCALE 1:2	WT.	SHEET 2 OF 3

Rosemount 3051S Series

Reference Manual
00809-0100-4801, Rev CB
January 2007

REVISIONS					
ZONE	REV	DESCRIPTION	CHG. NO.	APP'D	DATE
	AB				

HOUSING TO MODULE ASSEMBLY




Rosemount Inc. 8200 Market Boulevard Chanhassen, MN 55317 USA			CAD Maintained, (Pro/E)		
DR. <i>Myles Lee Miller</i>	8/28/00	SIZE A	FSCM NO	DWG NO.	03151-1023
ISSUED		SCALE	1 : 4	WT.	SHEET 3 OF 3

EUROPEAN ATEX DIRECTIVE INFORMATION

CENELEC/BASEEFA

Rosemount 3051S pressure transmitters that have the following label attached, have been certified to comply with Directive 94/9/EC of the European Parliament and the Council as published in the Official Journal of the European Communities No. L 100/1 on 19–April–1994.



The following information is provided as part of the labeling of the transmitter:

Name and address of the manufacturer (any of the following):

- Rosemount USA
- Rosemount Germany
- Rosemount Singapore




- Complete model number
- The serial number of the device
- Year of construction

- Marking for explosion protection:
 - EEx ia IIC T5 ($T_{amb} = -60$ to 40 °C)
 - EEx ia IIC T4 ($T_{amb} = -60$ to 70 °C)
 - $U_i = 30$ V dc, $I_i = 300$ mA, $P_i = 1.0$ W, $C_i = 30$ nF, $L_i = 0$ mH
 - BASEEFA ATEX certificate number: BAS01ATEX1303X




Intrinsic Safety housing label




- Marking for explosion protection:
 - EEx ia IIC T5 (See Certificate)
 - EEx ia IIC T4 (See Certificate)
 - BASEEFA ATEX certificate number: BAS01ATEX1303X




Type n housing label



- Marking for explosion protection:
EEx nL IIC T5 (-40 °C ≤ T_{amb} ≤ 70 °C)  II 3 G
Ui = 45 Vdc MAX
BASEEFA ATEX certificate number: BAS01ATEX3304X


Dust housing label



- Marking for explosion protection:
-20 °C ≤ T_{amb} ≤ 85 °C
T105°C
IP66
V = 42.4 VOLTS MAX
A = 24 mA
BASEEFA ATEX certificate number: BAS01ATEX1374X

**CENELEC/KEMA
 Flameproof**

The Rosemount 3051S and 300S pressure transmitters that have the following label attached, have been certified to comply with Directive 94/9/EC of the European Parliament and the Council as published in the Official Journal of the European Communities No. L 100/1 on 19-April-1994.



The following information is provided as part of the labeling of the transmitter:

Name and address of the manufacturer (any of the following):


- Rosemount USA
- Rosemount Germany
- Rosemount Singapore



- Complete model number
- The serial number of the device
- Year of construction
- Marking for explosion protection:
 EEx d IIC T6 ($T_{amb} = -50$ to 65 °C)
 EEx d IIC T5 ($T_{amb} = -50$ to 80 °C)
 ATEX certificate number: KEMA00ATEX2143X



Housing Label



- Marking for explosion protection:
 EEx d IIC T6 ($T_{amb} = -50$ to 65 °C)
 EEx d IIC T5 ($T_{amb} = -50$ to 80 °C)
 ATEX certificate number: KEMA00ATEX2143X



Rosemount 3051S Series

Reference Manual
00809-0100-4801, Rev CB
January 2007

Index

A

- Address
 - Changing 3-26
- Alarm 3-14
 - Burst mode values 3-14
 - Failure mode values 3-12
 - Level configuration 3-13
 - Level verification 3-14
 - Multidrop mode values 3-14
- Alarm direction configuration 2-15
- Alerts 3-15
- Analog output trim 4-7
- Approvals
 - Drawings B-6

B

- Basic setup 3-8
- Bolts
 - Installation 2-6
 - Material 2-7
- Brackets
 - Mounting 2-6
- Burst mode
 - Advanced functions 3-24
 - Alarm and saturation values 3-14

C

- Calibration 4-1
 - Choosing a procedure 4-5
 - Frequency, determining 4-4
 - Full trim 4-6
 - Overview 4-2
 - Recal factory trim
 - Analog output 4-10
 - Sensor trim 4-7
 - Sensor trim 4-5
 - Tasks 4-2
 - Zero trim 4-6
- Cloning 3-22
- Commissioning
 - HART protocol
 - AMS 3-2
 - HART Communicator 3-2
- Compensating line pressure 4-10

Configuration

- Alarm and saturation 3-13
 - Applying a user configuration 3-24
 - Cloning 3-22
 - Data review 3-4
 - LCD meter 3-11
 - Recalling 3-22
 - Reusable copy 3-23
 - Saving 3-22
 - Scaled variable 3-16
- ## Configure
- Alarm direction 2-15
- ## Considerations
- Compatibility 2-2
 - Electrical, fieldbus 2-16
 - Environmental 2-3
 - General 2-2
 - Mechanical 2-2

D

- Damping 3-11
- Detailed setup 3-12
- Diagnostics and service 3-20
 - Loop
 - Test 3-21
 - Messages 4-12
 - Transmitter test 3-20

Diagrams

- Bench hook-up 3-3
- Field hook-up 3-3
- HART terminal block 2-15
- Installation 2-10
- Multidrop network 3-25
- Typical multidrop network 3-25
- Digital to analog trim 4-8
 - Other scale 4-9

Disassembly

- Before disassembling 5-3
- Remove assembly 5-4
- Remove from service 5-3
- Remove housing 5-4
- Removing electronics board 5-4
- Removing sensor module 5-4
- Removing terminal block 5-4
- Disassembly procedures 5-3
- Drawings
 - Approval B-6

E

- Electronics board
 - Removing 5-4
- Environmental considerations 2-3

F

- Failure mode alarm and saturation
 - Values 3-12
- Full trim 4-6

G

- Gas mounting requirements 2-10
- Grounding 2-18
 - External assembly 2-20
 - Internal connection 2-20
 - Signal wiring grounding 2-16

H

- Housing Rotation
 - Junction Box 2-6, 2-12
 - PlantWeb 2-6, 2-12

I

- Impulse piping 2-9
- Installation 2-5
 - 304 manifold 2-22
 - 305 manifold 2-21
 - 306 manifold 2-22
 - Alarm direction 2-15
 - Bolts 2-6
 - Cover 2-5
 - HART flowchart 2-4
 - Housing rotation 2-12
 - LCD meter 2-20
 - Mounting 2-6
 - Brackets 2-6
 - Torque values 2-7
 - Power supply
 - HART protocol 2-16
 - Power up 2-15
 - Process Flange Orientation 2-5
 - Signal wiring grounding 2-16
 - Wiring 2-15
- Introduction 1-1

L

- LCD meter 3-11
 - Configuration 3-11
 - Installing 2-20
 - Options 3-12
- Lightning 2-16
- Line pressure
 - Compensating 4-10
- Liquid mounting requirements 2-10
- Loop
 - Setting to manual 3-2
- Loop test 3-21

Rosemount 3051S Series

M

- Maintenance 4-1
- Manifold installations 2-22
- Manual
 - Use of 1-1
- Mechanical considerations ... 2-2
- Mounting
 - Bolt installation
 - Torque values 2-7
 - Installation 2-6
- Mounting requirements 2-10
 - Gas 2-10
 - Liquid 2-10
 - Steam 2-10
- Multidrop communication ... 3-14
 - Advanced functions ... 3-25
 - Communicating 3-26
 - Diagram 3-25

N

- NAMUR-compliant values ... 3-13

O

- Operation 4-1
- Options
 - LCD meter 3-12
- Output
 - Process variables 3-7
 - Recal factory trim 4-10
 - Sensor temperature 3-7
 - Transfer function 3-8

P

- Piping, impulse 2-9
- Power supply
 - HART protocol 2-16
- Power up 2-15
 - Power supply HART protocol .
2-16
 - Remote meter 2-17
- Process alerts 3-15
- Process connections 2-11
- Process variables 3-7
 - Units 3-8

R

- Reassembly 5-5
 - Attaching SuperModule .. 5-5
 - Install terminal block 5-5
 - Process sensor body 5-6
- Reassembly procedures 5-5
- Recall factory trim
 - Analog output 4-10
 - Sensor trim 4-7
- Recalling 3-22
- Re-mapping 3-19

- Remote Meter Wiring 2-17
- Remote meter wiring
 - Wiring diagram 2-18
- Rerange 3-9
 - AMS only 3-11
 - HART Communicator only 3-10
 - Pressure Input Source
 - With AMS 3-11
 - Pressure input source
 - With HART Communicator
3-10
 - With local zero and span .
3-10
- Returning products and materials 5-7
- Reusable copy 3-23

S

- Saturation
 - Burst mode values 3-14
 - Failure mode values ... 3-12
 - Level configuration 3-13
 - Multidrop mode values . 3-14
- Saving a configuration 3-22
- Scaled variable configuration 3-16
- Security (Write Protect) 2-13
- Sensor module
 - Removing 5-4
- Sensor Temperature 3-7
- Sensor temperature 3-7
 - Unit 3-20
- Sensor trim 4-5
- Service and Diagnostics 3-20
- Service Support 1-3
- Setup
 - Basic 3-8
 - Detailed 3-12
- Signal wiring grounding 2-16
- Spare parts A-40
- Steam mounting requirements 2-10
- SuperModule
 - Installing 5-5
- Surges 2-17
- Switches and jumpers
 - Configuration
 - Junction Box 2-14
 - PlantWeb 2-14
 - Security (Write Protect) . 2-13

T

- Tagging 2-2
- Terminal block
 - Installing 5-5
 - Removing 5-4
- Terminal block diagrams
 - HARTprotocol 2-15
- Terminal Side 2-5
- Test 3-20

- Torque values 2-7
- Transfer function 3-8
- Transient
 - Protection 2-16
- Transients 2-16
- Transmitter functions 4-1
- Transmitter test 3-20
- Trim
 - Analog output 4-7
 - Digital to Analog 4-8
 - Other scale 4-9
 - Full 4-6
 - Recall factory
 - Analog output 4-10
 - Sensor trim 4-7
 - Sensor 4-5
 - Zero 4-6
- Troubleshooting 5-1
 - Reference table 5-2

U

- Units, Process variable 3-8
- Upgrades 4-14
 - Feature boards 4-14

W

- Wiring
 - Remote meter 2-17
 - Signal wiring grounding .. 2-16
 - Surges 2-17
 - Transients 2-16
- Wiring diagrams
 - Bench hook-up 3-3
 - Field hook-up 3-3

Z

- Zero trim 4-6

Reference Manual

00809-0100-4801, Rev CB
January 2007

Rosemount 3051S Series

*The Emerson logo is a trademark and service mark of Emerson Electric Co.
Rosemount and the Rosemount logotype are registered trademarks of Rosemount Inc.
SuperModule and Coplanar trademarks of Rosemount Inc.
PlantWeb is a mark of one of the Emerson Process Management companies.
HART is a registered trademark of the HART Communications Foundation.
ASP Diagnostics Suite is a trademark of one of the Emerson Process Management companies.
Hastelloy C and Hastelloy C-276 are registered trademarks of Cabot Corp.
Monel is a registered trademark of International Nickel Co.
Syltherm and D.C. are registered trademarks of Dow Corning Co.
Neobee M-20 is a registered trademark of Stephan Chemical Co.
The 3-A symbol is a registered trademark of the 3-A Sanitary Standards Symbol Council.
FOUNDATION fieldbus is a registered trademark of the Fieldbus Foundation.
Teflon is a registered trademark of E.I. du Pont de Nemours & Co.
Grafoil is a trademark of Union Carbide Corp.*

All other marks are the property of their respective owners.

Cover Photo: Cosmos/HighRes/305/0305h0061

Emerson Process Management

Rosemount Inc.

8200 Market Boulevard
Chanhausen, MN 55317 USA
T (U.S.) 1 800 999 9307
T (International) (952) 906 8888
F (952) 949 7001
www.rosemount.com

Emerson Process Management GmbH & Co.

Argelsrieder Feld 3
82234 Wessling
Germany
Tel 49 (8153) 9390
Fax 49 (8153) 939172

Emerson Process Management Asia Pacific Private Limited

1 Pandan Crescent
Singapore 128461
T (65) 6777 8211
F (65) 6777 0947
Enquiries@AP.EmersonProcess.com

Beijing Rosemount Far East Instrument Co., Limited

No. 6 North Street,
Hepingli, Dong Cheng District
Beijing 100013, China
T (86) (10) 6428 2233
F (86) (10) 6422 8586

