

12-1-3-2. Parts of HTP Positioner (Pilot relay portion)

(1,000 yen)

No.	Part No.	Description	Price	Quantity		Remarks
1	82510399-10300	Nut	0.3	1		
3	80250338-00100	Spring sheet	0.3	1		
4	80250307-00100	Bottom chamber assembly	7.8	1		
5	80250337-00100	Gasket	0.4	1F		
6	82512090-10100	Stem	0.7	1		
7	80250317-00100	Gasket	0.4	2		
7	80250317-0020V	Gasket	0.7	2		For high temperature
8	80250318-00100	Body plate assembly	9.1	1		
8-1	80250320-00100	Body plate	2	1		
8-2		Rolling pin		-		Deleted
8-3	80250325-00100	Nozzle	1.3	1		
8-4	80250321-00100	Flapper lever	0.4	1		
8-5	80250322-00100	Lever holder	1.3	1F		
8-6	80250324-00100	Clamp	0.7	1F		
8-7	HS100204-06000	Screw	0.7	1F		
9	80250326-00100	Top chamber assembly	7.8	1		
10	80250335-00100	Diaphragm plate	0.7	1		
11	80250334-00100	Input diaphragm	1.3	1		
11	80250334-0020V	Input diaphragm for high temperature	2.6	1		
12	80250331-00100	Input chamber assembly	2.6	1		
13	HS167320-38500	Bolt	1.3	1F		