

Section 5 – Configuration, Start-up, and Operation with SFC

5.1 Overview

Section contents

This section contains the following topics:

	Topic	See Page
5.1	Overview.....	155
5.2	SFC Smart Field Communicator.....	156
5.2.1	Communications Summary.....	156
5.2.2	Operating the SFC.....	159
5.3	Configuration with the SFC.....	165
5.3.1	Quick Set-up.....	173
5.3.2	Entering Tag Number.....	177
5.3.3	Adjusting Damping Time.....	179
5.3.4	Selecting Unit of Measurement.....	180
5.3.5	Selecting Type of Flow Measurement.....	183
5.3.6	Setting Range and Display Data.....	185
5.3.7	Setting Detector Data.....	191
5.3.8	Setting Alarm Set Points.....	193
5.3.9	Selecting Failsafe Modes.....	195
5.3.10	Selecting Digital (Relay) I/O Functions.....	197
5.3.11	Totalizer and Pulse Output.....	201
5.3.12	Velocity and Span Data.....	207
5.3.13	Upper and Lower Range Limits.....	209
5.3.14	Upper Range Values (URV).....	210
5.3.15	Converting Engineering Units.....	213
5.3.16	DE Configuration Parameters.....	215
5.4	Disconnecting the SFC.....	221
5.5	Start-up and Operation Using the SFC.....	222
5.5.1	Zeroing the Meter.....	223
5.5.2	Checking the Analog Output.....	225
5.5.3	Checking the Optional Pulse Output.....	228
5.5.4	Accessing Operation Data.....	230
5.5.5	Writing Data in Scratch Pad.....	235
5.5.6	Saving and Restoring a Database.....	237

About this section

This section applies to the user of the SFC Smart Field Communicator as the MagneW 3000 **PLUS** interface. The section covers connecting the SFC, how to configure, start-up, and operate the MagneW 3000 **PLUS** using the SFC only.

- *If you are using the DOP to configure and operate the flowmeter, refer to Section 4.*
- *If you are using the Universal Station to configure and operate the flowmeter, refer to Appendix A.*

Compatibility

ATTENTION If you are using an SFC model STS103 with an earlier software version than 5.0 or a model STS102, Honeywell strongly recommends that you use the DOP to configure the MagneW 3000 **PLUS**, as some functions will be limited. There are some parameters that can be changed at the SFC, but if they are downloaded to the flowmeter, output errors occur.