

Service Information

SCHMIDT® Strömungs-Sensor SS 20.501 / 502

Wartung

Sämtliche gelieferten Teile besitzen keine zu wartenden Teile.
Die Sensorköpfe können bei Verstaubung / Verschmutzung durch vorsichtiges Schwenken in warmem Wasser (ggfs mit Zusatz von sanftem Reinigungsmittel) gereinigt werden. Der SS 20.502 kann mit Alkohol gereinigt werden. Ein weicher Lappen oder eine weiche Bürste kann verwendet werden.

Vor der Reinigung ist der Sensor von der Stromversorgung zu trennen.
Keine harte Bürste oder harte Gegenstände zur Reinigung verwenden.

Re-Kalibrierung

Soweit kundenseitig keine andere Vorgabe getroffen ist, empfehlen wir die Wiederholung einer Kalibrierung im Rhythmus von 12 Monaten und im Windkanal des Herstellers vorzunehmen.

Ersatzteile oder Reparatur

Ersatzteile sind nicht verfügbar, da eine Reparatur nur beim Hersteller möglich ist.
Bei Defekten sind die Teile an den Lieferanten zur Reparatur einzusenden.

Für den Einsatz in wichtigen Anlagen empfehlen wir die Bereithaltung eines Ersatzgerätes.

Prüfzeugnisse und Werkstoffzeugnisse

Sind zu gelieferten Produkten nicht erforderlich. Eine Herstellererklärung ist nicht verfügbar.



Service Information

SCHMIDT® Flow Sensor SS 20.501 / 502

Maintenance

All parts supplied do not contain maintainable components.

If the sensor tip is contaminated or collected dust it can be cleaned by carefully swaying in warm water with soft detergents. A soft cloth or soft brush may be used for cleaning. SS 20.502 may also be cleaned using alcohol.

Disconnect sensor from power supply before cleaning. Do not use hard brushes or scratching tools for cleaning.

Re-Calibration

As far as it is not defined by the customer, we recommend to repeat a calibration every 12 months at the calibration wind channel of the original manufacturer.

Spare parts and repair

Spare parts are not available. A repair can only be executed at the manufacturer.

When used in critical applications we recommend to keep a replacement part at stock.

Test or factory certificates

Test or factory certificates are not required.